FOREWORD

Thanks for your selection of the servo drive. Meanwhile, please enjoy the comprehensive and sincere service from our technical teams.

The user manual is used for providing the instructions of installation and debugging, operation and use, fault diagnosis and attentions of routine maintenance. Please read this manual carefully before installing and using. This manual will be supplied together with servo drive, keep properly for further consulting and use.

If there are any questions in use and user cannot find any solutions in this manual, please contact and consult with our company or distributors directly. Our professional technique service team will offer the dedicated service to you. We are looking forward to your valuable comment and suggestion.

Our company is committed to the improvement of products and function upgrade. The content of user manual could be amended at any time without prior notice. The latest and detailed user manual will be launched in corporate website(www.euradrives.com).

Unpacking Inspection:

Please check as below carefully when unpacking:

Item to check	Description				
	Box contains ordered goods, user manual of				
Check if arrived goods are in complete	SD20 and accessories of servo drive.				
accord with the ordered product model?	Please use nameplates of servo drive and motor				
	to confirm.				
	Check the appearance of machine to see if there				
	is any damage during the transportation.				
Check if there is any damage of product?	Please contact with our company or distributor in				
	time to solve if any damage or lost.				
Check if the rotation axis of servo motor running smoothly?	It is normal if the axis can be rotated gently by hand, except for servo motor with brake.				

SAFETY SIGNS

The safety operation of the product depends on the correct installation and operation and proper maintenance. Make sure to comply with the below safety signs in user manual:



Incorrect operation could trigger hazardous conditions, which may result in personnel injury and death.



Incorrect operation could trigger hazardous conditions, which may result in moderate to minor personnel injury, or device damage.

In addition, matters mentioned in this sign may result in severe consequence sometimes.

The significance of identifier in the drive case as below:



High voltage, electrical shock hazard.



Heat surface, do not touch.


IEC STANDARD

IEC/EN 61800-5-1: 2007 Adjustable speed electrical power drive systems safety requirements. IEC/EN 61800-3: 2004/ +A1: 2012 Adjustable speed electrical power drive system. Part 3: EMC product standard including specific test methods.



Attention: Please connect electronic transformer sequence correctly, or may lead to danger.

Electronic transformer wiring diagram



NOTICE FOR USE:

■ Basic Terms

The user manual, unless special instructions, is used by the proper technical terms as below:

Servo drive: to drive and control servo motor.

Servo system: servo control system, which consist of servo drive, servo motor, instruction

control unit and peripheral devices.

User parameter: monitor or set the parameters related to servo drive, dividing into

monitoring parameter and setting parameter. Monitoring parameter: read only, cannot modify.

Setting parameter: can be read and modified. Based on the function, it can be

divided into function parameter and data parameter.

EtherCAT B. G							
Common Term	Definition						
CiA	CAN in Automation						
CoE	CANopen over EtherCAT						
DC	Distribute Clock: make all slave stations receive the same time						
ECAT	Short for EtherCAT						
ESC	EtherCAT Slave Controller						
ESM	EtherCAT state machine						
ETG	EtherCAT technology group						
EtherCAT	Real-time industrial Ethernet standard						
OD	Object dictionary						
INIT	EtherCAT state machine: Initialization state						
PREOP	EtherCAT state machine: Pre-operation state						
SAFEOP	EtherCAT state machine: Safe operation state						
OP	EtherCAT state machine: Operation state						
SyncManager	Synchronous manager: control the access of application storage area						
SDO	Service data object						
PDO	Process data object						
TXPDO	Transmit process data						
RXPDO	Receive process data						
APRD	Auto-increment physical read: Read slave storage area selected from the						
7 II KD	salve position in network segment.						
APWR	Auto-increment physical write: Write slave storage area selected from the						
	slave position in network segment.						
APRW	Auto-increment physical read-write single slave						
ARMW	Auto-increment physical multiple read-write slaves						
BRD	Broadcast read: read the physical storage area of all network slaves.						
FMMU	Fieldbus Memory Management Unit						
LRD	Read single or multiple salve storage area selected from logic address.						
LWR	Write data to slave area select from logic address.						
LRW	Read or write data to the slave storage area selected from logic address.						

■ Common Symbol

This manual is used symbols as below for convenient representation.

1. Mode description

PP: Profile Position mode	
CSP: Cycle Sync. Position mode	
PV: Profile Velocity mode	
CSV: Cycle Sync. Velocity mode	ALL: All modes
PT: Profile Toque mode	
CST: Cycle Sync. Torque mode	
HM: Homing mode	

2. Use of backslash (/)

Backslash is used in wiring circuit diagram, which is descripted for default logic of IO port. For input signal, with backslash means that the input signal is enabled when input side on, so default logic is positive logic; without backslash means that the input signal is enabled when input side is off, so default logic is negative logic.

For output signal, with backslash means that the output side is always off, it is on only when signal outputs; without backslash means that the output side is always on, it is off only when signal outputs.

3. Others

NC: Not connected; N/A: No unit

■ XML File Configuration Instruction:

- 1. Please use proper ".XML" file to configure or install on the EtherCAT master before using SD20-E series servo slave to connect to the EtherCAT master.
- 2. The version of ".XML" file can be identified by servo parameter So-60 (Index 2008h-3Dh). The ".XML" file can be read from servo slave and configured to master by operating EtherCAT master. User also can ask the related personnel for the XML file.
- Parameter entry-into-effect time
- 1. The entry-into-effect time of below parameters is 1000ms, which means that the parameter will take 1000ms to take into effect after setting the parameter. These parameters are Po500, Po501, Po503, Po504, Po506, So-20, So-21, So-22, So-24, and So-62.
- 2. Excluding the parameters above, the entry-into-effect time of the rest SD20-E servo parameters is 100ms.

FOI	REWORD1
I.	USER REMINDER9
1.1	SAFETY PRECAUTIONS9
1.2	STORAGE AND TRANSPORTATION
1.3	INSTALLATION
1.4	WIRING
1.5	MAINTENANCE AND INSPECTION
II.	PRODUCT INFORMATION
2.1	SERVO DRIVE INTRODUCTION
2.2	SERVO MOTOR INTRODUCTION18
2.3	COMBINATION OF SERVO DRIVE AND SERVO MOTOR23
2.4	INPUT FILTER MODEL AND DIMENSIONS
III.	INSTALLATION
3.1	SERVO DRIVE INSTALLATION
3.2	INSTALLATION OF SERVO MOTOR
IV.	WIRING
4.1	MAIN CIRCUIT WIRING48
4.2	ENCODER WIRING
4.3	INPUT/OUTPUT SIGNAL WIRING
4.4	WIRING FOR SERVO DRIVE AND SERVO MOTOR73
4.5	EMC81
V. K	EYPAD OPERATION AND PARAMETERS80
5.1	KEYPAD OPERATION80
5.2	PANEL DISPLAY81
5.3	KEYPAD OPERATING PROCEDURE84
VI.	COMMUNICATION FUNCTION INTRODUCTION
6.1	ETHERCAT COMMUNICATION88
6.2	MODBUS COMMUNICATION
6.3	INTRODUCTION OF COMMON BUS CONTROL MODE
VII.	CONTROL MODE
7.1	BEFORE RUNNING

7.1.1 WIRING CHECKING	115
7.1.2 POWER ON	115
7.1.3 PARAMETERS SETTING	116
7.1.4 SETTING THE OVERTRAVEL LIMIT FUNCTION	120
7.1.5 JOG OPERATION PROCEDURE	123
7.1.6 SEQUENCE CONTROL	124
7.1.7 SETTING THE BRAKING	126
7.1.8 SETTING ELECTRONIC GEAR	131
7.1.9 POSITION COMMAND FILTER	134
7.1.10 POSITION COMMAND INHIBIT FUNCTION	134
7.1.11 COMMAND PULSE CLEAR FUNCTION	135
7.1.12 FREQUENCY-DIVISION OUTPUT FUNCTION	135
7.2 SERVO STATUS SETTING	140
7.2.1 CONTROL WORD 6040H	142
7.2.2 STATUS WORD 6041H	142
7.3 PROFILE POSITION MODE (PP)	143
7.3.1 RELATED OBJECTS	144
7.3.2 RELATED FUNCTIONS	145
7.3.3 PATH GENERATOR	146
7.3.4 RECOMMENDED CONFIGURATION	149
7.4 PROFILE VELOCITY MODE (PV)	149
7.4.1 RELATED OBJECTS	149
7.4.2 RELATED FUNCTIONS.	151
7.4.3 RECOMMENDED CONFIGURATION	151
7.5 PROFILE TORQUE MODE (PT)	151
7.5.1 RELATED OBJECTS	152
7.5.2 RELATED FUNCTIONS	153
7.5.3 RECOMMENDED CONFIGURATION	153
7.6 CYCLIC SYNCHRONOUS POSITION MODE (CSP)	154
7.6.1 RELATED OBJECT	155
7.6.2 RELATED FUNCTION	156
7.6.3 RECOMMENDED CONFIGURATION	157
7.7 CYCLIC SYNCHRONOUS VELOCITY MODE (CSV)	157
7.7.1 RELATED OBJECTS.	157

	7.7.2 RELATED FUNCTIONS	158
	7.7.3 RECOMMENDED CONFIGURATION	159
	7.8 CYCLIC SYNCHRONOUS TORQUE MODE (CST)	159
	7.8.1 RELATED OBJECTS	159
	7.8.2 RELATED FUNCTIONS	160
	7.8.3 RECOMMENDED CONFIGURATION	161
	7.9 HOMING MODE (HM)	161
	7.9.1 RELATED OBJECTS	161
	7.9.2 RELATED FUNCTIONS	163
	7.9.3 HOMING OPERATION	163
	7.10 AUXILIARY FUNCTION	204
V	III. OBJECT DICTIONARY AND PARAMETER LIST	215
	8.1 OBJECT DICTIONARY CLASSIFICATION	215
	8.2 COMMUNICATION PARAMETER (1000H~1FFFH)	216
	8.3 MANUFACTURER DEFINED PARAMETERS	2165
	8.4 PARAMETERS DEFINED BY SUB-PROTOCOL (6000H)	270
D	X ADJUSTMENTS	282
	9.1 SUMMARY	282
	9.2 INERTIA IDENTIFICATION	283
	9.2.1 OFFLINE IDENTIFICATION	283
	9.2.2 ONLINE INERTIA IDENTIFICATION	286
	9.3 GAIN ADJUSTMENT	287
	9.3.1 SUMMARY	287
	9.3.1 SUMMARY	
		288
	9.3.2 AUTOMATIC GAIN ADJUSTMENT	288 289
	9.3.2 AUTOMATIC GAIN ADJUSTMENT	288 289 293
	9.3.2 AUTOMATIC GAIN ADJUSTMENT	288 289 293 295
X	9.3.2 AUTOMATIC GAIN ADJUSTMENT 9.3.3 MANUAL GAIN ADJUSTMENT 9.3.4 GAIN SWITCHOVER 9.4 VIBRATION SUPPRESSION	288 289 293 295 295
X	9.3.2 AUTOMATIC GAIN ADJUSTMENT 9.3.3 MANUAL GAIN ADJUSTMENT 9.3.4 GAIN SWITCHOVER 9.4 VIBRATION SUPPRESSION 9.4.1 VIBRATION SUPPRESSION FUNCTION	. 288 . 289 . 293 . 295 . 295 . 298
X	9.3.2 AUTOMATIC GAIN ADJUSTMENT	. 288 . 289 . 293 . 295 . 295 . 298

SD20-E Series

10.3 ALARM CODE AND TROUBLE SHOOTING	301
XI APPENDIX	307
11.1 ENCODER CABLE SELECTION	307
11.1.1 ABSOLUTE ENCODER CABLE	307
11.1.2 INCREMENTAL ENCODER CABLE	308
11.1.3 RESOLVER ENCODER CABLE	309
11.2 CONTROL CABLE	309
11.3 POWER CABLE	309
11.4 SHIELDED NETWORK CABLE	310
11.5 OTHER CABLE	311
11.6 MOTOR AND MATCHED CABLE	312

I. User Reminder

1.1 Safety Precautions

Important matters that users must abide by are explained in the chapter, which relates to product confirm, storage, transportation, installation, wiring, operation, inspection, disposal, and so on.



- After the power off for at least 5 min and the power light is off, using multimeter to check the voltage between B1 and N+ firstly, then the drive can be disassembled and installed. Otherwise, residual voltage may cause electric shock.
- Never touch the inside of servo drive, or electric shock may occur.
- Process insulating treatment for the connecting part of power terminal.
- The GND terminal of servo drive must be grounded, or electric shock may occur.
- Do not damage or hard pull the cables, or make the cable bear overweight, otherwise, the inside cable may be damaged or electric shock may occur, which also may cause the damage of the product.
- Unless the designated professional personnel. Do not disassemble or repair the drive oneself, or electric shock may occur.
- Follow the procedures required in user manual to test running.
- In the connection status of servo motor and machinery, wrong operation may cause the damage of machinery, sometimes even human injury occurs, so operate discreetly.
- Except for special purpose, do not modify max speed value (Po002). Or machinery may damage or human injury occurs.
- Within a period time after power on and off, do not touch cooling fin, external braking unit, and servo motor, because the temperature could be very high, which may cause scald.
- Never touch the rotating part when servo motor running.
- Put servo motor in the status that can be emergency stop anytime when running installed with the matched machinery.
- For safety purpose, install the emergency stop device in the machinery side.
- The brake of servo motor is not used to make sure the safe stop device. Damage of equipment may occur without installing stop device.
- If momentary power loss then power recovers during the running process, unexpected restart of machinery may occur, press emergency stop key when power off, and then proceed to operate until the power supplies stably, meanwhile, do not close to the machinery to avoid hazard.
- Take appropriate measures to ensure safety against an unexpected restart.
- Do not modify products. Failure to observe this warning may result in personal injury and damage to products.
- Install servo drive, servo motor and external braking unit on the noncombustible.
- MCTT (electromagnetic contactor) and NFB(no fuse breaker) must be installed between main circuit power (L1,L3 for 1-phase, L1/R, L2/S, L3/T for 3-phase).
- Do not leave flammable foreign object such as oil, grease and conductive matter such as screw, sheet metal, or may result in fire risk.

1.2 Storage and transportation



- Do not store or install product in the following circumstance to avoid fire, electric shock or damage:
 - Location subjects to direct sunlight;
 - Location that environment temperature exceeds the range specified in temperature condition of storage and installation.
 - Location that relative humidity exceeds the range specified in the humidity condition of storage and installation.
 - Location subjects to large temperature difference and dew formation;
 - Location subjects to causticity gas, flammability gas and location with more dust, dirt, salts and metal dust;
 - Location subjects to drips of water, oil and drug; location that vibration or shock can be transferred to subject.
- Do not place any load exceeding the limit specified on the packing box;
- Do not hold the product by the cables or motor shaft when transporting it;

1.3 Installation



- Do not install the product in the environment of water, corrosive gases, inflammable gases, or combustibles.
- Do not step on or place a heave object on the product.
- Do not block inlet or outlet ports, preventing foreign objects from entering the product.
- Be sure to install the product in the correct direction.
- Keep specified space between servo drive and cabinet surface and other devices.
- Do not apply any strong impact.

1.4 Wiring



- Do not connect a three-phase power supply to the U, V, or W output terminals.
- Connect U, V and W of servo drive directly to U, V, and W of servo motor, and avoid using MCtt when connecting.
- When DO output connecting to relay, pay attention to the polarity of FWD (fly-wheel diode). Otherwise, damage of servo drive may occur, and signal outputs abnormally.
- Firmly fasten and securely connect power supply terminals and motor output terminals.
- Do not connect 220V servo drive directly to 400V voltage.
- Do not bundle the power cable and signal cable together or passing through in the same pipeline. Keep both cables separated by at least 30cm.
- Use twisted-pair shielded wires or multi-core twisted pair shielded wires for signal and encoder cables.
- The maximum length is 3m for reference input cable and the maximum length is 15m for encoder cable.
- Take appropriate countermeasures to potential interference when using the servo system in following locations.
- Locations subjects to static electricity or other forms of noise.
- Locations subjects to strong electromagnetic fields and magnetic fields.
- Locations subjects to possible exposure to radioactivity.
- Repair or maintain servo drive only after the CHARGE indication goes off.

1.5 Maintenance and Inspection




- Repair or maintenance of the servo drive can be performed only by qualified personnel.
- Cut off all connections of servo drive before the insulation resistor test of servo drive.
- To avoid the discoloration or damage of cover, do not use petrol, diluent, ethyl alcohol, acidic and alkaline detergent to clean.
- When replacing the servo drive, resume operation only after transferring the previous user parameters to the new servo drive or computer.
- Do not attempt to change wiring while the power is ON.
- Do not disassemble the servo motor.

II. Product Information

2.1 Servo drive introduction

2.1.1 Nameplate and Model selection



2.1.1 Servo drive naming rule

Note: Servo drives of M1-MM4 structure have no buit-in filter, use can select external filter to satisfy EMC R3 standard. Full details are given in chapter 2.4. Servo drives of M4-M6 structure have optional built-in R3 filter, it depends on user's selection.




Fig 2.1.2 Servo drive nameplate

2.1.2 Connection to Peripheral Devices

Each part name of Servo drive




Fig 2.1.3 Composition of servo drive

2.1.3 Servo drive specification

1) Electrical specification

a) 220V servo drive

Item		M	1			M2		М3	
Drive model	101	201	401	751	102	122	182	302	452
Continuous output current (Arms)	1.2	1.5	2.8	3.5	4.5	6.0	8.0	12	17
Max output current (Arms)	3.6	4.2	8.0	9.8	12.6	16.8	22.4	33.6	47.6
Main circuit power	1-phase/3-phase AC 220V -15~+10% 50/60Hz								
Control circuit power	1-phase/3-phase AC 220V -15~+10% 50/60Hz								50Hz
Brake mode	External brake resistor Built-in brake resistor								

b) 380/400V servo drive

Item	M	12		М3		MM4		M4	M5		M6		
Drive model	102	152	202	302	452	552	752	113	153	183	223	303	373
Continuous output current (Arms)	3	3.5	6.0	8.0	10.0	12.0	20	23	32	38	44	60	75
Max output current (Arms)	8.4	9.8	16	19.2	28	33	56	64	80	95	110	150	187
Main circuit power	1-phase/3-phase AC 380/400V -10~+10% 50/60Hz												
Control circuit power		No control circuit											
Brake mode		Built	-in br	ake re	sistor			Е	xterna	l brake	resist	or	

2) Technical specification

Item		Content						
Input power	S2/T2	220VAC -15~+10% 50/60Hz						
supply	Т3	380/400VAC -10~+10% 50/60Hz						
Cont	rol mode	1. Profile position control mode (PP) 2. Profile velocity mode (PV) 3. Profile torque mode (PT) 4. Homing mode (HM) 5. Cycle synchronous position mode (CSP) 6. Cycle synchronous velocity mode (CSV) 7. Cycle synchronous torque mode (CST)						
Energy	-loss brake	Built-in or External brake resistor (external brake alternative) M1 frame and above 7.5kW drive: No built-in brake resistor. Other models: Built-in brake resistor						
	Control type	PMSM motor						
Control	Response frequency	PMSM servo: 1.2KHz						
feature	Baud rate	±0.01% (load 0~100%)						
	Speed fluctuation	PMSM: ±0.01% (VC, load fluctuation 0 to 100%)						
	Speed ratio	1: 10000						
	Communication protocol	EtherCAT protocol						
	Support service	CoE (PDO, SDO)						
	Synchronous method	DC distributed clock						
	Physical layer	100BASE-TX						
	Transmission speed	100 Mbit/s (100Base-TX)						
EtherCAT	Duplex mode	Full duplex						
specification	Transmission media	CAT5E class and above shielded cable						
	Transmission distance	The distance between 2 nodes <100M (good surroundings and cables)						
	Slave station	Max 65535 (lower than 100 in practical use)						
	Synchronization jitter	<1us						
Minimum		500us						

Input signal	Control input	Servo enabled, alarm reset, command pulse clear, command pulse prohibited, forward prohibited, reverse prohibited, forward torque limit, reverse torque limit, internal speed selection, internal position triggered, origin/mechanical origin searching triggered, zero speed clamp, probe etc.
	Feedback	Absolute value encoder. Incremental encoder. Resolver
	Control output	Servo ready, servo alarm, positioning reach, speed reach, electromagnetic brake output, rotation detection, speed limit, homing completed, torque limit etc.
Output signal Encoder signal frequency dividing output		 Encoder Z phases open-collector output; Phase -A, -B: frequency-division differential output (not isolated, any frequency-division ratio) Phase-Z is not frequency-division output. Z pulse time extended function.
Position	Input mode	EtherCAT communication set, internal register, high-speed pulse input
control Electronic gear ratio		 1. 0.01≤ B / A≤100 2. Support 2 groups of electronic gear, which can be selected or switchover by users.
Acceleration/Deceleration		The setting range of accel/decel time is $1\sim30000$ ms (from 0 accelerated to rated speed)
Comn	nunication	RS485/RS232 communication port is connected with PC, to set control parameters and to monitor servo. Support EtherCAT bus.
Parameter	Keypad	Use 4 keys to set parameter, which is displayed by 5 LEDs.
setting	PC/PLC	PC/PLC software can be used to set servo parameter through RS485 communication interface.
Monitor function		Output current, PN voltage, motor speed, motor feedback pulse, motor feedback revolution, given pulse, given pulse error, given speed, given torque etc.
Protection function		Main circuit overvoltage, undervoltage, overload, overcurrent, encoder error, overspeed, abnormal pulse control command, emergency stop, servo overheat, main-circuit power phase-loss, regeneration brake error, position, over position control, lithium battery alarm, Sync. loss, network initialization failure, sync. cycle setting error, sync. cycle excessive error etc.
Applicabl	e load inertia	Lower than 5 times of servo motor inertia.

2.1.4 Connection to Peripheral Devices




Fig 2.1.4 Composition of servo system

2.2 Servo motor introduction

2.2.1 Servo motor nameplate and model selection




Fig 2.2.1 Servo motor naming rule (for 180 flange and below 180 flange motor)




Fig 2.2.2 Servo motor naming rule (for 180 spigot and 250 spigot motor)




Fig 2.2.3 Servo motor nameplate (below 7.5kw)

SM1	SM17-0110R6EEDFS									
Pn:11kw	Un:	400V	Tn: 64 N.m							
Nn: 1700r/ min	In:	23A	Fan voltage 220 V							
TH CI. F IP54	Code:									
Magnetic filed a	angle	Date	:							
FRA DRIVES	PMS]	M								

Fig 2.2.4 Servo motor nameplate (above 11kw)

[note]

- 1. Please refer to the chapter of 《3.2.4 servo motor dimension》 for flange dimension.
- 2. 11kw and above servo motor can be installed by flanged mounting and base mounting, user should select the mounting type.

2.2.2 Servo motor components




Fig 2.2.5 component name of servo motor

2.2.3Servo motor model

1) 220V motor model

Motor model ^{note}		Rated power	Rated torque	Rated current	Rotation inertia
		W	N⋅m	A	10 ⁻⁴ Kg⋅m ²
	SMSA-201*32***	200	0.64	1.2	0.17
	SMSA-401*32***	400	1.27	2.8	0.29
	SMSA-751*33***	750	2.39	3.5	1.82
CMC	SMSA-102*33***	1000	3.5	4.5	2.9
SMS series	SMSA-122*35***	1200	4	5	6.9
3000r/min	SMSA-152*37***	1500	5	7.5	12.2
	SMSA-182*35***	1800	6	8	10.1
	SMSA-232*37***	2300	7.7	10	18.2
	SMSA-302*37***	3000	10	15.5	24.2
SMS series 2500r/min	SMSB-102*33***	1000	3.82	4	2.9
	SMMA-801*35**	800	4	3.5	6.9
	SMMA-851*37**	850	4	4	10.8
	SMMA-102*37**	1000	5	5	12.2
	SMMA-122*35**	1200	6	5	10.1
SMM series	SMMA-132*37**	1300	6	6	15
2000 r/min	SMMA-152*37**	1500	7.7	7.5	18.2
	SMMA-202*37**	2000	10	10	24.2
	SMMA-312*37**	3100	15	14	34.9
	SMMA-352*3A**	3500	17.2	16	55.3
	SMMA-452*3A***	4500	21.5	19	74.8
	SMMB-122*37**	1200	7.7	5	18.2
	SMMB-152*37**	1500	10	6	24.2
SMM series	SMMB-232*37**	2300	14.6	10	34. 9
1500 r/min	SMMB-272*3A**	2700	17.2	11	55.3
	SMMB-302*3A**	3000	19	12	66.3
	SMMB-432*3A**	4300	27	16	84.8

	SMMB-552*3A***	5500	35	24	119.5
	SMMB-752*3A***	7500	48	32	133
	SMLA-102*37**	1000	10	4.5	24.2
SML series	SMLA-152*37**	1500	14.3	7	34.9
1000 r/min	SMLA-292*3A**	2900	27	12	84.8
	SMLA-372*3A**	3700	35	16	119.5

2) 380V motor model

Motor model ^{note}		Rated power	Rated torque	Rated current	Rotation inertia
		W	N⋅m	A	10 ⁻⁶ Kg⋅m ²
SMSA-751*63***		750	2.39	2	1.82
	SMSA-102*63***	1000	3.5	3	2.9
GM 4G	SMSA-122*65***	1200	4	4	6.9
SMS series	SMSA-152*67***	1500	5	5	12.2
3000 r/min	SMSA-182*65***	1800	6	6	10.1
	SMSA-232*67***	2300	7.7	7	18.2
	SMSA-302*67***	3000	10	8	24.2
	SMMA-801*65**	800	4	2.5	6.9
	SMMA-851*67**	850	4	3	10.8
	SMMA-102*67**	1000	5	3	12.2
	SMMA-122*65**	1200	6	3.5	10.1
	SMMA-132*67**	1300	6	3.5	15
CANA :	SMMA-152*67**	1500	7.7	4.5	18.2
SMM series	SMMA-202*67**	2000	10	5.5	24.2
2000 r/min	SMMA-312*67**	3100	15	9	34.9
	SMMA-352*6A**	3500	17.2	8	55.3
	SMMA-452*6A**	4500	21.5	10	74.8
	SMMA-602*6A**	6000	27	14	84.8
	SMMA-752*6A***	7500	35.8	18	119.5
	SMMA-103*6A**	10000	48	24	133
SMM series	SMMB-122*67**	1200	7.7	4	18.2
1500 r/min	SMMB-152*67***	1500	10	4	24.2

	SMMB-232*67**	2300	14.6	6	34. 9
	SMMB-302*67**	3000	14.6	7.5	34. 9
	SMMB-272*6A**	2700	17.2	8	55.3
	SMMB-302*6A**	3000	19	8	66.3
	SMMB-432*6A**	4300	27	10	84.8
	SMMB-552*6A**	5500	35	12.5	119.5
	SMMB-752*6A**	7500	48	17	133
CMI sories	SMLA-102*67***	1000	10	3	24.2
SML series 1000 r/min	SMLA-292*6A**	2900	27	7	84.8
1000 1/111111	SMLA-372*6A**	3700	35	9	119.5

3) Servo motor above 11kw

		Rated power	Rated	Rated
Motor	model ^{note}	Kaled power	torque	current
		KW	$N \cdot m$	A
	SM15-0100*6EE*FL	10	64	20.7
	SM15-0124*6EE*FL	12.4	80	24.7
	SM15-0160*6EE*FL	16	102	33.5
SMM series	SM15-0180*6EE*FL	18	118	40
1500 r/min	SM15-0210*6FE*FL	21	135	43.2
	SM15-0240*6EE*FL	24	152	46.7
	SM15-0290*6FE*FL	29	185	57.5
	SM15-0350*6FE*FL	35	225	71.7
	SM17-0092*6EE*FL	9.2	52	18
	SM17-0110*6EE*FL	11	64	23
	SM17-0140*6EE*FL	14	80	29.2
SMM series	SM17-0180*6EE*FL	18	102	38.5
1700 r/min	SM17-0210*6FE*FL	21	118	45
	SM17-0240*6EE*FL	24	135	48.5
	SM17-0270*6EE*FL	27	152	57.5
	SM17-0330*6FE*FL	33	185	68
CMM	SM20-0100*6EE*FL	10	52	22
SMM series	SM20-0140*6EE*FL	14	64	30
2000 r/min	SM20-0180*6EE*FL	18	80	37

S	SM20-0220*6EE*FL	22	102	43
S	SM20-0250*6EE*FL	25	118	49
S	SM20-0280*6EE*FL	28	135	56.9
S	SM20-0300*6EE*FL	30	152	67
Si	M20-0360*6FE*FL	36	185	74

Note: ** represents shaft type and brake type, please refer to the chapter of servo motor naming rule.

2.3 Combination of servo drive and servo motor Combination of 220V servo motor and SD20-E servo drive

Motor modelnote		Power	Ada	ptable servodrive (No	able servodrive (Note)	
Mic	otor model ^{mote}	W	1 phase220V	3 phase 220V	Function code	
	SMSA-201F/S32***	200	SD20-E201S2M1	SD20-E201T2M1		
	SMSA-401F/S32***	400	SD20-E401S2M1	SD20-E401T2M1		
	SMSA-751*33***	750	SD20-E751S2M1	SD20-E751T2M1		
G) (G)	SMSA-102*33***	1000	SD20-E102S2M2	SD20-E102T2M2		
SMS series 3000r/min	SMSA-122*35***	1200	SD20-E122S2M2	SD20-E122T2M2		
3000r/min	SMSA-152*37***	1500	GD20 F192G2M2	GD20 E192T2M2		
	SMSA-182*35***	1800	SD20-E182S2M2	SD20-E182T2M2		
	SMSA-232*37***	2300	_	SD20-E302T2M3		
	SMSA-302*37***	3000	_	SD20-E452T2M3		
SMM series 2500r/min	SMSB-102*33***	1000	SD20-E102S2M2	SD20-E102T2M2	Esp. (D.)	
	SMMA-801*35**	800	GD20 E102G2M2	CD20 E102E2M2	F5D*B*	
	SMMA-851*37**	850	SD20-E102S2M2	SD20-E102T2M2		
	SMMA-102*37**	1000	SD20 E122S2M2	GD20 F122F2142		
	SMMA-122*35**	1200	SD20-E122S2M2	SD20-E122T2M2		
SMM series	SMMA-132*37**	1300	SD20-E182S2M2	GD 20 E102E21 12		
2000r/min	SMMA-152*37**	1500	SD20-E162S2M2	SD20-E182T2M2		
	SMMA-202*37**	2000		SD20-E302T2M3		
	SMMA-312*37**	3100		SD20-E452T2M3		
	SMMA-352*3A**	3500		3D20-E43212N13		
	SMMA-452*3A***	4500	_	SD20-E552T2M4		
SMM series	SMMB-122*37**	1200	SD20-E122S2M2	SD20-E122T2M2		

1500r/min	SMMB-152*37**	1500	SD20-E182S2M2	SD20-E182T2M2
	SMMB-232*37**	2300		
	SMMB-272*3A**	2700	_	SD20-E302T2M3
	SMMB-302*3A**	3000	_	
	SMMB-432*3A**	4300	_	SD20-E452T2M3
	SMMB-552*3A***	5500	_	SD20-E552T2M4
	SMMB-752*3A***	7500	_	SD20-E752T2M4
	SMLA-102*37**	1000	SD20-E102S2M2	SD20-E102T2M2
SML series	SMLA-152*37**	1500	SD20-E182S2M2	SD20-E182T2M2
1000r/min	SMLA-292*3A**	2900		SD20-E302T2M3
	SMLA-372*3A**	3700	_	SD20-E452T2M3

Combination of 380V servo motor and SD20 servo drive

M / 1 Inote		Power	Adaptable servodrive (No	te)	
Mo	otor model ^{note}	W	Three-phase 380 v	Function code	
SMS series	SMSA-751*63***	750	SD20-E102T3M2		
	SMSA-102*63***	1000	SD20-E10213M2		
	SMSA-122*65***	1200			
	SMSA-152*67***	1500	SD20-E202T3M3		
3000r/min	SMSA-182*65***	1800			
	SMSA-232*67***	2300	SD20-E302T3M3	F5D*B*	
	SMSA-302*67***	3000	SD20-E452T3M3		
	SMMA-801*65***	800			
	SMMA-851*67**	850	SD20-E102T3M2		
	SMMA-102*67**	1000			
	SMMA-122*65**	1200	SD20-E152T3M2		
CMMi	SMMA-132*67**	1300	SD20-E13213M2		
SMM series 2000r/min	SMMA-152*67**	1500	SD20 E202T2M2		
20001/111111	SMMA-202*67**	2000	SD20-E202T3M3		
	SMMA-312*67**	3100			
	SMMA-352*6A**	3500	SD20-E452T3M3		
	SMMA-452*6A**	4500		İ	
	SMMA-602*6A**	6000	SD20-E752T3MM4		

SMMA-752*6A** 7500 SMMA-103*6A** 10000 SD20-E153T3M4 SMMB-122*67** 1200 SMMB-152*67** 1500 SD20-E202T3M3 SMMB-232*67** 2300 SMMB-272*6A** 2700 SMMB-302*6A** 3000 SMMB-302*6A** 4300 SD20-E302T3M3 SMMB-432*6A** 5500 SD20-E552T3M3 SMMB-752*6A** 7500 SD20-E752T3M4 ML series 000r/min ML series 000r/min SMLA-102*67** 1000 SD20-E102T3M2 SMLA-292*6A** 2900 SD20-E302T3M3 SMLA-372*6A** 3700 SD20-E302T3M3 SMLA-372*6A** 3700 SD20-E302T3M3 SMLA-372*6A** 3700 SD20-E452T3M3 SMLA-372*6A** 10000 SD20-E302T3M3 SMLA-372*6A** 10000 SD20-E302T3M3 SMLA-372*6A** 3700 SD20-E452T3M3 SMLA-372*6A** 3700 SD20-E452T3M3 SM15-0100*6EE*FL 10000 SMLS-0160*6EE*FL 10000 SD20-E113T3MM4 SM15-0160*6EE*FL 12400 SM15-0160*6EE*FL 16000 SMMS series SM15-0180*6EE*FL 18000
SMMB-122*67** 1200 SD20-E202T3M3 SMMB-152*67** 1500 SD20-E202T3M3 SMMB-232*67** 2300 SD20-E302T3M3 SMMB-272*6A** 2700 SD20-E302T3M3 SMMB-302*6A** 3000 SMMB-432*6A** 4300 SD20-E452T3M3 SMMB-552*6A** 5500 SD20-E552T3M3 SMMB-752*6A** 7500 SD20-E752T3MM4 SMLA-102*67** 1000 SD20-E102T3M2 SMLA-292*6A** 2900 SD20-E302T3M3 SMLA-372*6A** 3700 SD20-E302T3M3 SMLA-372*6A** 3700 SD20-E452T3M3 SM15-0100*6EE*FL 10000 SD20-E113T3MM4 SM15-0124*6EE*FL 12400 SM15-0160*6EE*FL 12400 SD20-E183T3M5 SM20-E183T3M5
SMMB-152*67** 1500 SD20-E202T3M3
SMMB-232*67** 2300 SMMB-272*6A** 2700 SD20-E302T3M3 SMMB-302*6A** 3000 SMMB-432*6A** 4300 SD20-E452T3M3 SMMB-552*6A** 5500 SD20-E552T3M3 SMMB-752*6A** 7500 SD20-E752T3MM4 SMLA-102*67** 1000 SD20-E102T3M2 SMLA-292*6A** 2900 SD20-E302T3M3 SMLA-372*6A** 3700 SD20-E302T3M3 SMLA-372*6A** 3700 SD20-E452T3M3 SM15-0100*6EE*FL 10000 SM15-0124*6EE*FL 12400 SM15-0160*6EE*FL 16000 SD20-E183T3M5 SM20-E183T3M5
MM series SMMB-272*6A** 2700 500r/min SMMB-302*6A** 3000 SMMB-432*6A** 4300 SD20-E452T3M3 SMMB-552*6A** 5500 SD20-E552T3M3 SMMB-752*6A** 7500 SD20-E752T3MM4 ML series SMLA-102*67** 1000 SD20-E102T3M2 SMLA-292*6A** 2900 SD20-E302T3M3 SMLA-372*6A** 3700 SD20-E452T3M3 SM15-0100*6EE*FL 10000 SM15-0124*6EE*FL 12400 SM15-0160*6EE*FL 16000 SD20-E183T3M5
SD20-E302T3M3 500r/min SMMB-302*6A** 3000 SD20-E302T3M3 SMMB-432*6A** 4300 SD20-E452T3M3 SMMB-552*6A** 5500 SD20-E552T3M3 SMMB-752*6A** 7500 SD20-E752T3MM4 SMLA-102*67** 1000 SD20-E102T3M2 SMLA-292*6A** 2900 SD20-E302T3M3 SMLA-372*6A** 3700 SD20-E452T3M3 SM15-0100*6EE*FL 10000 SM15-0124*6EE*FL 12400 SM15-0160*6EE*FL 16000 SD20-E183T3M5
SMMB-432*6A** 4300 SD20-E452T3M3 SMMB-552*6A** 5500 SD20-E552T3M3 SMMB-752*6A** 7500 SD20-E752T3MM4 ML series 0000r/min SMLA-102*67** 1000 SD20-E102T3M2 SMLA-292*6A** 2900 SD20-E302T3M3 SMLA-372*6A** 3700 SD20-E452T3M3 SM15-0100*6EE*FL 10000 SM15-0124*6EE*FL 12400 SM15-0160*6EE*FL 16000 SD20-E183T3M5
SMMB-552*6A** 5500 SD20-E552T3M3 SMMB-752*6A** 7500 SD20-E752T3MM4 ML series SMLA-102*67** 1000 SD20-E102T3M2 SMLA-292*6A** 2900 SD20-E302T3M3 SMLA-372*6A** 3700 SD20-E452T3M3 SM15-0100*6EE*FL 10000 SM15-0124*6EE*FL 12400 SM15-0160*6EE*FL 16000 SD20-E183T3M5
SMMB-752*6A** 7500 SD20-E752T3MM4 SMLA-102*67** 1000 SD20-E102T3M2 SMLA-292*6A** 2900 SD20-E302T3M3 SMLA-372*6A** 3700 SD20-E452T3M3 SM15-0100*6EE*FL 10000 SM15-0124*6EE*FL 12400 SM15-0160*6EE*FL 16000 SD20-E113T3MM4 SM20-E113T3MM4
ML series 000r/min SMLA-102*67** 1000 SD20-E102T3M2 SMLA-292*6A** 2900 SD20-E302T3M3 SMLA-372*6A** 3700 SD20-E452T3M3 SM15-0100*6EE*FL 10000 SM15-0124*6EE*FL 12400 SM15-0160*6EE*FL 16000 SD20-E183T3M5
ML series 000r/min SMLA-292*6A** 2900 SD20-E302T3M3 SMLA-372*6A** 3700 SD20-E452T3M3 SM15-0100*6EE*FL 10000 SM15-0124*6EE*FL 12400 SM15-0160*6EE*FL 16000 SD20-E183T3M5
SMLA-292*6A** 2900 SD20-E302T3M3 SMLA-372*6A** 3700 SD20-E452T3M3 SM15-0100*6EE*FL 10000 SD20-E113T3MM4 SM15-0124*6EE*FL 12400 SD20-E113T3MM4 SM15-0160*6EE*FL 16000 SD20-E183T3M5
SMLA-372*6A** 3700 SD20-E452T3M3 SM15-0100*6EE*FL 10000 SD20-E113T3MM4 SM15-0124*6EE*FL 12400 SD20-E113T3MM4 SM15-0160*6EE*FL 16000 SD20-E183T3M5
SM15-0124*6EE*FL 12400 SD20-E113T3MM4 SM15-0160*6EE*FL 16000 SD20-E183T3M5
SM15-0124*6EE*FL 12400 SM15-0160*6EE*FL 16000 SD20-E183T3M5
SD20-E183T3M5
500r/min SM15-0210*6EE*FL 21000 SD20-E223T3M5
SM15-0240*6EE*FL 24000
SM15-0290*6EE*FL 29000 SD20-E303T3M6
SM15-0350*6EE*FL 35000 SD20-E373T3M6
SM17-0092*6EE*FL 9200
SM17-0110*6EE*FL 11000 SD20-E113T3MM4
SM17-0140*6EE*FL 14000 SD20-E153T3M4
MM series SM17-0180*6EE*FL 18000 SD20-E183T3M5
700r/min SM17-0210*6EE*FL 21000 SD20-E223T3M5
SM17-0240*6EE*FL 24000
SD20-E303T3M6 SM17-0270*6EE*FL 27000
SM17-0330*6EE*FL 33000 SD20-E373T3M6
SM20-0100*6EE*FL 10000 SD20-E113T3MM4
MM series SM20-0140*6EE*FL 14000 SD20-E153T3M4
000r/min SM20-0180*6EE*FL 18000 SD20-E183T3M5
SM20-0220*6EE*FL 22000 SD20-E223T3M5

SM20-0250*6EE*FL	25000	SD20-E303T3M6	
SM20-0280*6EE*FL	28000	SD20-E30313M0	
SM20-0300*6EE*FL	30000	SD20 E272T2M6	
SM20-0360*6FE*FL	36000	SD20-E373T3M6	

Note:

- 1. 5.5 kw and above 5.5kw servo drive doesn't have dynamic brake. M1, MM4 structure and above servodrive doesn't have built-in resistor, customer should purchase braking resistor separately.
- 2. R means resolver, F means 14-core 2500ppr incremental encoder, G means 8-core 2500ppr incremental encoder, H means 4-core 23-bit incremental encoder, S means 4-core 17-bit absolute, and T means 4-core 23-bit absolute.
- 3. ** means shaft type and brake type, please refer to the chapter of servo motor naming rule.

2.4 Input filter model and dimensions

SD20 series can supply EMC R3 level filter, the filter of M1-MM4 structure is external, the filter of M4-M6 structure is built-in.

1. **Input filter model:**

Servo drive model	Filter model	Filter model	Remarks
	(FILTEMC)	(SCHAFFNER)	
SD20-E101S2M1	FT130-6-T2/02.12.205	FN2090NN-6-06	
SD20-E201S2M1	FT130-6-T2/02.12.205	FN2090NN-6-06	
SD20-E401S2M1	FT130-6-T2/02.12.205	FN2090NN-10-06	
SD20-E751S2M1	FT130-10-T2 /02.12.209	FN2090LL-10-06	
SD20-E102S2M2	FT130-20-T2 /02.12.207	FN2090-20-06	
SD20-E122S2M2	FT130-20-T2 /02.12.207	FN2090-20-06	1.
SD20-E182S2M2	FT130-20-T2 /02.12.207	FN2090-20-06	User can select
SD20-E101T2M1	FT330-6-T3 /02.17.136	FN3258-7-44	different brand
SD20-E201T2M1	FT330-6-T3 /02.17.136	FN3258-7-44	filters according to actual situation.
SD20-E401T2M1	FT330-6-T3 /02.17.136	FN3258-7-44	to actual situation.
SD20-E751T2M1	FT330-6-T3 /02.17.136	FN3258-7-44	
SD20-E102T2M2	FT330-10-T3	FN3258-7-44	
SD20-E122T2M2	FT330-10-T3	FN3258-16-44	
SD20-E182T2M2	FT330-15-T3	FN3258-16-44	
SD20-E302T2M3	FT330-20-T3	FN3258-30-33	

SD20-E452T2M3	FT330-30-T3	FN3258-30-33	
SD20-E102T3M2	FT330F-6-T3	FN3258-7-44	
SD20-E152T3M2	FT330F-6-T3	FN3258-7-44	
SD20-E202T3M3	FT330F-15-T3	FN3258-16-44	
SD20-E302T3M3	FT330F-15-T3	FN3258-16-44	
SD20-E452T3M3	FT330F-20-T3	FN3258-16-44	
SD20-E552T3M3	FT330F-20-T3	FN3258-30-33	
SD20-E752T3MM4	FT330F-50-T3	FN3258-42-33	
SD20-E113T3MM4	FT330F-50-T3	FN3258-42-33	
SD20-E153T3M4	_	_	Built-in
SD20-E183T3M5	_	_	Built-in
SD20-E223T3M5	_		Built-in
SD20-E303T3M6		_	Built-in
SD20-E373T3M6	_	_	Built-in

- 2. Input filter dimensions.
- (1) FT series filter dimension




Fig 2.4.1 FT130 series

Model	Remarks
FT130-6-T2	
FT130-10-T2	
FT130-20-T2	




Fig 2.4.2 FT330 series

Model	Remarks
FT330-6-T3	
FT330-15-T3	
FT330F-6-T3	
FT330F-15-T3	
FT330F-20-T3	




Fig 2.4.3 FT330F series




Fig 2.4.4 FT330F series

Model	Remarks
FT330F-30-T3	

(2) FN series filter dimension




Fig **2.4.5 FN2090** series

	FN2090NN-6-06	FN2090LL-10-06	FN2090-20-06
A	85	113.5±1	113.5±1
В	54	57.5±1	57.5±1
C	30.3	45.4±1	45.4±1
D	64.8	94±1	94±1
E	49.8	56	56
F	75	103	103
G	27	25	25
Н	12.3	12.4	12.4
I	20.8	32.4	32.4
J	19.9	15.5	15.5
K	5.3	4.4	4.4
L	6.3	6	6
M	0.7	0.9 0.9	
N	6.3X0.8	6.3X0.8	6.3X0.8




Fig 2.4.6 FN2090 series

	FN3258-7-44	FN3258-16-44	FN3258-30-33	FN3258-42-33
A	190	250	270	310
В	40	45	50	50
C	70	70	85	85
D	160	220	240	280
E	180	235	255	295
F	20	25	30	30
G	4.5	5.4	5.4	5.4
Н	1	1	1	1
I	22	22	25	25
J	M5	M5	M5	M6
K	20	22.5	25	25
L2	29.5	29.5	39.5	37.5

III. Installation

3.1 Servo drive installation

3.1.1 Installation conditions

Environment Conditions	Equipment location	In an indoor location, preventing exposure from direct sunlight, free from dust, tangy caustic gases, flammable gases, steam or the salt-contented etc.
	Altitude/level	1000m and below(derate use if over 1000m)
	Atmospheric pressure	86kPa~106kPa
	Operating temperature	-10℃~40℃
	Storage temperature	-20℃~60℃
	Humidity	0~ 90% RH (no water-bead coagulation)
	Vibration Strength	Below 0.5G (4.9m/s ²) ,10~60Hz (Discontinuous)
	IP rating	IP20
	Power system	TN system (Note)

Note: TN system: A power distribution system having one point directly earthed, the exposed conductive parts of the installation being connected to that points by protective earth conductor.

3.1.2 Installation precautions

To make good effect of cooling circulation, user needs to ensure to leave enough space for ventilation when installing servo drive. The typical minimum installation dimension is shown as below in figure 3.1.1.




Fig 3.1.1 typical min installation dimension

If multiple drives are installed in parallel, the distance between each drive is at least 20mm in horizontal, at least 100mm in vertical. Cooling fan can be placed on top to avoid the temperature rise. Consult with supplier if smaller space need.




Fig 3.1.2 min installation dimension for multiple drives installed

3.1.3 Servo drive dimension

M1 structure dimension: (unit: mm)




Fig 3.1.3 Servo drive structure size 1

M2 structure dimension: (unit: mm)




Fig 3.1.4 servo drive structure size 2

M3 structure dimension: (unit: mm)




Fig 3.1.5 servo drive structure size 3

MM4 structure dimension: (unit: mm)




Fig 3.1.6 Servo drive structure size 4




Fig 3.1.7 Servo drive structure size 5

M5 structure dimension: (unit: mm)




Fig 3.1.8 Servo drive structure size 6

M6 structure dimension: (unit: mm)




Fig 3.1.9 Servo drive structure size 7

Note: All changes of structure dimension without prior notice.

3.2 Installation of Servo motor

3.2.1 Installation location

- Install the servo motor in an environment free from corrosive or inflammable gases or combustibles, such as hydrogen sulfide, chlorine, ammonia, sulphur gas, chloridize gas, acid, soda and salt.
- Select and use the servo motor with oil seal in a place with grinding fluid, oil spray, iron powder or cuttings.
- Install the servo motor away from heat sources such as heating stove.
- Never use the servo motor in an enclosed environment. Working in the enclosed environment could result in high temperature of the servo motor, which will shorten its service life.

3.2.2 Installation conditions

	Equipment location	Prevent tangy caustic gases and flammable gases
	Altitude	1000m or below (derate use if over 1000m)
	Atmospheric pressure	86kPa~106kPa
Environment	Operating temperature	-15°C~40°C (no freezing)
conditions	Storage temperature	-20~80°C
	Humidity	Below 90% (no water-bead coagulation)
	Vibration Strength	Below 0.5G (4.9m/s ²) ,10~60Hz (Discontinuous)
	IP rating	IP64

3.2.3 Precautions on installation

Item	Description
Anticorrosive	Clean the anticorrosive paint that coasts the end of motor shaft before installation, and then proceed the rust-proof treatment.
Encoder	Use screw hole on the shaft end when installing pulley on the servo motor shaft with key slot. To install pulley, insert the double-headed nail into screw hole firstly, use cushion ring on the surface of coupling end, and use nut to lock in the pulley gradually. Install with the screw hole in shaft end for the servo motor shaft with key slot. Use methods such as friction coupling for servo motor shaft without key slot. To avoid bearings bear strong impact of load, use remover to assemble pulley. Install protective cover or similar device on the rotation zone, such as pulley.
Alignment	Use coupler to align the servo motor shaft with the shaft of the equipment when connecting to the machinery.
Orientation	Servo motor can be installed either horizontally or vertically.
Handing oil and water	When using in the location with water drops, the protection level of servo motor needs to be confirmed firstly. When using in the location that oil could drops into the shaft through position, do not remove the oil seal of servo motor. Precautions on using servo motor with oil seal The oil surface must be under the oil seal lip. Use oil seal in favorably lubricated condition. When servo motor installed vertically, do not make oil seal lip deposit oil.
Cable stress	Make sure there are no bends or tension on cables, especially for the signal line, which core is only 0.2mm or 0.3mm, do not make too tight when wiring.

Precautions on the connector parts as below:

- Make sure there are no foreign matters such as dust and metal chips in the connector before connecting.
- When the connectors are connected to the motor, make sure to connect from the side of servo motor main-circuit cables firstly, and the grounding cable must be earthed reliably. If connecting from the side of encoder cables firstly, encoder fault may occur because of the potential difference between PE.
- Make sure the correct pin arrangement.
- Do not exert force to connector, which is made from resin.
- When handling a servo motor with its cable connected, do not exert force to the connector. The connector may be damaged because of the stress.

3.2.4 Servo motor dimension

Connectors




Fig 3.2.1 Motor installation dimension

Model	L(mm)	L (mm) With brake	Weight (Kg)	Remarks
SMSA-201F/S32***	146	194	1.2	The screw hole size:
SMSA-401F/S32***	171	219	1.6	M4 X 12




Fig 3.2.2 Servo motor installation dimension

Model	L (mm)	L (mm) With brake	Weight (Kg)	Remarks
SMSA-751**3***	192	237	2.8	The serow hele size :
SMSA-102**3*** SMSB-102*33***	219	263	3.8	The screw hole size : M5 X 22





Fig 3.2.3 Servo motor installation dimension


Model	L (mm)	L (mm) with brake	Weight (kg)	Remarks	
SMSA-122**5*** SMMA-801**5***	250	298	6.5	The screw hole size :	
SMSA-182**5*** SMMA-122**5***	280	328	8	M6 X 25	



Tolerance standard:GB/1804-2000-M

Fig 3.2.4 Servo motor installation dimension

Model	L (mm)	L(mm)with brake	Weight (Kg)	Remarks
SMMA-851**7*** SMSA-152**7*** SMMA-102**7***	230	278	7	
SMMA-132**7***	238	286	7.7	
SMSA-232**7*** SMMA-152**7*** SMMB-122**7***	251	299	8	The screw hole size:
SMSA-302**7*** SMMA-202**7*** SMMB-152**7*** SMLA-102**7***	274	322	10	M6 X 25
SMMA-312**7*** SMLA-152*37*** SMMB-232**7***	301	349	12	



Tolerance standard:GB/1804-2000-M

Fig 3.2.5 Servo drive installation dimension

Model	L without brake (mm)	L with brake (mm)	Weight (Kg)	Remarks
SMMA-352**A*** SMMB-272**A***	300	382	18	
SMMA-452**A*** SMMB-302**A***	320	402	20	
SMMA-602*6A*** SMMB-432**A*** SMLA-292**A***	332	414	23	The screw hole size is M10 X 30
SMMA-752*6A*** SMMB-552**A*** SMLA-372**A***	370	452	29	
SMMA-103*6A*** SMMB-752**A***	416	498	36	

[Note]: 180 servo motor includes general motor and fan motor. Fan servomotor can obviously reduce temperature rise. The length of fan motor is 81mm longer than general motor.




Fig 3.2.6 Servo motor installation dimension

Base	D1	D2	D3	D4	D5	L1	L2	L3	L6	L7	L8	L9	L10
E	180	42	14	215	14.5	77	5	39	12	56	185	75.5	147
F	250	48	18	300	17.5	112.5	4.5	53	14	90	185	128	147

Base	H1	H2	Н3	H4	Н5	M1	M2
E	124	200	224	12	200	254	278
F	160	240	294	13	266	356	396

Motor rated torque Nm (△T=100° C)	46	68	84	96	130	147	160	196	220	275	330	380	428	481
Motor rated torque Nm (△T=65°C)	40	52	64	80	102	118	135	152	185	225	270	307	324	385
Stand spigot	Е	Е	Е	Е	Е	Е	Е	Е	F	F	F	F	F	F
L4 (mm)	267	285	312	354	396	436	478	520	317	370	423	476	529	583
L5 (mm)	345	397 -	429	471	513	555	597	619	511. 5	560. 5	609. 5	658. 5	707. 5	756. 5

IV. WiringInternal block diagram of servo system as below:




Fig 4.1.1 220V servo internal principle diagram




Fig 4.1.2 380V servo internal principle diagram

4.1 Main circuit wiring

4.1.1 Names and functions of Main circuit wiring terminals

1) 220V names and functions of main circuit wiring terminals

Terminal Symbol	Terminal Name	Function
L1/R, L2/S, L3/T	Main circuit power input terminals	Connect 3-phase 220V input power Connect 1-phase 220V power supply between L1 and L3. (2kW and above drive only connects to 3-phase power supply)
L1C, L2C	Control power input terminals	Connect any 2 phase in 3-phase power supply or single-phase power supply.
	B2, B3: Built-in braking resistor connecting terminal	Terminals are shorted by default. Use built-in brake resistor. (built-in braking resister for the drive of M2 and above cover)
B1/P, B2/B, B3	B1/P, B2/B: External braking resistor connecting terminal	Normally no need to connect. If built-in braking capacity is insufficient, remove the jumper between B2 and B3, and connect external braking resistor between B1 and B2.
N+, N- DC reactor connecting termin		Terminals are shorted by default. Connect DC reactor between both terminals when restraining power harmonic.
U, V, W	Servo motor connection terminals	Connect to servo motor.
⊕, "	Ground terminal	The servo drive must be grounded.

2) 380V names and functions of main circuit wiring terminals

Terminal Symbol	Terminal Name	Function
R/L1, S/L2, T/L3	Main circuit power input terminals	Connect 3-phase 380V input power supply (R, S, T are the main circuit power input terminals of M4 and above drives)
L1C, L2C	Connection forbidden	Disabled
	B2, B3: Built-in braking resistor connecting terminal	Terminals are shorted by default. Use built-in brake resistor. (no built-in braking resistor for 7.5kW and above drives)
B1/P, B2/B, B3	B1/P, B2/B: External braking resistor connecting terminal	Normally no need to connect. If the built-in braking capacity is insufficient, remove the jumper between B2 and B3, connect external braking resistor between B1 and B2.
N+、N-、—	DC bus reference terminal	Forbidden to ground or connect to zero line.
U, V, W	Servo motor connection terminals	Connect to servo motor.

(a) Grou	und terminal	The servo drive must be grounded.
----------	--------------	-----------------------------------

4.1.2 Wiring of Main circuit terminals

There are two main circuit terminals of servo drive: plug-in terminal and screw terminal. The usage of plug-in terminal is mainly described as below:

1) The dimension of electric wire:

Solid wire: Ø $0.5 \sim Ø 1.6$ mm;

Twisted wire: 0.8 mm2~3.5mm2 (American-standard AWG28~AWG12)

- 2) Connection method:
 - 1. Strip off the wire skin for around 5~6cm.
 - 2. Use pull-rod or slotted screwdriver with 3.0~3.5mm edge to open circle opening by pushing the upper openings of terminal connector.
 - 3. Insert the core of wire into the circle openings, then loose the screwdriver or pull-rod.




Fig 4.1.3 Main circuit terminals connection method

SD20 series product divides into 220V and 380V voltage class, 220V terminals as below:




Fig 4.1.4 220V servo power terminals wiring diagram,

380V terminals as below:




Fig 4.1.5 380V servo power terminals wiring diagram

When using screw terminal for wiring, if lug is needed, dimension of screw terminal as below:




Fig 4.1.6 main circuit terminals sketch diagram

Note: The figure above is only sketch, exact shape in kind prevail.

Table 4.1.1 SD20 series servo screw terminals dimension table

Starratuma	Main circuit terminals				
Structure	X (mm)	Y (mm)	Screw	Locked Torque (Nm)	
M3	9.9	13.0	M4	1.24 (Max)	
MM4	10.2	12.7	M4	1.46	
M4	11.7	16	M6	2.5	
M5	13	16	M5	2.0	
M6	20.3	23.5	M8	2.8	

EURA recommends below tube cable lug for wiring:

 Table 4.1.2
 Tube cable lug dimension and appearance

Tube c	able lug	D (mm)	d2(mm)	B (mm)	Appearance
	1.25-3	4.0	3.7	5.5	
	1.25-4	4.0	4.3	8.0	∳ d2
TVR	2-3M	4.5	3.7	6.6	B
series	2-4	4.5	4.3	8.5	
	5.5-3	6.3	3.7	9.5	
	5.5-4	6.3	4.3	9.5	
	1.25-3	4.0	3.2	5.7	
	1.25-4	4.0	1.2	7.2	
TVS	W	4.0	4.3	1.2	\$\phi\$ d2 \B
series	2-3W	4.5	3.7	6.2	φ D .
	5.5-3	6.3	3.2	7.3	
	5.5-4	6.3	4.3	8.2	

4.1.3 Typical main circuit wiring example

(1) 220V servo main circuit wiring example:




Fig 4.1.7 Typical wiring of 220V servo main circuit

Instructions:

- 1. Built-in brake resistor is used by default, B2 and B3 are shorted. If external resistor is need, remove the jumper between B2 and B3, then connect external resistor between B1 and B2.
- 2. RLY: Externally connected alarm signal output relay.
- 3. KM1: contactor, select connect or disconnect main circuit power input by manual switch.
- 4. If using the absolute encoder multi-circle function, install battery in the side of encoder cable with battery unit.



Note: emergency stop circuit should be connected in the wiring design of main circuit. Make sure that stop running of the equipment and cut off the power supply immediately to avoid the accident.

(2) 380V servo main circuit wiring example




Fig 4.1.8 Typical wiring of 380V servo main circuit

Instructions:

- 1. Built-in brake resistor is used by default, B2 and B3 are shorted. If external resistor is need, remove the jumper between B2 and B3, then connect external resistor between B1 and B2.
- 2. RLY: Externally connected alarm signal output relay.
- 3. KM1: contactor, select connect or disconnect main circuit power input by manual switch. Mention the use of zero line if using 220V contactor.
- 4. N: DC bus reference.



Note: emergency stop circuit should be connected in the wiring design of main circuit. Make sure that stop running of the equipment and cut off the power supply immediately to avoid the accident.

4.1.4 Precautions for Main Circuit Wiring

- Do not connect the power supply cables to U, V and W. Failure to comply will cause damage to the servo drive.
- B2 and B3 are shorted with a jumper by default. If external brake resistor is used, remove the jumper between B2 and B3, and then connect the external resistor between B1 and B2, wrong wiring method will cause damage of servo drive.
- Do not connect the resistor between DC bus terminals B1 and N+ (N-). Failure to comply may cause a fire.
- When cables are bundled in a duct, take current reduction into consideration since the cooling condition becomes poor.
- Ordinary cables become quickly aged in high temperature environment, easily sclerotic and broken in low temperature environment. Thus, use heat resistance cables in high temperature environment and take heat preservation measures in low temperature environment.
- The bending radius of a cable shall exceed 10 times that of its outer diameter to prevent the internal wire core from breaking due to long time bending.
- Do not bundle power cables and signal cables together or run them through the same duct. Power and signal cables must be separately by at least 30cm to prevent interference.
- High residual voltage may still remain in the servo drive when the power supply is cut off. Do not touch the power terminals within 5 minutes after power-off.
- Use grounding cable with the same cross-sectional area as the power cable.
- Ground the servo drive reliably.
- Do not power on the servo drive when any screw of the terminal block or any cable becomes loose. Otherwise, fire hazards may occur.
- Wiring operation should be performed by professionals.
- To avoid electric shock, user must wait for at least 5 min after power-off, "charge" indicator off, and no voltage between "B1/P" and "N+/-" tested by multimeter, then proceed to disconnect and assemble the servo motor.
- Do not damage or hard pull cables, or make the cable bear overweight, otherwise, inside cable may be damaged or electric shock may occur, which also cause damage of the product.
- Specification & installation mode of external wiring need adhere to local laws & regulations.

4.1.5 The Selection Guide of Leakage Protection Circuit Breaker

The leakage current of servo drive is higher than 3.5mA, so it must be protected by earthing. The servo device can generate DC leakage current in protective conductor, B type (time-delay) ≥200mA leakage protection circuit breaker must be selected.

When malfunction of leakage protection circuit breaker occurs, user can:

- Use the leakage protection breaker of higher rated action current and time-delay type.
- ◆ Reduce the carrier frequency of servo drive.
- ◆ Shorten the length of motor driving cable.
- ◆ Add the leakage current suppression measurement.
- ◆ The recommended brand of leakage protection circuit breaker is CHINT and SCHNEIDER.

4.2 Encoder wiring

Precautious of encoder wiring:

- Ground the servo drive and shielded layer of the servo motor reliably. Otherwise, the servo drive will report a fault alarm;
- Do not connect to "NC" terminal;
- To determine the length of the encoder cable, consider voltage drop caused by the cable resistance and signal attenuation caused by the distributed capacitance.
- Encoder cable and power cable must be separately by at least 30cm;
- If encoder cable needs to add another cable because of short, make sure that the shielded layer and grounding are connected reliably

4.2.1 Absolute encoder connector terminal layout

CN2 Encoder Connector Terminal Layout is as shown in figure 4-2-1.




Fig 4.2.1 Absolute encoder terminal layout

Table 4.2.1 Encoder connector terminal name and function

Terminal code	Terminal abbreviation	Signal name	Function
CN2- 1	NC	NO CONNECTION	NO CONNECTION
CN2- 2	VCC	+5V power	+5V power
CN2- 3	PS	PG serial signal	Serial signal
CN2- 4	/PS	PG serial signal	Serial signal
CN2- 5	GND	Cassadias	Casyadias
CN2- 6	GND	Grounding	Grounding
CN2- 7	NC	NO CONNECTION	NO CONNECTION
CN2- 8	NC	NO CONNECTION	NO CONNECTION
CN2- 9	NC	NO CONNECTION	NO CONNECTION
	HOUSING		Shielded (plug cover)

Note: 4-core 23 bit incremental encoder has the same terminal layout as absolute encloder. 4-core 23 bit incremental encoder and absolute encoder are communication encoder.

4.2.2 Resolver encoder connector terminal layout

CN2 Encoder Connector Terminal Layout is as shown in figure 4-2-2.




Fig 4.2.2 Resolver encoder terminal layout

Table 4.2.2 Encoder connector terminal name and function

Terminal code	Terminal abbreviation	Signal name	Function
CN2- 1	RE2	Resolver stimulus signal	Connect to servo motor stimulus signal.
CN2- 2	VCC	+5V power output	+5V power output
CN2- 3	KTY	motor temperature sensor	Motor temperature detection
CN2- 4	NC	No connection	No connection
CN2- 5	RE1	Resolver signal stimulus	Connect to servo motor stimulus signal.
CN2- 6	COS-	Resolver differential signal	Connect to servo motor differential signal.
CN2-7	COS+	Resolver differential signal	Connect to servo motor differential signal.
CN2-8	SIN-	Resolver differential signal	Connect to servo motor differential signal.
CN2- 9	SIN+	Resolver differential signal	Connect to servo motor differential signal.
	HOUSING		Shielded (plug cover)

4.2.3 Incremental encoder connector terminal layout

CN2 Encoder Connector Terminal Layout is as shown in figure 4-2-3.




Fig 4.2.3 Incremental encoder terminal layout

Table 4.2.3 14-core Encoder connector terminal name and function

Terminal code	Terminal abbreviation	Signal name	Function
CN2- 1	V	Encoder V phase input	Connect to motor encoder V phase
CN2- 2	U	Encoder U phase input	Connect to motor encoder U phase
CN2- 3	Z	Encoder Z phase input	Connect to motor encoder Z phase
CN2- 4	В	Encoder B phase input	Connect to motor encoder B phase
CN2- 5	A	Encoder A phase input	Connect to motor encoder A phase
CN2- 6	/V	Encoder /V phase input	Connect to motor encoder /V phase
CN2- 7	/U	Encoder /U phase input	Connect to motor encoder /U phase
CN2-8	/Z	Encoder /Z phase input	Connect to motor encoder /Z phase
CN2- 9	/B	Encoder /B phase input	Connect to motor encoder /B phase
CN2-10	/A	Encoder /A phase input	Connect to motor encoder /A phase
CN2-11	/W	Encoder /W phase input	Connect to motor encoder /W phase
CN2-12	W	Encoder W phase input	Connect to motor encoder W phase
CN2-13	VCC	+5V power	+5V power
CN2-14	GND	Grounding	Grounding
CN2-15			NO CONNECTION
	HOUSING		Shielded (plug cover)

 Table 4.2.4
 8-core encoder connector terminal name and function

Terminal code	Terminal abbreviation	Signal name	Function
CN2- 1			NO CONNECTION
CN2- 2			NO CONNECTION
CN2- 3	Z	Encoder Z phase input	Connect to motor encoder Z phase
CN2- 4	В	Encoder B phase input	Connect to motor encoder B phase
CN2- 5	A	Encoder A phase input	Connect to motor encoder A phase
CN2- 6			NO CONNECTION
CN2- 7			NO CONNECTION
CN2- 8	/Z	Encoder/Z phase input	Connect to motor encoder /Z phase
CN2- 9	/B	Encoder/B phase input	Connect to motor encoder /B phase
CN2-10	/A	Encoder/A phase input	Connect to motor encoder /A phase
CN2-11			NO CONNECTION
CN2-12			NO CONNECTION
CN2-13	VCC	+5V power	+5V power
CN2-14	GND	Grounding	Grounding
CN2-15			NO CONNECTION
	HOUSING		Shielded (plug cover)

4.3 Input/output signal wiring




Fig 4.3.1 Wiring diagram in bus mode

CN3 Input/output signal connector terminal layout, see figure 4.3.2 as below:




Fig 4.3.2 I/O signal connector (connected to CN3) terminal layout

1	AO1	
2	GP	
3	HPULS-	
4	HPULS+	
5	HSIGN+	
6	HSIGN-	
7	ALM+	
8	ALM-	
9	DO1+	
10	DO1-	
11	DO2-	
12	NC	
13	DI8	
14	AO2	
15	NC	

16	PZO+	
17	PZO-	
18	DI1	
19	DI2	
20	DI3	
21	DI4	
22	DI5	
23	NC	
24	GND	
25	NC	
26	DO2+	
27	NC	
28	NC	
29	+24V	
30	CM	

31	DO4-
32	DO4+
33	PBO-
34	PBO+
35	PAO-
36	PAO+
37	ZO
38	DI6
39	DI7
40	GND
41	DO3+
42	DO3-
43	NC
44	NC

4.3.1 Position command input signal and function

Table 4.3.1 Position command signal

Signal Name		Pin No.	Function
	HPULS+	CN3-4	High speed pulse position command
III:-1I	HPULS-	CN3-3	High-speed pulse position command
High-speed	HSIGN+	CN3-5	High speed myles direction command
pulse receiver	HSIGN-	CN3-6	High-speed pulse direction command
	GND	CN3-24	Signal reference

The max input frequency identified by position command receiving circuit see table as below:

Pulse mode		Max frequency	Remark
High-speed	Differential	4M	5V command

High-speed pulse command input:

In host device side, the output circuit of high-speed command pulse and symbol, only output to servo drive via differential drive.




Fig 4.3.3 High-speed pulse input interface circuit

- ★ Make sure the differential input is 5V, otherwise, servo drive receives unstable pulses and the servo internal parts could result in damage.
- ★ Make sure the 5V grounding of host device is connected to GND of servo drive, otherwise, below problems may occur:
 - 1. Pulse loss occurs when inputting pulse;
 - 2. Interference occurs when receiving pulse, which make the received pulse inaccurate.

4.3.2 Digital input signal and function

Signal Name		Pin No.	Function
Programmable input terminal	DI1	CN3-18	
	DI2	CN3-19	
	DI3	CN3-20	DI1-DI7 are normal digital inputs, input mode is switch signal, which function can be modified according to the practical requirements. See details in 8.3.10 for DI/DO function specification.
	DI4	CN3-21	
	DI5	CN3-22	
	DI6	CN3-38	
	DI7	CN3-39	
	High-speed DI		Function
	DI8+	CN3-13	DI8 is a high-speed DI channel. When DI8 is used,

	DI8-	CN3-14	the input pulse frequency range is 0-200khz, the pulse duty ratio cannot be lower than 20%.
Signal N	ame	Pin No.	Function
	DO1+	CN3-9	
	DO1-	CN3-10	
	DO2+	CN3-26	
	DO2-	CN3-11	DO1-DO4 and ALM are DO output, output mode
Programmable output terminal	DO3+	CN3-41	is switch signal, which function can be modified
	DO3-	CN3-42	according to the practical requirements. See details
	DO4+	CN3-32	in 8.3.10 for DI/DO function specification.
	DO4-	CN3-31	
	ALM+	CN3-7	
	ALM-	CN3-8	
Signal N	ame	Pin No.	Function
Built-in 24V power supply	+24V	CN3-29	Provide 24V power supply, voltage range: 20V~30V, load capacity of power supply is 100mA; Switch to external power supply if external load is higher than 100mA.
	CM	CN3-30	24V power supply reference

1) Digital input circuit

DI1~DI7 7-channel input terminals circuit adopt bidirectional photoelectric coupler isolation circuit, the common port of photoelectric coupler is GP, can be connected to power supply or GND of power supply, see figure 4.3.3 and 4.3.4. The primary side of photoelectric coupler needs DC power supply configured by user to reduce the interference of internal circuit.

DI8 is high-speed optocoupler channel, which can be used as either high-speed DI or normal DI optocoupler. Common input mode in DI circuit as below:

a) Passive contact

Including relay contact, travel switch, keys, buttons etc. common interface circuit as below:




Fig 4.3.3 Passive contact interface circuit

b) Active contact

Including some photoelectric sensor, hall sensor, transistor-type PLC etc. common interface circuit as below:




Fig 4.3.4 Active contact interface circuit

c) DI8 terminal connection

DI8 terminal adopts high-speed optocoupler, can either be used as high-speed DI count signal, or either be used as common DI optocoupler. Wiring as below when using DI8 contact as the high-speed optocoupler circuit:




Fig 4.3.5 DI8 wiring diagram



- ★ To avoid the wrong wiring, there is diode in parallel in DI8 circuit; make wiring strictly followed by the instruction showed in figure above, wrong wiring or improper use may result in damage of internal circuit.
- ★ DI8 circuit receives 24V command by default.

2) Digital output circuit

Output signals, ALM and DO1~DO4, adopt the photoelectric coupler of Darlington output, strong driving capacity can drive small relay directly, and also can drive isolation components such as photoelectric coupler to realize driving much more load. Assure the limit of output current in use (max current is 50mA). Common interface circuit as below:

a) Relay output:




Fig 4.3.6 Relay output interface correct circuit diagram




Fig 4.3.7 Wrong wiring circuit of relay output interface



- ★ Relay is the inductive load; Anti-parallel free-wheeling diode must be connected to both ends of the load.
- ★ Anti-access of free-wheeling diode could result in damage of servo drive.

b) Optocoupler isolated output




Fig 4.3.8 photoelectric coupler output interface circuit



The power supply and current-limiting resistance must be matched to ensure the external optocoupler conduct reliably.

The max allowance voltage and current of servo drive internal optocoupler output circuit: (Max voltage: DC 30V; Max current: DC 50mA)

4.3.3 Encoder frequency-dividing output signal and function

Signal name		Pin No.	Function	
General - output - terminal -	PAO+	CN3-36	A phase frequency-dividing output signal	
	PAO-	CN3-35		
	PBO+	CN3-34	B phase frequency-dividing output signal	
	PBO-	CN3-33		
	PZO+	CN3-16	7.1.6.1.1	
	PZO-	CN3-17	Z phase frequency-dividing output signal	
	OZ	CN3-37	Z pulse open collector output signal	
	CM	CN3-30	Signal reference	

Servo drive makes frequency division for encoder input signal by internal frequency-dividing circuit, one way is to use differential bus mode to output. The interface circuit can be divided into high-speed photoelectric coupler reception and differential chip reception. Take sample as encoder A-phase (PAO) pulse frequency-dividing output, the interface circuit shows as below figure 4.3.9 and figure 4.3.10.




Fig 4.3.9 photoelectric coupler interface circuit of encoder frequency-dividing output




Fig 4.3.10 differential chip interface circuit of encoder frequency-dividing output



- ★ Receiver chip is recommended to use AM26LS32;
- ★ Matched resistance is recommended to use $200\Omega/1/4W$;

Encoder Z phase frequency-dividing output circuit uses open collector

signal for providing feedback signal when forming position control system. In upper device side, use photoelectric coupler and relay circuit to receive.




Fig 4.3.11 collector OZ signal interface circuit

4.3.4 Communication wiring

(1) Serial port specification

RS485 communication interface locates in CN1 of controller; the figure below is the connector terminals diagram and definition.




Fig 4.3.12 communication port CN1 pin terminal sequence diagram

Table 4.3.2 Communication port terminal name and function

Terminal	Name	Function
CN1-1	VCC	5V power
CN1-2	RS232-RXD	Receiver terminal of RS232

CN1-3	B-	Differential output -
CN1-4	GND	Reference terminal
CN1-5	RS232-TXD	Transmission terminal of
		RS232
CN1-6	A+	Differential output +

Note: CN1-1 can provide the load capacity of 100mA. Switch to external power if >100mA.

(2) EtherCAT interface specification

Connect EtherCAT gridding cable to network interface with metal shielded layer, dividing into input (IN) and output (OUT). The electrical characteristics meet IEEE 802.3 and ISO 8877.





Table 4.3.3 Communication port terminal name and function


Pin	Definition	Description
1	TX+	Data send+
2	TX-	Data send-
3	RX+	Data receive+
4	Reserved	Reserved
5	Reserved	Reserved
6	RX-	Data receive-
7	Reserved	Reserved
8	Reserved	Reserved

EtherCAT topological structure connects flexibly, there is basically no limit for connection, the servo has IN and OUT interface, the topological connection as below:

Linear connection:



Redundant ring connection:



(3) Communication cable

EtherCAT communication cable use Ethernet Category 5(100BASE-TX) network cable or high-intensity shielded network cable. The shielded network cable is also needed for the servo drive, and the length of cable cannot be longer than 100M. Shielded network cable can enhance the anti-interference capacity of servo system.

4.3.5 Multiple online wiring

Alarm signal is normally closed output by default, cut-off between ALM+ and ALM- when servo drive alarms. When using in multiple drives, considering that faulty of any drive can cut off the main circuit power supply, so it can be designed that the alarm signals of multiple drives are strung together.

(1) Wiring for multiple 220V servo drives




Fig 4.3.13 220V multiple online wiring

(2) Wiring for multiple 380V servo drives




Fig 4.3.14 380V multiple online wiring

4.3.6 The usage of absolute encoder

Encoder type	Resolution ratio	Multi-turn data output range	Action when out of allowed range
17 bit absolute encoder	16-bit multiturn 17-bit single-turn	0~+65535	·Multi-turn data will turn to 0 when data exceeds upper limit (+65535) of forward direction.
23 bit absolute encoder	16-bit multiturn 23-bit single-turn	0 -+03333	•Multi-turn data will turn to 0 when data exceeds lower limit (+65535) of reverse direction.

User can read absolute position by MODBUS protocol. In practical control, absolute position can be read by Modbus protocol when motor is in static state (see details in 6.2), and then motor real-time position can be got by PG frequency-division output pulse count.

(1) The usage of battery


Please install battery cell in order to save position data of absolute value encoder.

Please purchase special cable and battery box of manufacture.


Battery installations steps:

A: open cover of battery cover.

B: Install battery as below figure:



C: Close the cover of battery cell.



(2) Battery replacement

When battery voltage drops to about 1.3V, servo drive will trip into "AL-19" (battery voltage is

lower). At this time, multi-turn data still exists, but user should change battery immediately, otherwise multi-turn data will be lost when battery voltage keeps dropping. Please change battery according to the following steps:

- 1. Please change battery when servo drive is POWER ON.
- 2. After changing battery, reset servo drive by hold pressing "SET" key to clear "AL-19".
- 3. Repower on the servo drive, if no abnormal situation, it means battery change succeeds. Note:
- 1. When servo drive trips into AL-24 (under voltage protection), the alarm can be reset only by setting mechanical origin again.
- 2. If user wants to shield AL-24 alarm, please set 2008h-27h (So-38) to 0, reset encoder alarm by 2008h-2Ch (So-43), and fault reset by hold pressing "reset" key.

4.4 Wiring for servo drive and servo motor

Attention:

- 1. The "number" mentioned in following description means pin number of plug.
- 2. If the number of plug chip does not match the quantity of plug chip mentioned in user manual, user should follow the number in user manual to weld, no connection for the pin number that not mentioned in user manual
- 3. The bonding definition of core-saving encoder means remove U/V/W signal on the base of normal incremental encoder, the followings described in table is only for normal incremental encoder.

4.4.1 The connection of encoder cable

(1) Absolute encoder layout

Table 4.4.1 Absolute encoder plug cable sequence

No.	Name	Function
1	PE	Grounding
2	VCC	Encoder power
3	GND	Encoder power grounding
4	BAT(+)	Battery anode
5	BAT(-)	Battery cathode
6	PS	Absolute value encoder serial signal
7	/PS	Absolute value encoder serial signal

(2) Incremental encoder layout

Table 4.4.2 DB15 plug-type encoder plug cable sequence

No.	Name	Function
1	A	Encoder A phase
2	В	Encoder B phase
3	Z	Encoder Z phase

4	U	Encoder U phase
5	V	Encoder V phase
6	/A	Encoder /A phase
7	/B	Encoder /B phase
8	/Z	Encoder /Z phase
9	/U	Encoder /U phase
10	/V	Encoder /V phase
11	W	Encoder W phase
12	/W	Encoder /W phase
13	VCC	Encoder power
14	GND	Encoder grounding
15		No connection
	HOUSING	HOUSING

Table 4.4.3 Aviation plug encoder plug cable sequence

No.	Name	Function
1	PE	grounding
2	A	Encoder A phase
3	/A	Encoder /A phase
4	В	Encoder B phase
5	/B	Encoder /B phase
6	U	Encoder U phase
7	/U	Encoder /U phase
8	V	Encoder V phase
9	/V	Encoder /V phase
10	W	Encoder W phase
11	/W	Encoder /W phase
12	VCC	Encoder power
13	GND	Encoder grounding
14	Z	Encoder Z phase
15	/Z	Encoder /Z phase

(3) Resolver encoder cable sequence

Table 4.4.6 15-core aviation plug encoder cable sequence

No.	Name	Function
1	PE	Grounding
2	COS+	Resolver differential signal
3	NC	No connection
4	NC	No connection
5	COS-	Resolver differential signal

6	NC	No connection
7	NC	No connection
8	NC	No connection
9	NC	No connection
10	SIN+	Resolver differential signal
11	NC	No connection
12	NC	No connection
13	SIN-	Resolver differential signal
14	RE1	Resolver excitation signal
15	RE2	Resolver excitation signal

Table 4.4.7 10-core aviation plug type encoder cable sequence

No.	Name	Function
1	RE1	Resolver excitation signal
2	RE2	Resolver excitation signal
3	COS+	Resolver differential signal
4	COS-	Resolver differential signal
5	SIN+	Resolver differential signal
6	SIN-	Resolver differential signal
7	KTY+	Motor thermistor signal
8	KTY-	Motor thermistor signal
9	PE	Grounding
10	NC	No connection

4.4.2 The connection of power cable

a) 4-core power AMP plug




Fig 4.4.1 4-core power aviation plug sketch map

Name	Cable color	Function
U	Yellow	Drive input
V	Blue	Drive input
W	Red	Drive input
PE	Yellow-green/black	Grounding

b) 4-core power aviation plug



Fig 4.4.2 4-core power aviation plug sketch map

No.	Name	Function
1	PE	Grounding
2	U	Drive input
3	V	Drive input
4	W	Drive input

c) Brake cable plug




Fig 4.4.3 2-core power-off brake AMP plug sketch map

No.	Name	Function
1	+	DC 24V +
2	_	DC 24V -




Fig 4.4.4 3-core DC 24V power-off brake plug sketch map

Plug No.	Name	Function
1	+	DC 24V +
2	_	DC 24V -
3	_	None

4.5 EMC

4 5 1 Definition

Electromagnetic compatibility (EMC) describes the ability of electronic and electrical devices or systems to work properly in the electromagnetic environment and not to generate electromagnetic interference that influences other local devices or systems.

In other words, EMC includes two aspects: The electromagnetic interference generated by a device or system must be restricted within a certain limit; the device or system must have sufficient immunity to the electromagnetic interference in the environment.

4.5.2 Installation Environment

The system manufacturer using the servo drive is responsible for compliance of the system with the European EMC directives. Based on the application of the system, the integrator must ensure that the system complies with standard EN 61800-3: 2004 Category C2, C3 or C4.

The system (machinery or appliance) installed with the servo drive must also have the CE mark. The system integrator is responsible for compliance of the system with the EMC directives and standard EN 61800-3: 2004 Category C2.

If applied in the first environment, the servo drive may generate radio interference. Besides the CE compliance described in this chapter, users must take measures to avoid such interference, if

necessary.


4.5.3 Selection and Installation of Peripheral EMC Devices

An EMC filter installed between the servo drive and the power supply can not only restrict the interference of electromagnetic noise in the surrounding environment on the servo drive, but also prevent the interference from the servo drive on the surrounding equipment. SD20 works with external filter and input filter according to different power rating. The installation precautions are as follows.


- Strictly comply with the ratings when using the EMC filter. The EMC filter is category I
 electric apparatus, and therefore, the metal housing ground of the filter should be in good
 contact with the metal ground of the installation cabinet on a large area, and requires good
 conductive continuity. Otherwise, it will result in electric shock or poor EMC effect.
- 2) The ground of the EMC filter and the PE conductor of the servo drive must be tied to the same common ground. Otherwise, the EMC effect will be affected seriously.
- 3) The EMC filter should be installed as closely as possible to the power input side of the servo drive.

4.5.4 Shielded Cable

The shielded cable must be used to satisfy the EMC requirements of CE marking. The Shielded cable are shown in the following figure



To suppress emission and conduction of the radio frequency interference effectively, the shield of the shielded cable is cooper braid. The braided density of the cooper braid should be greater than 90% to enhance the shielding efficiency and conductivity, as shown in the following figure.



The installation precautions are as follows:

- 1) Symmetrical shielded cable is recommended. The four-conductor shielded cable can also be used as an input cable.
- 2) The motor cable and PE shielded conducting wire (twisted shielded) should be as short as possible to reduce electromagnetic radiation and external stray current and capacitive current of the cable. If the motor cable is over 100 meters long, an output filter or reactor is required.
- 3) It is recommended that all control cables be shielded.
- 4) The motor cables must be laid far away from other cables. The motor cables of several servo drives can be laid side by side.
- 5) It is recommended that the motor cables, power input cables and control cables be laid in different ducts. To avoid electromagnetic interference caused by rapid change of the output voltage of the servo drive, the motor cables and other cables must not be laid side by side for a long distance.
- 6) If the control cable must run across the power cable, make sure they are arranged at an angle of close to 90° . Other cables must not run across the servo drive.
- 7) The power input and output cables of the servo drive and weak-current signal cables (such as control cable) should be laid vertically (if possible) rather than in parallel. The filter, servo drive and motor should be connected to the system (machinery or appliance) properly, with spraying protection at the installation part and conductive metal in full contact.

V. Keypad Operation and Parameters

5.1 Keypad operation

5.1.1 Keypad description

The name of keypad and each part as figure below:




Fig 5.1.1 Keypad sketch map

Identifier	Name	Function
SON	Indicator (green)	Indicating that Servo is on.(Light on when servo on)
ALM	Indicator (red)	Indicating that malfunction occurs.(Light on when faulty occurs)
RUN	EtherCAT state indicator	EtherCAT state machine indicator
PANAL	LCD Display	The LCD display (5-digit display panel) shows the monitor codes, parameter settings and operation values of the servo drive.
MODE	Mode key	1 Switching between function groups.2 Displaying malfunction codes in turn.
(UP)	UP	1 Press the key to increase the displayed value. 2 Hold the key for 0.5s to increase setting the value slowly. 3 Hold the key for over 1s to increase setting value rapidly. 4 Used to forward start in jogging run.
(DOWN)	DOWN	 Press the key to decrease the display value. Hold the key for 0.5s to decrease setting value slowly. Hold the key for over 1s to decrease setting value rapidly. Used to reverse start in jogging run.
(SET)	shift/set	1 Hold the key for 0.5s to enter into parameter setting mode 2 Pressing the key can move the cursor to the left and then change parameter settings (blinking digits) by using arrow keys. 3 Hold the key for 0.5s to confirm and set current value into the current user parameter. 4 Hold the key for 2s to reset the malfunction.

5.2 Panel Display

5.2.1 Switchover of panel display




Fig 5.2.1 the switchover of user parameter area sketch map

After main circuit is powered on, servo status display So-09 is displayed in the keypad, the Mfr's value of which is servo output speed. The display content will switch among monitor functional area (Lo- \Box), auxiliary functional area (So- \Box), main functional area (Po \Box), motor parameters area (Ho \Box), high-speed counting area (PL \Box) and main shaft induction servo parameter area by pressing MODE key.

If fault occurs, current fault code will be displayed circularly.

5.2.2 Parameters display



The representation method in this manual is Po001.

The hollow segment code represents blinking operating digits, which is the adjustable digits.

In this manual, three parameters modes is adopted to introduce the parameters.

represents five operating digits in keypad.

■ One parameter mode (if no special instruction, the parameters belong to this mode)

 $\begin{picture}(20,0) \put(0,0){\line(0,0){10}} \put(0,0$

For example:

Ex 1: Ho005 Servo motor interphase resistance is $10000 \text{ m}\Omega_{2}$, the display content is:

10000

(The unit is $10^{-3} \Omega$) The quoting mode is Ho005=10000.

Ex 2: Ho018 Servo motor installation angle is -10000, the display content is:

1.0.0.0.0.

(Unit N/A) The quoting mode is Ho018=-10000.

Note: if all decimal points are lit, the current value is negative value.

■ Two parameters mode

 $d\;\underline{\ }\,\underline{\ }\,\underline{$

 $\mathbf{Y} \quad \mathbf{X}$

X and Y represent an adjustable parameter digit separately.

For example:

Ex: Po407 CN3-5 terminal function is alarm-reset. The display content is:

8 8

The quoting mode is Po407.X=1.

■ Four parameters mode

b \square \square \square Four parameters mode means each digit except the first digit is an adjustable parameter digit.

D C B A

A, B, C and D represents an adjustable parameter digit separately.

Ex: at position mode, the pulse command type of pulse +pulse is selected, and then the last digit of Po300 is set to1. The display content is:





The quoting mode is Po300.A=1.

■ Five parameters display

EDCBA

For example: set value of HOME, Po136=131072, the actual display content is as below:





Note: The parameter action scope means the running mode that the parameter works.

5.3 Keypad Operating Procedure

5.3.1 Example for parameter setting of monitoring functional area

Take usage of Lo-14(DI8~DI5 status display) as the example:




Fig 5.3.1 Terminal status monitoring sketch map

5.3.2 Example for parameter setting of auxiliary area

Take usage of So-14 (JOG run) as the example:




Fig 5.3.2 Jog run sketch map

5.3.3 Example of parameter setting




Fig 5.3.3 parameter setting sketch map

If the parameter digits are longer than 5 digits, the setting method is as below: Take setting home searching shift pulses (Po123) to 100000000 as example:




Fig 5.3.4 parameter setting sketch map

VI. Communication Function Introduction

SD20-E series servo drive supports EtherCAT and serial communication, EtherCAT supports CoE protocol, serial communication supports MODBUS protocol. The chapter mainly introduces the EtherCAT and MODBUS communication.

6.1 EtherCAT Communication

EtherCAT is a real-time Industrial Ethernet technology with the feature of high performance, low cost, flexible topology and easy operation, which can be used in industrial field high-speed I/O network. EtherCAT system consists of master station and slave station. EtherCAT uses standard Ethernet technology, and supports almost all topology type, which includes linear, tree, star etc. It uses standard Ethernet physical layer, transmission medium twisted-pair or optical fiber (100Base-TX or 100Base-FX).

Based on the field bus of Ethernet network, EtherCAT technology was launched by Germany BECKHOFF Automation Company in 2003. EtherCAT has features of high-speed and high data efficiency, supporting multiple devices to connect topological structure, which master requires standard Ethernet controller, and which slave requires special slave control chip.

The main features of EtherCAT as below:

- Wide applicability: any control unit with Ethernet controller for commercial use can be used as EtherCAT master;
- Meet Ethernet standard: according to the EtherCAT frame structure, EtherCAT data adopts for standard Ethernet frame (IEEE802.3), therefore, EtherCAT can coexist in same bus with other Ethernet device and protocol, the transmission rate can reach 2×100M bit/s;
- Flexible wiring: support varieties of topological structures such as linear, star and tree type;
- High efficiency: maximum using Ethernet bandwidth for data transmission.
- Excellent synchronization performance: realize lower than 1µs clock synchronization of each slave by accurate calibration of synchronous clock;
- To support more kinds of devices and wider application layer, EtherCAT establishes the application protocol: CoE (CANopen Over EtherCAT)

CoE (CANopen Over EtherCAT)

CANopen is originally the application layer based on the system of CAN (Control Area Network) bus. EtherCAT protocol supports profile CiA402 of CANopen protocol in application layer, called CoE. SD20-E series servo supports CoE protocol.

EtherCAT supports CANopen, meanwhile makes relevant expansion, the main features as below:

- Access CANopen object dictionary and its objects by mailbox communication to realize network initialization;
- Drive PDO message by CANopen emergency object and optional event to realize network management;
- Map process data by object dictionary, cyclic transmit command data and status data.

CoE object dictionary

CoE protocol fully comply with CANopen protocol, the definition of object dictionary is same.

Index number	Definition
0000h∼0FFFh	Data type description
1000h∼1FFFh	Communication object, including: Device type, identifier, PDO mapping, compatibility with CANopen; CANopen special data object EtherCAT extended data object
2000h∼5FFFh	Manufacturer defined object
6000h∼9FFFh	Profile defined data object
A000h~FFFFh	Reserved

CoE communication data object:

Index number	Definition
	Device type, 32-bit integer
1000h	Bit $0\sim15$: used device profile
	Bit 16~31: Additional information based on profile
	Error register, 8-bit
	Bit 0: general error Bit 1: current error
1001h	Bit 2: voltage error Bit 3: temperature error
	Bit 4: communication error Bit 5: device profile defined erroe
	Bit 6: reserved Bit 7: manufacturer defined error
1008h	Device name

EtherCAT network connection diagram as below. There are 2 ports of IN and OUT, when using master to assign the station number automatically by default, slave number will assign by sequencing order.




Fig 6.1.1 EtherCAT network connection sketch map

Station alias: It can be modified by changing the value of object 2008-3Ch if slave cannot match the master that does not assign station number automatically, or user wants to assign the station number of servo slave as required. After modifying successfully, read the value of configure station alia of ESC register (0012h), and set to configure station address (0010h).

	Name		Station alias		Set mode		Mode	ALL
2008h-3Ch	Unit	N/A	Setting range	0~ 65535	When enabled	Immediate	Mfr's value	0
	Parameter	So-59	accessibility	RW	Mapping	N	Data type	UINT16

In general, follow below flow chart to use EtherCAT communication function:




Fig 6.1.2 EtherCAT flow chart

6.1.1 System parameter setting

SD20-E series is a bus-type servo drive specially based on the development of EtherCAT bus. Po001=d 1 21 by default, which is bus control mode. User can use for bus control directly.

Object dictionary index	Sub- index	Name	Setting Range
2000h	02h	Control mode and forward/reverse direction setting	X Control Mode Setting
2005h	06h	Communication read/write running	X Communication write-enable 0 Read/write enable 1 Read/write disable Y If XML file saves to E2ROM 0 Yes 1 No

[Note]: To ensure that servo connects to the EtherCAT field bus network correctly, the parameter settings are need for servo drive.

Set 2005h-06h as the corresponding value before saving the parameters to EEPROM, otherwise, the parameter returns to default value after restart.

	6.1.2	EtherCAT	communication	specification
--	-------	-----------------	---------------	---------------

Object		Specification
Communication protocol		Field bus standard: IEC 61158 Type 12,
		IEC 61800-7 CiA 402 Drive Profile
	SDO	SDO request, SDO reply
	PDO	Variable PDO mapping
		Profile position mode (PP)
Application layer		Profile velocity mode (PV)
	CIA402	Profile torque mode (PT)
		Homing mode (HM)
		Cyclic synchronous position mode (CSP)
		Cyclic synchronous velocity mode (CSV)
		Cyclic synchronous torque mode (CST)
Dhavaial	Transport protocol	IEEE802.3 (100BASE-TX)
Phsycial	Max distance	50M
layer	Port	RJ45 * 2 (INT、OUT)

6.1.3 Communication Structure

Multiple protocols can be transmitted using EtherCAT. The IEC 61800-7 (CiA 402) drive profile is used for the servo drive.

The figure below shows the EtherCAT communication structure at CANopen application layer.




Fig 6.1.3 EtherCAT communication structure at CANopen application layer

In the structure diagram, the object dictionary in the application layer contains communication parameters, application data and PDO mapping data. The process data object (PDO) consists of the real-time data during the running process of servo drive, and cyclically reads and writes. Mailbox communications (SDO) uses non-cyclical message communications where all objects in the object dictionary can be read and written.

6.1.4 State Machine

State transition block diagram as below:




Fig 6.1.4 EtherCAT state machine

EtherCAT supports 4 states, and coordinates the state relationship between the master and slave.

Init: Initialization, short for I; Pre-Operational: short for P; Safe-Operational: short for S; Operational: short for O.


The sequence of "Init-Pre-Operational-safe-Operational-Operational" must be followed step by step when transiting from Init state to Operational state. In transition from Operational state back to Init state, certain steps can be skipped. The table below shows the state transition

and initialization process.

State &Transition	Operation	
Init (I) Initialization	No communication in application, the master only read/write ESC register	
IP: Init state transit to pre-op state	The master configures slave address register; Configure mailbox channel parameter if support mailbox communication. Configure DC related register, if support distributed clock. The master writes state control register to request "Pre-Op".	
Pre-Op: Pre-Operational	Mailbox communications in application layer (SDO)	
PS: Pre-Operational transit to safe-OP state	The master uses data mapping of the mailbox initialization process; The master configures the SM channel in process data communication. The master configures SMMU; The master writes state control register to request "Safe-Op".	
Safe-OP:	Application layer supports mailbox communication; Process data communication is available, but allows only input and inhabits output (SDO, TPDO)	
SO	The master sends valid output data; The master writes state control register to request "Op" state.	
Operational	Both input and output are enabled; Mailbox communication can still be used. (SDO, TPDO, RPDO)	

6.1.5 Process Data Object (PDO)

PDO data is transmitted in the producer-consumer model. PDO is divided into RPDO (receive=PDO) and TPDO (transmit-PDO). The slave receives commands from the master through RPDO and sends its status to the master through TPDO.



(1) PDO mapping parameters

PDO mapping is used to build the mapping relationship between object dictionary and PDO. 1600h~17FFh are RPDO, 1A00h~1BFFh are TPDO, there are 6 RPDO and 5 TPDO can be selected in the servo drive, see table as below:

6 RPDO	1600h	Variable mapping	
6 KPDO	1701h~1705h	Fixed mapping	
5 TPDO	1A00h	Variable mapping	
	1B01h∼1B04h	Fixed mapping	

a) Fixed PDO mapping

SD20-E provides 5 fixed RPDO and 4 fixed TPDO. Some typical RPDO and TPDO instances are listed in the table below:

Control Mode	PP CSP
	Mapping objects (3, 8 bytes)
	6040h (Control word)
1701h	607Ah (Target position)
	60B8h (Touch probe function)
	60FE (Digital output)
1B01h	Mapping objects (8, 24 bytes)
	603Fh (Error code)
	6041h (Status word)
	6064h (Error feedback)
	6077h (Torque actual value)
	60F4h (Positional deviation))
	60B9h (Touch probe status)
	60Bah (Touch probe 1 rising edge position feedback)
	60FDh (DI status)

Control Mode	PP PV PT CSP CSV CST		
	Mapping objects (7, 19 bytes)		
	6040h (Control word)		
	607Ah (Target position)		
1702h	60FFh (Target velocity)		
170211	6071h (Target torque)		
	6060h (Mode selection)		
	60B8h (Touch probe function)		
	607Fh (Max velocity)		
	Mapping objects (9, 25 bytes)		
	603Fh (Error code)		
1B02h	6041h (Status word)		
	6064h (Position feedback)		
	6077h (Torque actual value)		
	6061h (Mode display)		
	60B9h (Touch probe function)		
	60Bah (Touch probe 1 rising edge position feedback)		
	60BCh (Touch probe 2 rising edge position feedback)		
	60FDh (DI status)		

Control Mode	PP PV CSP CSV		
	Mapping objects (7, 17 bytes)		
	6040h (Control word)		
	607Ah (Target position)		
1703h	60FFh (Target velocity)		
170311	6060h (Mode selection)		
	60B8h (Touch probe function)		
	60E0h (Positive torque limit)		
	60E1h (Reverse torque limit)		
	Mapping objects (10, 29 bytes)		
	603Fh (Error code)		
	6041h (Status word)		
	6064h (Position feedback)		
	6077h (Torque actual value)		
1B03h	60F4h (Position deviation)		
	6061h (Mode selection)		
	60B9h (Touch probe status)		
	60Bah (Touch probe 1 rising edge position feedback)		
	60BCh (Touch probe 2 rising edge position feedback))		
	60FDh (DI status)		

Control Mode	PP PV PT CSP CSV CST		
	Mapping objects (9, 23 bytes)		
	6040h (Control word)		
	607Ah (Target position)		
1704h	60FFh (Target velocity)		
	6071h (Target torque)		
170411	6060h (Mode selection)		
	60B8h (Touch probe function)		
1B02h	607Fh (Max velocity)		
	60E0h (Forward torque limit)		
	60E1h (Reverse torque limit)		
	Mapping objects (9, 25 bytes)		
	603Fh (Error code)		
	6041h (Status word)		
	6064h (Position feedback)		
	6077h (Torque actual value)		
	6061h (Mode display)		
	60B9h (Touch probe status)		
	60Bah (Touch probe 1 rising edge position feedback)		
	60BCh (Touch probe 2 rising edge position feedback)		
	60FDh (DI status)		

Control Mode	PP PV CSP CSV
	Mapping objects (8, 9 bytes)
	6040h (Control word)
	607Ah (Target position)
	60FFh (Target velocity)
1705h	6060h (Mode selection)
	60B8h (Touch probe function)
	60E0h (Forward torque limit)
	60E1h (Reverse torque limit)
	60B2h (Torque bias)
	Mapping objects (10, 29 bytes)
	603Fh (Error code)
	6041h (Status word)
	6064h (Position feedback)
	6077h (Torque actual value)
1B04h	6061h (Mode display)
	60F4h (Position bias)
	60B9h (Touch probe status)
	60Bah (Touch probe 1 rising edge position feedback)
	60BCh (Touch probe 2 rising edge position feedback)
	606Ch (Velocity actual value)

The servo drive provides 1 variable RPDO and 1 variable TPDO.

Variable PDO	Index	Max Number of Mapping Objects	Max Byte Length	Default Mapping Object
RxPDO-Map	1600h	10	40	6040h (Control word) 607Ah (Target position) 6081h (Profile velocity) 6060h (Operation mode)
TxPDO-Map	1A00h	10	40	6041h (Status word) 6064h (Position feedback) 606Ch (Velocity actual value)

(2) Synchronous Management PDO assignment

Several PDO mapping objects are included during EtherCAT cyclic data communication. CoE protocol uses data object 1C10h~1C2Fh to define the PDO mapping object list of the sync manager. Multiple PDO can be mapped into different sub-index, EtherCAT bus-type servo drive supports 1 RPDO and 1 TPDO assigned for the sync manager, as below table:

Index	Sub-index	Content
1C12h	01h	One of 1600h and 1701h~1705h used as the actual RPDO
1C13h	01h	One of 1A00h and 1B01h~1B04h used as the actual TPDO

(3) PDO configuration

PDO mapping parameters include the indicators of process data for PDOs, including index, sub-index and mapping object length. The sub-index 0 indicates the number (N) of mapping objects in the PDO; the maximum length of each PDO is 4*N bytes; and one or multiple objects can be mapped. Sub-indexes 1 to N indicate the mapping content, as below table:

Bit	31		16	15		8	7		0
Meaning	Index		Sub	-inde	X	Obj	ject ler	igth	

The index and sub-index together defines the position of an object in the object dictionary. The object length indicates the bit <u>length</u> of the object, in <u>hexadecimal</u>, as below:

Object Length	Bit Length
08h	8-bit
10h	16-bit
20h	32-bit

Use the following procedure for PDO mapping:

- 1. If use TwinCAT to configure PDO, open Process Data, and rescan to take effort after addition or deletion.
- 2. If use CodeSys to configure PDO, open Process Data, and download the program again to power on after addition or deletion.

6.1.6 Mailbox Data SDO (service data object)

EtherCAT SDO is used to transfer non-cyclic data, such as communication parameter configuration, and servo drive running parameter configuration. The CoE service type includes: 1) emergency message, 2) SDO request, 3) SDO response, 4) TxPDO, 5) RxPDO, 6) remote TxPDO transmit request, 7) remote RxPDO transmit request, 8) SDO information.

At present, the servo drive supports 1) emergency message; 2) SDO request; 3) SDO response, 4) TxPDO; 5) RxPDO.

6.1.7 Distributed Clock (DC)

Distributed clock enables all EtherCAT devices to have the same system time and implement synchronization between devices. A slave produces the synchronization signal according to the synchronized system time. The servo drive supports the DC synchronization mode.


The synchronization cycle is controlled by SYNC0.

In DC synchronization mode, if DC cycle is above 500us, user should set cycle according to the formula:

Multiple of 4/Ho020, unit is second.

For example, Ho020=20000, 4/20000=0.0002s=200us, synchronization cycle is multiple of 200us, min value is 600us.

6.1.8Status indicator



1) Communication connection status

The indicator of RJ45 reflects the connection status of RJ45:

LED indicator (green)						
Status	Status Description Explanation					
Off	Connection not detected	Physical layer not detect the communication connection				
On Connection succeed Physical layer has set up the connection						
Blink						

2) Communication running status

Both communication running status and servo enabled are displayed in the same interface; RUN indicator on servo board indicates the status of slave EtherCAT state machine.

	LED indicator (green)					
Status	Description	Explanation				
OFF	Keep off	Init. state				
Blink	RUN indicator lighten duty ratio is 50%, at interval of 336ms.	Pre-O state				

Flash	ON 0.178 OFF 0.178	Safe-O state
ON	Keep on	Operational

6.1.9Emergency Message

When alarm occurs, CoE will start an emergency message; send Error code (603Fh) and register (1001h) to the master as the emergency message form. The relation table of common failure and error code as below:

Table: Servo failure and error code relation table

Display	Failure Name	Error Code (603F)
AL-01	Over-current	2311h
AL-02	Over-voltage	3210h
AL-03	Under-voltage	3220h
AL-04	Hardware error	5210h
AL-05	Electrical angle identification error	FF05h
AL-06	Motor Overload	3230h
AL-07	Over-speed	8400h
AL-08	Overload	2221h
AL-09	Oversize position-loop tracking error	8611h
AL-10	Encoder error	7305h
AL-11	Emergency stop	FF11h
AL-12	Overheat	4210h
AL-13	Main-circuit power supply phase-loss	3130h
AL-14	Energy-loss brake error	FF14h
AL-16	Repeat setting of input terminal	FF16h
AL-17	Encoder disconnection	FF17h
AL-18	Rotary inertia identification error	FF18h
AL-19	Encoder battery warning	FF19h
AL-20	Servo motor E ² ROM not initialization	FF20h
AL-23	Torque detuning protection	3331h
AL-24	Encoder battery alarm	FF24h
AL-25	Motor overheat protection	4210h
AL-26	Motor temperature detection disconnection protection	FF26h
AL-27	Over-travel protection	FF27h
AL-28	E ² ROM error	5530h
AL-29	Earth leakage protection	2240h
AL-30	Blocking protection	7121h
AL-31	Full-closed loop mixed error alarm	FF31h
AL-35	Back-to-zero overtime	FF35h
AL-36	Parameter copy error	FF36h

AL-37	Network initialization failure	FF37h
AL-38	OP abnormal protection	FF38h
AL-39	Sync. lost protection	FF39h
AL-40	Sync. setting error protection	FF40h

The servo drive will send emergency message to network when alarm occurs, the message format as below:

Byte	0	1	2	3	4	5
Content	Error code (603Fh)	Error register(1001h)	Reserv	ed	


The master can also know the alarm by analyzing the emergency message, learn about the current failure matching with the codes in 60sFh, and display the alarm by low 4 bit value of 1001h. See details as below table:

Table: Error Register 1001h

1001h bit	Content				Definition	Remarks
	5210h	FF05h	8400h	8611h		
	7305h	FF11h	FF14h	FF16h		
	FF17h	FF18h	FF19h			When there is data on
Bit0	FF20h				Common error	the left of 603Fh,
	3331h	FF24h	FF26h	FF27h		bit0=1 of 1001h.
	5530h	2240h	7121h	FF31h		
	FF35h	FF36h				
						When there is data on
Bit1	2311h 3	3230h	2221h		Current error	the left of 603Fh,
						bit1=1 of 1001h.
						When there is data on
Bit2	3130h 3	210h 3220)h		Voltage error	the left of 603Fh,
						bit2=1 of 1001h.
	4210h				Tomporoturo	When there is data on
Bit3					Temperature	the left of 603Fh,
					error	bit3=1 of 1001h.
	FF37h	FF38h	FF39h		Communication	When there is data on
Bit4	FF40h				error	the left of 603Fh,
	FF4Un					bit4=1 of 1001h.

6.1.10 CiA402 Overview

The SD20-E runs in the specified status only when it is instructed according to the flow chart defined in CiA402.



The states are described in the following table:

	The states are described in the following table.									
Initialization	Servo drive initialization and internal self-check has been done.									
IIIItiaiizatioii	Neither parameter setting nor drive function can be implemented.									
Servo no	No fault in servo drive or the error has been eliminated.									
fault	The parameter can be set.									
Doody	The servo drive is ready.									
Ready	The parameter can be set.									
Wait to	The servo drive waits to switch on.									
switch on	The parameter can be set.									
Servo	The servo drive is running normally and one control mode is enabled; the									
running	motor is energized, and rotates when the command reference is not equal to 0.									
Quick stop	The function is enabled, and the servo drive is executing quick stop function.									
Stop at fault	Fault occurs; the servo drive is in the process of fault stop.									
Fault	The stop process is completed, and all drive function are inhibited.									

6.2 MODBUS Communication

6.2.1 Introduction of MODBUS communication

Servo drive provides RS485 communication. The following description shows the contents related to the communication protocol, hardware interface etc.

6.2.2 MODBUS Overview

Modbus is a serial and asynchronous communication protocol. Modbus protocol is a general language applied to PLC and other controllers. The protocol defines an information structure that can be identified and used by controller regardless of whatever network they are transmitted. Modbus protocol does not need the special interface; the typical physical interface is RS485. User can read reference books or ask for the details of MODBUS from manufactures.

6.2.3 MODBUS Communication Protocol

I. Overall Introduction

1. Transmission Mode

(1) ASCII transmission mode

In ASCII mode, one Byte (hexadecimal format) is expressed by two ASCII characters. For example, 31H (hexadecimal data) includes two ASCII characters'3(33H)','1(31H)'. Common characters, ASCII characters are shown in the following table:

Characters	'0'	'1'	'2'	'3'	'4'	' 5'	'6'	'7'
ASCII Code	30H	31H	32H	33H	34H	35H	36H	37H
Characters	'8'	'9'	'A'	'B'	'C'	ʻD'	'E'	'F'
ASCII Code	38H	39H	41H	42H	43H	44H	45H	46H

(2) RTU mode

In RTU mode, one Byte is expressed by hexadecimal format. For example, 31H is delivered to data packet directly.

2. Baud Rate

Setting range: 2400, 4800, 9600, 19200, 38400, 57600.

3. Frame Structure

(1) ASCII mode

Byte	Function
1	Start Bit (Low Level)
7	Data Bit
0/1	Parity Check Bit (None for this bit in case of no checking. Otherwise 1 bit)
1/2	Stop Bit (1 bit in case of checking, otherwise 2 bits)

(2) RTU mode

Byte	Function
1	Start Bit (Low Level)
8	Data Bit
0/1	Parity Check Bit (None for this bit in case of no checking. Otherwise 1 bit)
1/2	Stop Bit (1 bit in case of checking, otherwise 2 bits)

4. Error Check

(1) ASCII mode

Longitudinal Redundancy Check (LRC): It is performed on the ASCII message field contents excluding the 'colon' character that begins the message, and excluding the CRLF pair at the end of the message.

The LRC is calculated by adding together successive 8-bit bytes of the message, discarding any carries, and then two's complementing the result.

(2) RTU mode

CRC-16 (Cyclical Redundancy Check), please read reference books or ask for the details from manufactures.

II. Command Type& Format

1. Command types of common functional domain parameters as below:

Code	Name	Description						
03	Read Holding Registers	Read the binary contents of holding registers in the slave. (Less than 10 registers once time)						
06	Preset Single Register	Preset a value into holding register						
16	Preset Multiple Register	Preset values into successive registers (1~120 registers) Note: In ASCII mode, register number must be less than 40. In RTU mode, register number must be less than 100.						

2. Data packet mode:

(1) ASCII Mode

Start	Address	Function		Data	a		LRC o	heck	End		
: (0X3A)	Servo drive Address	Function Code	Data length			Data N	High-order byte of LRC	Low-order byte of LRC	Return (0X0D)	Line Feed (0X0A)	

(2) RTU Mode

Start	Address	Function	Data	CRC	End	
T1-T2-T3-T4	Servo drive Address	Function Code	IN data	Low-order byte of CRC	High-order byte of CRC	T1-T2-T3-T4

(3) Protocol Converter

It is easy to turn a RTU command into an ASCII command followed by the lists:

- 1) Use the LRC to replace the CRC.
- 2) Transform each byte in RTU command into a corresponding two byte ASCII. For example: transform 0x03 into 0x30, 0x33 (ASCII code for 0 and ASCII code for 3).
- 3) Add a 'colon' (:) character (ASCII 3A hex) at the beginning of the message.
- 4) End with a 'carriage return line feed' (CRLF) pair (ASCII 0D and 0A hex).

3. Parameter address rules

The address of P group parameters is the parameter numbers.

Ex1: Communication address of Po101:

The parameter numbers of Po101 is 101, the hex format is 0065. The address of high bit is 00 and the address of low bit is 65.

Ex2: Communication address of Po407:

The parameter numbers of Po407 is 407, the hex format is 0197. The address of high bit is 01 and the address of low bit is 97.

The address of S group parameters equals to parameter numbers +800

Ex3: Communication address of So-02:

The parameter numbers of So-02 is 02, so the address of So-02 is 802 after adding 800; the hex format is 0322. The address of high bit is 03 and the address of low bit is 22.

The address of PL group parameters equals to parameter numbers +1000

Ex4: Communication address of PL101

The parameter numbers of PL101 is 101, so the address of PL101 is 1101 after adding 1000; the hex format is 044D. The high bit address is 04, the low bit address is 4D.

Part of L group data is 32-bit data, so the address is special, please refer to following table:

Address	Meaning	Address	Meaning Meaning
900	Servo drive output current low 16 bits	918	Reserved
901	Servo drive output current high16 bits	919	Reserved
902	Servo drive bus voltage low 16 bits	920	Reserved
903	Servo drive bus voltage high 16 bits	921	Reserved
904	Servo motor rotation speed low 16 bits	922	Reserved
905	Servo motor rotation speed high16 bits	923	Bit mode, low 8 bits stands for DI8~DI1 status.(Note)
906	Servo motor feedback pulse numbers low 16 bits	924	Reserved
907	Servo motor feedback pulse numbers high 16 bits.	925	Bit mode, low 8 bits stands for DO8~DO1 status.(Note)
908	Servo motor feedback rotation low 16 bits	926	Bit mode, alarm code (Note)
909	Servo motor feedback rotation high 16 bits	927	Reserved
910	Given pulse numbers low 16 bits	928	Reserved
911	Given pulse numbers high 16 bits	936	Servo motor absolution position pulse numbers high16 bits
912	Pulse counting deviation low16 bits	937	Servo motor absolution position pulse numbers low16 bits
913	Pulse counting deviation high 16 bits	938	Servo motor absolution position rotation high16 bits
914	Given speed low 16 bits	939	Servo motor absolution position rotation low 16 bits
915	Given speed high16 bits	952	Actual absolute position (bit0-bit15)

916	Given torque low 16 bits	953	Actual absolute position (bit16-bit31)
917	Given torque high 16 bits	954	Actual absolute position (bit32-bit47)
955	Actual absolute position (bit48-bit63)	957	Actual absolute position (divided by electric gear ratio) (bit6-bit31)
956	Actual absolute position (divided by electric gear ratio) (bit0-bit5)	958	Actual absolute position (divided by electric gear ratio) (bit32-bit47)
959	Actual absolute position (divided by electric gear ratio) (bit48-bit63)		

Note: please refer to 4 Reading and writing rules of parameters about bit mode.

When the master reads 900 group functions via EtherCAT, 900-group dynamically configures three as the parameter monitoring to use, the main index is 2009h, see details in below table:

Table: The definition of sub-index under the main index 2009h

Sub-index	Function
01h	First display address
02h	Second display address
03h	Third display address
04h	Corresponding value of first display address
05h	Corresponding value of second display address
06h	Corresponding value of third display address

For example: Set 01h as 902, then 04h is displayed as bus voltage value.

4. Parameter read-write rules

Except two-parameter and four-parameter, the other parameters can be read directly, the data is 16-bit integer (it is complement form).

Concerning for two-parameter and four-parameter, the written and read value is hexadecimal format (The marking bits of d and b do not occupy communication bit). Under line "_" means that the bit is not displayed.

- Ex5: Two-parameter mode is d_1_10, so the hex format is 0x10A, so the read result is 266.
- Ex6: Four-parameter mode is b1234, so 1234 is written, and b1234 is displayed after the order succeeds. The special instructions for 32-bit data are as the following.
- Ex7: Read servo motor feedback pulse numbers. Separately read high 16-bit and low 16-bit parameters value, shift high 16-bit data 16 bits to the left, and execute OR with low 16-bit, and confirm positive and negative according to the highest bit 0 or 1. If the highest bit is 0, the data is actual servo motor feedback pulse numbers and the data is positive number. If the highest bit is 1, to negate every bit and to add 1 to them, which equals to servo motor feedback pulse numbers and it is a negative number. If high 16 bit

is 65534 and low bit is 31073, the binary form of which is 111111111111111 and 111100101100001, after shifting high 16-bit data to the left, the data becomes 111111111111111100111100101100001. The highest data is 1, so the data is negative. Negate the data, the data becomes 11000011010011110, and add 1 to the data, the data becomes 11000011010011111, the decimal form is 99999. Because it is a negative number, so it is -99999.

Bit mode meaning in monitor group:

The parameter meaning in address 923:

MSB	←	←													LSB
16	15 14 13 12 11 10 9 8 7 6 5 4 3 2											1			
_	_		_		_	_		DI8	DI7	DI6	DI5	DI4	DI3	DI2	DI1

The parameter meaning in address 925:

MSB		← I												LSB	
16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
_	_			_		_	_	_	_		ALM	DO4	DO3	DO2	DO1

The parameter meaning in address 940:

MSB	←						
16	15	14	13	12	11	10	9
AL-16	AL-15	AL-14	AL-13	AL-12	AL-11	AL-10	AL-09

The parameter meaning in address 940 (continued):

←							LSB
8	7	6	5	4	3	2	1
AL-08	AL-07	AL-06	AL-05	AL-04	AL-03	AL-02	AL-01

Note: "—" means "reserved", which is used to add new function.

Communication example:

(1) In RTU mode, change acceleration time (Po109) to 5ms in No. 01 servo drive.

Host query:

Address	Parameter	Register Address Hi	Register Address Lo	Write status Hi	Write status Lo	CRC Lo	CRC Hi
01	06	00	6D	00	05	D8	14

Servo1 write register Po109 5(Unit: ms) CRC check

Slave response:

Servo 1 write register

Address	Parameter	Register Address Hi	Register Address Lo	Write status Hi	Write status Lo	CRC Lo	CRC Hi
01	06	00	6D	00	05	D8	14

5(Unit: ms)

CRC check

Po109

⁽²⁾ In RTU mode, read acceleration time (Po109) of No. 01 servo drive.

Host query:

Address	Parameter	First register Hi	First register Lo		Numbers of register Lo	CRC Lo	CRC Hi
01	03	00	6D	00	01	15	D7

Servo1 read register Po109 one register CRC check

Slave response:

Address	Parameter	Data numbers	Data Hi	Data Lo	CRC Lo	CRC Hi
01	03	02	00	C8	B9	D2

Servo 1 write register 2 bits 200(Unit: ms) CRC check

6.2.4 Parameters related to Communication

(1) Below parameters need to set when communicating with servo drive by MODBUS:

	Communication address	PP PV PT	CSP CSV	CST HM	
	Setting range	Setting unit	Mfr's value	When enabled	
2005h-01h	1~254		1	Immediate	
	Corresponding parameter	Mapping	Data type	Accessibility	
	Po500	N	UINT16	RW	
	Communication mode	PP PV PT	CSP CSV	CST HM	
	Setting range	Setting unit	Mfr's value	When enabled	
2005h-02h	0~1		0	Immediate	
	Corresponding parameter	Mapping	Data type	Accessibility	
	Po501	N	UINT16	RW	
	Stop bit settings	PP PV PT	CSP CSV	CST HM	
	Setting range	Setting unit	Mfr's value	When enabled	
2005h-03h	0~1	_	0	Immediate	
	Corresponding parameter	Mapping	Data type	Accessibility	
	Po502	N	UINT16	RW	
	Odd/even calibration F	PP PV PT	CSP CSV	CST HM	
	Setting range	Setting unit	Mfr's value	When enabled	
2005h-04h	0~2	_	0	Immediate	
	Corresponding parameter	Mapping	Data type	Accessibility	
	Po503	N	UINT16	RW	
	Baud rate P	P PV PT	CSP CSV	CST HM	
2005h-05h	Setting range	Setting unit	Mfr's value	When enabled	
2003H-03N	0~5	bit/s	2	Immediate	
	Corresponding parameter	Mapping	Data type	Accessibility	

	Po504	N	UINT16	RW
	Communication read/write	allowed PP P	PV PT CSP	CSV CST HM
	Setting range	Setting unit	Mfr's value	When enabled
2005h-06h	_		d 1 1	Immediate
	Corresponding parameter	Mapping	Data type	Accessibility
	Po505	N	UINT16	RW

Note: When remote control by PLC or other intelligent device, parameters in above table must be set correctly to make sure the accordance for parameters of both ends.

The command from PC/PLC will be written into data memory of servo drive immediately; it is not recommended to write the data into the memory continuously.

(2) Structure of field bus




Fig 6.4.1 Field bus connection

RS485 Half-duplex communication mode is adopted for servo drive. Daisy chain structure is adopted by 485 Bus-line. Do not use 'spur' lines or a star configuration. Reflect signals which are produced by spur lines or star configuration will interfere in 485 communications. Shield twisted pair cable must be chosen for wiring. As far as away from strong current, do not parallel with power cable or tie up together.


Please note that for the same time in half-duplex connection, and only one inverter can have communication with PC/PLC. Should two or more than two inverters upload data at the same time, then bus competition will occur, which will not only lead to communication failure, but higher current to make certain elements damage.

(3) Grounding and terminals

Terminal resistance of 1200 will be adopted for terminal of RS485 network, to diminish the

reflection of signals. Terminal resistance shall not be used for intermediate network.

No direct grounding shall be allowed for any point of RS485 network. All the equipment in the network shall be well grounded via their own grounding terminal. Please note that grounding wires will not form closed loop in any case.



Please think over the drive capacity of PC/PLC and the distance between PC/PLC and inverter when wiring. Add a repeaters if drive capacity is not enough.

Note: All installations and wirings must be conducted only when servo drive is power off.

Display

VAR

6.3 Introduction of common bus control mode

Indev

Supported servo modes

SD20-E series supports 7 servo modes, as defined in the object dictionary 6502h.

muex				moue		Structure	
6502h	Access	RO	Mapping	N		Data type	UDINT32
	Mode	ALL	Data range			Default	941
It indica	tes the su	pported th	e running modes	of servo driv	ve:		
bit			Description		0: Not suppo	orted 1: S	Supported
0	Prof	Profile position mode (PP)				1	
1	Vari	able veloc	ity mode (VL)			0	
2	Prof	le velocit	y (PV)		1		
3	Prof	le torque	(PT)		1		
4	Rese	Reserved			Reserved		
5	Hon	ing mode	(HM)		1		
6	Inter	polated p	osition mode (IP)		0		
7	Cycl	ic synchro	onous position mo	de (CSP)		1	
8	Cycl	Cyclic synchronous velocity mode (CSV)			V) 1		
9	Cycl	Cyclic synchronous torque mode (CST)				1	
10~	31 Rese	rved	·		•	Reserved	
(Note)	if devic	e supports	6502hm, the sup	ported mode	es can be kno	wn in this obje	ect.

The operation mode of the servo drive is set in 6060h. The operation mode of the servo drive can be checked in 6061h.

Mode selection 6060h:

Index	Name	Operation mode		Setting mode	 Data structure	VAR
6060h	Access	RW	Mapping	RPDO	Data type	UINT16
	Mode	ALL	Data range	0~10	Default	0

It used to select the operation mode of servo drive:

Value	Servo mode				
0	Reserved	Reserved			
1	Profile position mode (PP)	Refer to PP mode			
2	Reserved	Reserved			
3	Profile velocity mode (PV)	Refer to PV mode			
4	Profile torque mode (PT)	Refer to PT mode			
5	Reserved	Reserved			
6	Homing mode (HM)	Refer to HM mode			
7	Interpolated position mode (IP)	Not supported			
8	Cyclic synchronous position mode (CSP)	Refer to CSP mode			
9	Cyclic synchronous velocity mode (CSV)	Refer to CSV mode			
10	Cyclic synchronous torque mode (CST)	Refer to CST mode			

Mode display 6061h:

Index	Name	Operation mode of servo		Setting mode	_	Data structure	VAR
6061h	Access	RO	Mapping	TPDO		Data type	UINT16
	Mode	ALL	Data range			Default	_

It displays the current operation mode of the servo drive.

bit	Operation Mode	Operation Mode				
0	Reserved	Reserved				
1	Profile position mode (PP)	Refer to PP mode				
2	Reserved Reserved					
3	Profile velocity mode (PV)	Refer to PV mode				
4	Profile torque mode (PT)	Refer to PT mode				
5	Reserved	Reserved				
6	Homing mode (HM)	Refer to HM mode				
7	Interpolated position mode (IP) Not supported					
8	Cyclic synchronous position mode (CSP) Refer to CSP mode					

9	Cyclic synchronous velocity mode (CSV)	Refer to CSV mode
10	Cyclic synchronous torque mode (CST)	Refer to CST mode


6.3.1 Mode Switchover

Observe the following precautions during mode switchover.

- 1. When the servo drive in any state switches over from the PP or CSP mode to another mode, the position references not executed will be abandoned.
- 2. When the servo drive in any state switches over from the PV, PT, CSV or CST mode to another mode, it stops at ramp before entering into that mode.
- 3. The servo drive cannot switch over to another mode when it is in the HM mode in running state. After homing is completed or interrupted (fault or power-off), the servo drive can then enter into another mode.
- 4. When the servo drive in running state switches over from a mode to the cyclic synchronous mode, send the references at an interval of at least 1 ms; otherwise, reference loss or error may occur.

VII. Control mode

Servo system includes servo drive, servo motor and encoder.




Based on the command modes and running characteristics, servo drives supports three running mode, position control, speed control and torque control.

In the position control mode, motor target position is confirmed by position command total numbers. The position control mode strictly controls the position and speed, and is often used in the positioning device. It is the most commonly used mode of the servo drive, applicable to the mechanical arm, mounter, engraving and milling machine, and computer numerical control (CNC) machine tool.

In the speed control mode, the speed is controlled by DI setting, or communication setting. It is often used in scenarios with constant speed. The host controller uses the position mode, and the servo drive uses the speed control mode.

In the torque control mode, the torque is changed by changing the address value by means of communication. This mode is mainly applied to the winding and unwinding devices with strict tension requirements.



Note:

Please make servo motor run without load, then connect load to motor.

After a servo motor is changed, if user does not know encoder electric angle and whether motor phase sequence is correct, user can make the servo motor operate normally by using electric angle indication function. Before electric angle indication, please make sure the following steps:

- (1) Motor actual power.
- (2) Ensure that the servomotor encoder cable is connected properly.

- (3) Ensure that the servomotor is connected to zero.
- (4) Ensure that the servo is in the OFF status.

When 2008h-1 Ah=3, please input motor actual power to servo drive, then identify parameters.

	Motor rated power	PP PV P1	, , , , , , , , , , , , , , , , , , , 	CST PP HM
	Setting range	Setting unit	Mfr's value	When enabled
2006h-0Ch	1~30000	0.01KW	_	Effective Immediately
	Function code	Mapping	Data type	Assessibilty
	Ho011	N	UINT16	RW

	Motor parameter iden	tification setting	PP PV PT CS	SP CSV CST PP HM		
	Setting range	Setting unit	Mfr's value	When enabled		
	0~4	N/A	0	Effective Immediately		
	Function code	Mapping	Data type	Assessibilty		
	So-25	N	UINT16	RW		
2008h-1Ah	0: no motor parameter indentification 1: indentify motor resistor, inductance, pole pairs numbers and encoder installation angle					
	2: lock motor shaft3:indentify motor resistor, inductance and estimate motor EMF4: indentify motor resistor, inductance, pole pairs numbers, motor EMF and					
	encoder installation an	gle				

When 2008h-1Ah is set to 1, enter So-14 jogging control mode. System starts automatic testing, panel displays flashing "TEST". After indentification is finished, panel will return to So-14 interface, and electrical angle is saved in 2006h-13h. If line sequence error occurs, panel displays AL-05, please stop the motor and adjust the line sequence before next operation.

: When line sequence error occurs, reverse two phases, and then repeat the electrical angle identification.

7.1 Before running

7.1.1 Wiring checking

Make sure that all wiring has been completed.

	Wiring				
1	Connect L1C and L2C of servo drive to main circuit power.	L1C and L2C are forridden connected for 380V servo drive.			
2	Connect U/V/W of servo drive to U/V/W of servo motor well.				
3	Check all control signal cables are connected correctly, and check				
	the brake, overtravel and the other protrective functions for				
	correct operation.				
4	Servo drive and servo motor must be grounded reliably.				
5	When external resistor is used, please remove short wires between				
	B2 and B3.				
	Environment and machinery				
1	There is no iron dust or foreign matter in the servo drive.				
2	There is no inflammable substance nearby servo drive and external				
	braking resistor.				
3	Servo motor is reliably connected to mechanical equipment.				

7.1.2 Power on

1) Power on control circuit and main circuit.

Power on control circuit (L1C, L2C) and main circuit:

For 1-phase 220V servo drive, please connect power to L1 and L3.

For 3-phase 220V servo drive, please connect power to L1/L2/L3. For 3-phase 380V servo drive, please connect power to R/S/T.

- Power on control circuit and main circuit, if bus voltage indicator shows no abnormal, and "0" is displayed in the keypad, it indicates servo drive is enabled.
- If "AL-xx" is displayed in the keypad, please refer to Chapter 10.

2) Set S-ON to OFF status.

Please refer to chapter 6.1.10 CiA 402 protocal introduction.

7.1.3 Parameters setting

1) Motor parameters

The parameters of the motor include: rated voltage, rated current, encoder lines, rated rotary speed, numbers of pole pairs, phase resistance, inductance, Movement of inertia, back EMF, line voltage, etc. Please confirm that the parameter's setting value is identical to the motor's parameter to ensure motor normal operation, in case of burning servo system out. When 2008h-31h= 1, motor's parameters can be changed .The parameter functions are as follow:

		parameter setting (index 2			CSV CST PP HM	
	Sub- inde x	Parameters (unit)	Setting range	Function	When enabled	
	01h	Rated voltage (V)	1~30000	rated voltage	Display	
	02h	Rated current (0.1A)	1~30000	rated current	Immediate	
	03h	Max rotary speed (rpm)	0~32000	Max rotary speed	Immediate	
	04h	Rated rotary speed (rpm)	0~32000	rated rotary speed	Immediate	
ers	05h	Pole-pairs (pair)	1~30	pole-pairs	Immediate	
Motor parameters	06h	Phase resistance $(10^{-3}\Omega)$	0~65535	phase resistance	Immediate	
para	07h	Q-axis inductance (10 ⁻⁶ H)	0~65535	D-axis inductance	Immediate	
tor]	08h	Q-axis inductance (10 ⁻⁶ H)	0~65535	Q-axis inductance	Immediate	
Mo	09h	Back EMF line voltage effective value (0.1V/1000 rpm)	0~30000	back EMF line voltage effective value	Immediate	
	0Dh	Motor movement of inertia (10 ⁻⁶ Kg•m2)	$0\sim$ (2 ³¹ -1)	motor rotary inertia	Immediate	
	11h	Encoder line number 0^{\sim} Motor encount number number		Motor encoder line number	Immediate	
	13h	Encoder installation angle(pulse numbers)	$-(2^{31}-1)\sim$ + $(2^{31}-1)$	Encoder installation angle(pulse numbers)	Immediate	
	48h	Overload sensitivity setting	1~30000	over-load sensitivity	Immediate	

Motor parameters can be set according to the table, in addition, pay attention to the following points in use:

(1)When 2008h-31h=1,the H group parameters can be set. If photoelectric encoder is adopted, encoder line*4 is set to 2006h-11h, if communication encoder is adopted, encoder line is set to 2006h-11h.

After electrical degree identification is finished, the installation angle of the encoder is saved in 2006h-13h. Please refer to chapter 6 for operating method of electrical degree identification.

- (2) Different motor parameter corresponds to different servo motor, make sure the parameters are in accordance with the motor's before using.
- (3) Change the value of 2006h-48h according to heat radiation of the motor. It can adjust the motor overload protection time early or delayed. The higher the parameter value is, the longer overload protection time is.
- (4) Do not modify motor parameters set by the manufacturer .If the system is damaged because user sets the wrong motor parameters or use non-standard motor, user should be response for the consequence.

2) Switching the Servo motor Rotation Direction


The default setting for "forward rotation" is counterclockwise as viewed from the servo motor shaft. The mfr's value of 2000h-02h.Y is 1. When 2000h-02h.Y is set to 0, the forward rotation is clockwise as viewed from the servo motor shaft.

2000h-02h.Y =1, forward	2000h-02h.Y =0, forward
rotation is counterclockwise.	rotation is clockwise.

3) Holding brake setting

The holding brake is used when the servo motr controls a vertical shaft. The servo motor with brake prevents the movable part from shifting due to gravity when the power supply fails. The holding brake function is only suitable for servo motor with brake.

a) Wiring of holding brake



Note:

- 1. The internal electromagnetic is only valid when servo is in the stop status.
- 2. The coil of electromagnetic has polarity, please distinguish them when wiring.
- 3. The power supply of electromagnetic is supplied by users. The voltage is 24VDC ($\pm 10\%$) and the current should be selected according to nameplate of brake. And electromagnetic and control signal are forbidden using one power supply.

b) Braking parameters setting

Signal name	Code	Terminals	Remarks
Electromagnetic braking control	BRAKE	BRAKE+ BRAKE -	Electromagnetic braking control output.

Braking working sequence is different with servo drive status, which includes servo normal status and servo off status.

1) When servo works in normal status.

Servo normal status includes servo motor in static status and servo motor in running status. Static status: motor actual rotary speed is lower than 20rpm.

Running status: motor actual rotary speed is higher than 20rpm.

a) Braking when servo motor stops

	Delay time for serv	vo OFF PP PV	PT CSP	CSV CST HM
	Setting range	Setting unit	Mfr's value	When enabled
2008h-03h	0~500	00 10ms 0		Effective Immediately
	Function code	Mapping	Data type	Accessibility
	So-02	N	UINT16	RW

	Speed threshold of electromagnetic braking PP PV PT CSP CSV CST HM				
	Setting range Setting unit		Mfr's value	When enabled	
2008h-11h	0~30000 0.1rpm 1000		1000	Effective Immediately	
Function code		Mapping	Data type	Accessibility	
	So-16	N	UINT16	RW	

Note: the value of 2008h-11h should not be set too high, please use the Mfr's value.

When servo motor stops or the motor speed is lower than So-16, if enable signal is OFF and electromagnetic braking signal is invalid, after the time set by 2008h-03h, servo will be in the disable status.




Fig 7-1-3 Electromagnetic brake sequence diagram

Note: if some alarms occur, servo will turn to disable status, 2008h-03h will be invalid.
b) Braking when servo motor is rotating

	Delay time for electro	CSP CSV CST HM		
	Setting range Setting unit Mfr's value		When enabled	
	10~100	10ms	50	Effective
2008h-04h		TOHIS	30	Immediately
	Function code	Mapping	Data type	Assessibilty
	So-03	N	UINT16	RW

When servo motor is rotating and speed is higher than 2008h-11h, after alarm occurs, servo drive will become disable status immediately, servo motor will free stop. When any of below items occurs, braking signal will be closed:

- 1. Speed decreases to setting value of 2008h-11h.
- 2. Servo drive becomes disabled status, and after delay time of 2008h-04h.




Fig 7-1-4 Electromagnetic brake sequence diagram

Note: servo enabled is off, T1 is the smaller value between 2008h-04h and the time taken by speed decreasing to 2008h-11h.

7.1.4 Setting the Overtravel Limit Function

The overtravel limit function forces movable machine parts to stop if they exceed the allowable range of motion. The function adopts a limit switch or a photoelectric switch.

1. Hardware overtravel protection function

As soon as the servo drive detects the on/off signal from the limit switch, it will force the speed in the present direction to turn to 0, but it does not work for the speed of opposite direction.




Fig 7-1-5 Overtravel Limit Function

(1) Input signal

Signal name	Code	Remarks
Forward run prohibited	F-INH	Forbidden servo drive forward run.
Reverse run prohibited	R-INH	Forbidden servo drive reverse run.

(2) Setting related parameter

	Forward run pr	ohibited PP	PV PT CSP CSV	CST HM
	Setting range	Setting unit	Mfr's value	When enabled
20001 125	0: Prohibited invalid	N/A	1	Effective
2008h-12h	1: Prohibited valid	N/A	1	Immediately
	Function code	Mapping	Data type	Accessibility
	So-17	N	UINT16	RW

	Reverse run pro	hibited PP	PV PT CSP CSV	CST HM
	Setting range	Setting unit	Mfr's value	When enabled
20001 121	0: Prohibited invalid	N/A	1	Effective
2008h-13h	1: Prohibited valid		1	Immediately
	Function code	Mapping	Data type	Accessibility
	So-18	N	UINT16	RW

(1) Enabled the overtravel signal

When 2008h-12h =1, 2008h-13h =0 and external control terminals with the function of F-INH and R-INH are allocated, the overtravel function is enabled. For security, the default setting of So-17 and So-18 are prohibited valid and the signal input type is common-close contact. So even malfunction occurs, the overtravel protection is still valid.

(2) Disable the overtravel signal

When 2008h-12h =0 and 2008h-13h =0, the overtravel function is disable. If the input terminals with the function of F-INH and R-INH are not allocated, the overtravel function is disabled.

(3) Setting the stop torque for overtravel

	Forward/reverse run prohibited and emergency stop torque PP PV PT SP CSV CST HM				
2002h-08h	Setting range	Setting unit	Mfr's value	When enabled	
	1~300	1% of rated	100	Effective	
	1 500	torque	100	Immediately	
	Function code	Mapping	Data type	Accessibility	
	Po207	N	INT16	RW	

When forward/reverse run prohibited signal or emergency stop signal is valid, the max value of instantaneous reverse stop torque of servo motor is limited by 2002h-08h. The entry-into-effect time is 100ms.

In torque mode, when motor is running, after prohibited signal is given, the torque prohibited value is limited by 2002h-11h.

	Forward/reverse run prohibited torque setting PP PV PT CSP CSV CST HM					
2002h-	Setting range	Setting unit	Mfr's value	When enabled		
	0~1	N/A	1	Immediate		
11h	Function code	Mapping	Data type	Accessibility		
	Po216	N	INT16	RW		

When 2002h-11h =0, the actual reverse limit torque is the setting torque in Po207; When 2002h-11h =1, torque limit value is 0.

2. Software overtravel protection function

Once encoder multiturn position is detected to exceed setting range, alarm will occur. Take "Home" as initial position, servo motor can move between movement range set by forward/reverse. If servo motor exceeds movement range, servo drive will trip into AL-27. The related parameters are as below:

	Forward running range pulse when overtravel protection PP PV PT CSP CSV CST HM					
	Setting range	Setting unit	Mfr's value	When enabled		
2001-29h	$0 \sim 2147483647$	N/A	0	Immediate		
	Function code	Mapping	Data type	Accessibility		
	Po140	N	DINT32	RW		
	Forward running range	multi-loop numbers	when overtrave	l protection		
	PP PV PT CS		НМ			
2001 ADL	Setting range	Setting unit	Mfr's value	When enabled		
2001-2Bh	0~32000	N/A	1000	Immediate		
	Function code	Mapping	Data type	Accessibility		
	Po142	N	INT16	RW		
	Reverse running range pp PV PT CSP CSV	Reverse running range pulse when overtravel protection PP PV PT CSP CSV CST HM				
	Setting range	Setting unit	Mfr's value	When enabled		
2001-2Ch	0~2147483647	N/A	0	Effective		
				Immediately		
	Function code	Mapping	Data type	Assessibilty		
	Po143	N	DINT32	RW		
	Reverse running range multi-loop numbers when overtravel protection PP PV PT CSP CSV CST HM					
	Setting range	Setting unit	Mfr's value	When enabled		
2001-2Eh	0 22000	NT/A	1000	Effective		
	0~32000	N/A	1000	Immediately		
	Function code	Mapping	Data type	Assessibilty		
	Po145	N	INT16	RW		
	Overtravel limit function PP PV PT CSP CSV CST HM					
	Setting range	Setting unit	Mfr's value	When enabled		
2008h-28h	0: Invalid 1: Valid	NT/A	1	Effective		
	2: stop but no alarm	N/A	1	Immediately		
	Function code	Mapping	Data type	Assessibilty		
	So-39	N	UINT16	RW		

(1) Instructions

Set mechanical origin as initial position, and set forward/reverse motion range, which can

realize overtravel protection by software.

(2) Masking overtravel protection function

To set 2008h-28h = 0.

7.1.5 Jog operation procedure

1) Panel jog function

Step	Content	Remarks
	Check wiring of main circuit and power supply of	
1	control circuit (L1C, L2C) is powered on, and power	
	supply of main circuit (R/L1, S/L2, T/L3) is powered on.	
2	Press MODE key, to enter auxiliary function section	Please refer to 5.2.1
	So-□□	
3	Press UP or DOWN key to find So-13 (Jog speed)	The Mfr's value is 100rpm
4	Press SET key for 0.5s to enter setting interface, to set	Note: the unit of speed is
4	safety value of jog speed by press UP or DOWN key.	0.1rpm.
5	Press SET key for 0.5s to confirm the setting speed, and	
3	return to So-13.	
6	Press UP key to display So-14 (jog run)	
7	Dragg CET leave for 0.5s to ing myn	JOG is displayed, servo is
/	Press SET key for 0.5s to jog run.	enabled.
8	Press UP key to jog forward run; press DOWN key to jog	To confirm rotating
0	reverse run.	direction.
9	Press MODE key, and servo is OFF, to quit JOG mode.	

	JOG speed	PP PV PT	CSP CSV	CST HM
2008h-0Eh	Setting range	Setting unit	Mfr's value	When enabled
	0~30000	0.1rpm	1000	Immediate
	Function code	Mapping	Data type	Accessibility
	So-13	N	UINT16	RW

Note: 1. internal jog mode is a special speed mode, jog speed is related to decel. time Po109, Po110.

- 2: Internal jog mode is not limited by forward/reverse prohibited, make sure it is safe.
- 3: Please refer to 5.3.3 about procedure of internal jog operation.
- 4: The entry-into-effect time of Po109 and Po110 is 100ms

2) Terminal jog function

Signal name	Name	Default terminal	Function
Terminal FWD jog	JOGU	None	Forward jog is realized by controlling terminals.
Terminal REV jog	JOGD	None	Reverse jog is realized by controlling terminals.

Note: The priority of jog mode is higher than the other modes.

When servo is OFF and terminal jog signal is valid, servo will run at jog mode.

If terminal jog signal is valid at any modes, servo will enter jog mode

7.1.6 Sequence control

(1) Time sequence at power-on




Fig 7.1.6 Time sequence at power-on

Note:

- 1. Above figure is time sequence at power-on with no fault.
- 2. Servo ready means that after CPU reset and main power supply is connected, outputs without any failures.
- 3. Before servo is ready, power supply should be connected and all control signals should be ignored.
- 4. When 2008h-08h is 0 or 1 and servo on is ready, please wait at least 100ms before sending control command. Or else, command may be ignored.
 - When 2008h-08h is set to 2 and servo on is ready, please wait at least 10ms before sending control command. Or else, command may be ignored.

(2) Sequence control after alarm activated




Fig 7-1-7 Sequence control of servo alarm activated

Note:

- 1. Above figure shows the control sequence of servo drive when alarm occurs in the running process of servo motor.
- 2. T1 is 0.1ms~20ms according different alarm type.
- 3. T2 is the smaller value between 2008h-04h and the time taken by speed reaching to 2008h-11h.
- (3) Sequence control after resetting servo drive




Fig 7-1-8 sequence control after resetting servo drive

7.1.7 Setting the braking

The braking types of servo drive include three kinds:

1.dynamic braking 2.energy-consumption braking 3. Electromagnetic braking.

Caution

- ★ Energy-consumption braking is valid after main circuit is powered on.
- ★ Electromagnetic braking starts after servo OFF. If it is not, overload malfunction will occur.
- ★ Dynamic braking starts after servo OFF or main circuit is powered off. But if motor rotation speed is too high, dynamic braking resistor will be overheat.

(1) Dynamic braking

Dynamic braking is a common way to stop servo motor. It is a kind of special energy-consumption braking mode. The braking circuit includes dynamic braking resistor and diode. The method of dynamic braking is to short-connect drive line coil of servo motor, to shorten motor mechanical feed distance by modes of energy consumption braking finally.




Fig 7-1-9 Dynamic braking

1) Setting function

	Servo OFF stop mode	o OFF stop mode PP PV PT CSP CSV CST HM		
	Setting range	Setting unit	Mfr's value	When enabled
2008h-08h	0: Coast stop 1: Dynamic braking 2: Fast enable 3: Deceleration to stop 4: Deceleration to stop and dynamic brake 5: Deceleration to stop and fast enable	N/A	0	Effective Immediately
	Function code	Mapping	Data type	Accessibility
	So-07	N	UINT16	RW

Fast enable: after servo is power on, relay is switched on. After enable signal is valid, servo will be ON after 10ms.

2) Related parameter

	Dynamic braking dela	y time PP PV	PT CSP CSV	CST HM
	Setting range	Setting unit	Mfr's value	When enabled
2008h-09h	100~30000 0.1ms		5000	Immediate
	Function code	Mapping	Data type	Accessibility
	So-08	N	UINT16	RW

(2) Energy consumption braking

Motor is in the state of energy regeneration during deceleration or stop process, which converts mechanical energy into electrical energy. The energy feedback works on bus line by inverting circuit, which leads to the voltage of bus line higher. When the voltage is too high, the components in the servodrive will be damaged. The method of energy consumption braking is to consume feedback energy into heat energy by braking resistor.




Fig 7-1-10 Wiring of energy consumption braking




Fig 7-1-11 Wiring of braking resistor

Some servo drives have built-in braking resistor, if users need to use external braking resistor,

please set the following both parameters:

	Braking resistor va	alue PP PV F	PPV PT CSP CSV CST HM		
	Setting range	Setting unit	Mfr's value	When enabled	
2008h-05h	8~1000	Ω		Immediate	
	Function code	Function code Mapping		Accessibility	
	So-04	N	UINT16	RW	
	Discharge duty ratio PP PV		PT CSP C	CSV CST HM	
	Setting range	Setting unit	Mfr's value	When enabled	
2008h-06h	0~100	%	50	Immediate	
	Function code	Mapping	Data type	Accessibility	
	So-05	N	UINT16	RW	

Please refer to next table for built-in braking resistor and min resistor value of external braking resistor for 220V servo.

Servo drive structure code	Built-in resistor value and power	Min resistor value of external braking resistor	Specification of external braking resistor
M1	None	40Ω	60Ω/200 W
M2	$50\mathrm{W}/50\Omega$	25Ω	40Ω/ 400 W
M3	$100 \mathrm{W}/20 \Omega$	15Ω	15Ω/ 1000 W
M4	260W/10Ω	10Ω	15Ω/ 2000 W

Please refer to next table for built-in braking resistor and min resistor value of external braking resistor for 380V servo.

Servo drive structure code	Built-in resistor value and power	Min resistor value of external braking resistor	Specification of external braking resistor
M2	$50\mathrm{W}/50\Omega$	50Ω	50Ω/1000W
M3	$100\mathrm{W}/60\Omega$	50Ω	50Ω/1000W
MM4/M4	260W/50Ω	40Ω	40Ω/1000W
M5		20Ω	20Ω/1000W
M6	_	20Ω	20Ω/2200W




Fig 7-1-12 Wiring of braking resistor




Fig 7-1-13 Wiring of braking resistor

Resistor	External	dimension	(mm)	Installation dia	mension (mm)		
power	Length (A)	Width (B)	Height (H)	Length (W)	Aperture (Φ)	Resistor type	
500W	360±3.0	50±1.0	91±3.0	338±3.0	Φ6.5±0.3	Non-sense ripple	
						porcelain tube resistor	
1kW	350±3.0	60±2.0	119±3.0	325±5.0	Ф6.5±0.3	Non-sense ripple porcelain tube resistor	
1.5kW	484±5.0	68±1.0	125±3.0	454±4.0	Ф6.5±0.3	Non-sense ripple porcelain tube resistor	
2kW	557±5.0	60±1.0	119±3.0	532±4.0	Ф6.5±0.3	Non-sense ripple porcelain tube resistor	
4kW	587±5.0	70±1.0	210±5.0	559±4.0	Ф6.5±0.3	Double tube vertical non-sense ripple porcelain tube resistor	
6kW	661±5.0	70±1.0	210±5.0	633±4.0	Ф6.5±0.3	Three tube vertical non-sense ripple porcelain tube resistor	
9kW	660±5.0	260±1.0	133±5.0	635±4.0	Ф6.5±0.3	Three tube lateral non-sense ripple porcelain tube resistor	
4kW	562±5.0	140±1.0	119±5.0	537±4.0*80	Ф6.5±0.3	Double tube lateral non-sense ripple porcelain tube resistor	
6kW	562±5.0	220±1.0	119±5.0	537±4.0*160	Ф6.5±0.3	Three tube lateral non-sense ripple porcelain tube resistor	
9kW	652±5.0	300±1.0	131±5.0	627±4.0*160	Ф6.5±0.3	Four tube lateral non-sense ripple porcelain tube resistor	

There are two installation mode can be selected for 4kW, 6kW and 9kW brake resistors. It is recommended to use last three kinds of brake resistors, which are adopted for horizontal fixed structure.

(3) Electromagnetic braking

Electromagnetic braking is suitable for servo motor with brake, which can make sure machine not move because of self-weight when servo is OFF.

7.1.8 Setting electronic gear


1) Electronic gear

At the position control mode, input position command (command unit) is used to set load displacement, motor position command (Encoder unit) is used to set motor displacement. Electronic gear ratio is used to set proportional relation between motor position command and input position command.

2) Procedure for setting the electronic gear ratio

Step	Operation	Description
1	Check machine specifications.	Check the deceleration ratio, ball screw pitch, and pulley diameter.
2	Check the number of encoder pulses.	Check the number of encoder pulses for the servo motor used.
3	Determine the command unit used.	Determine the command unit from the command controller
4	Calculate the travel distance per load shaft rotation.	Calculate the number of command units necessary to turn the load shaft one rotation based on the previously determined command units.
5	Calculate the electronic gear ratio.	Use the electronic gear ratio equation to calculate the ratio
6	Set parameters.	Set parameters using the calculated values.

Setting parameters procedure is as below:



When 2003h-05h and 6091h-01h are not 0, electronic gear ratio equals to 2003h-05h/2003h-06h (or 6091h-01h/6091h-02h). If 2003h-05h or (6091h-01h)=0, pulse numbers of motor rotating a rotation is controlled by 2003h-06h or (6091h-02h).

3)Related parameters

① Function code

	First group electron	nic gear numerator		PP CSP
	Setting range	Setting unit	Mfr's value	When enabled
2003h-05h	0~65535	N/A	0	Immediate
	Function code	Mapping	Data type	Accessibility
	Po304	N	UINT16	RW
	First group electro	nic gear denominato	r	PP CSP
	Setting range	Setting unit	Mfr's value	When enabled
2003h-06h	1~65535	N/A	10000	Immediate
	Function code	Mapping	Data type	Accessibility
	Po305	N	UINT16	RW
	Numerator of Gear	ratio		PP HM CSP
	Setting range	Setting unit	Mfr's value	When enabled
6091h-01h	$0\sim (2^{31}-1)$	N/A	0	Immediate
	Function code	Mapping	Data type	Accessibility
	Po344	N	DINT32	RW
	Denominator of ele	ectronic gear		PP HM CSP
	Setting range	Setting unit	Mfr's value	When enabled
6091h-02h	$1 \sim (2^{31}-1)$	N/A	10000	Immediate
	Function code	Mapping	Data type	Accessibility
	Po346	N	UDINT32	RW

Note: the default gear ratio is the second electronic gear ratio.

② Electronic gear ratio switchover

If two groups of electronic gear ratio have large difference, motor speed fluctuates wildly when electronic gear ratio switchover. (2003h-07h) position command filter can smooth position switchover.

When 2003h-28h=2, electronic gear switchover function is valid. Only one group gear ratio is valid at the same moment.

	Electronic gear rati	o selection		PP CSP	
	Setting range	Setting unit	Mfr's value	When enabled	
	0~2	N/A	1	Immediate	
2003h-28h	Function code		Data type	Accessibility	
200311-2011	Po339	N	INT16	RW	
	0: First electronic gear ratio				
	1: Second electronic gear ratio				
	2: Two groups of electronic gear ratio switchover				

When the terminal is valid, the second electronical gear ratio is valid. When the terminal is invalid, the first electronical gear ratio is invalid. The entry-into-effect time is 100ms.

4) Instruction

The deceleration ratio is n/m, electronic gear numerator is B, and electronic gear denominator is A, so the setting value of electronic gear ratio is:

Note: The deceleration ratio is n/m where m is the rotation of the servo motor and n is the rotation of the load shaft.

B/A=Po304/ Po305=(No. of encoder pulses×4/travel distance per load shaft rotation)× (m/n) The actual meaning of electronic gear is:

Command pulse input Pulses numbers are
$$X$$
 \xrightarrow{B} Position command $Y = X \times \frac{B}{A}$

* If the ratio is outside the setting range, reduce the fraction (both numerator and denominator) until you obtain integers within the range. Be careful not to change the electronic gear ratio (B/A).

Electronic gear ratio setting range: $0.01 \le \text{Electronic gear ratio } (B/A) \le 100$

If the electronic gear ratio is outside this range, the control precision will decrease.

Ex: The following example shows electronic gear ratio settings for ball screw which pitch is 6mm.




Fig 7-2-2 Setting electronic gear

Step	Operation	Calculation
1	Check machine specifications.	The deceleration ratio is 1:1 and the pitch is
2	Check the number of encoder	17 bits encoder
3	Determine the command unit used.	The command unit is 1μm.
4	Calculate the travel distance per load shaft rotation.	6000μm/1μm=6000
5	Calculate the electronic gear ratio.	B/A=(131072/6000) ×1/1
6	Set parameters.	2003h-05h=8192 2003h-06h=375

7.1.9 Position command filter

For the below situation, position command filter should be selected:

- 1.Position command of PC/PLC output is not dealt with by acceleration/deceleration.
- 2. The frequency of pulse command is high.
- 3. The electronic gear ratio is higher than 10 times


	Position loop filter time constant			PP CSP
	Setting range	Setting unit	Mfr's value	When enabled
2003h-07h	1~10000	ms	1	Immediate
	Function code	Mapping	Data type	Accessibility
	Po306	N	INT16	RW

Setting position loop filter time constant correctly can make motor rotate smoothly. The parameter does not affect pulse numbers.

Filter frequency is used to inhibit high-frequency of disturbance pulses. Please do not set this value too low, avoid inhibiting effective high-frequency pulse command.

7.1.10 Position command inhibit function

This function inhibits the servo drive from counting input pulses during position control.



(1) Input signal

Signal name	Code	Default terminal	Remarks
Command pulse inhibit	INH-P	Must be allocated	Inhibiting the servo drive from counting input pulses, position pulse command is invalid.

(2) Setting parameters

Parameters	Remarks
2003h-09h.A=0	Terminal of inhibiting command pulse is invalid.
2003h-09h.A=1	Terminal of inhibiting command pulse is valid.

7.1.11 Command pulse clear function

Position deviation=(position command-position feedback) (encoder unit) This function clears position deviation register during position control.

(1) Input signal

Signal name	Code	Default terminal	Remarks
Pulse clear	CLR	CN3-37 (at the mode of position pulse)	Clearing position deviation register during position control

(2) Setting parameters

Parameters	Remarks
2003h-09h.B=0	Command pulse clear function is OFF.
2003h-09h.B=1	Command pulse clear function is ON.

7.1.12 Frequency-division output function

Encoder pulse is frequency-division processed by servo drive internal circuit, and orthogonal differential signal outputs. The frequency-division signal setting is as below:




Fig 7.2.5 Frequency-division output diagram


(1) Output signal

Encoder pulse frequency-division signal has three groups output terminals.

		•	9 1 1
Signal	name	Terminal code	Remarks
PA	PAO-	CN3 – 36	Encoder A phase pulse frequency-division output
phase	PAO+	CN3 - 35	Encoder A phase pulse frequency-division output
PB	PBO-	CN3 – 34	Encoder B phase pulse frequency-division output
phase	PBO+	CN3 – 33	Efficación B phase pulse frequency-division output
DZ	PZO-	CN3 – 16	Encoder Z phase home pulse output
PZ phase	PZO+	CN3 – 17	(no frequency-division)
	OZ	CN3-37	Z phase open collector output

When output signal is frequency-division, output pulse source (2000h-13h) and phase (2003h-01h) should be set by actual requirement. When output source is motor shaft, and motor rotates one revolution, A/B phase output pulse numbers is controlled by 2000h-04h (Molecule of encoder frequency-division numbers), width is controlled by motor speed.

When output signal is Z phase open collector output, pulse output setting (2000h-13h) should be set by actual requirement. At high-speed, Z pulse is narrow, and it can be adjusted by 2000h-12h.



(2) Related parameters

(2) Related parameters					
	Encoder frequency	-division numbers	PPPV PTCSPCSVCSTHM		
	Setting range	Setting unit	Mfr's value	When enabled	
2000h-04h	1~65535	N/A		Immediate	
	Function code	Mapping	Data type	Accessibility	
	Po003	N	UINT16	RW	
	Encoder pulse frequency-divisi		umbers denominator		
	PP PV PT	CSP CSV	CST HM		
2000h-06h	Setting range	Setting unit	Mfr's value	When enabled	
200011-0011	1~2147483647	N/A	_	Immediate	
	Function code	Mapping	Data type	Accessibility	
	Po005	N	UDINT32	RW	
	Z pulse frequency	-division output wid	th PP PV PT C	SP CSV CST HM	
	Setting range	Setting unit	Mfr's value	When enabled	
2000h-12h	50~30000	N/A		Immediate	
	Function code	Mapping	Data type	Accessibility	
	Po017	N	INT16	RW	
	Pulse output configuration PP		PV PT CSP CSV	V CST HM	
	Setting range	Setting unit	Mfr's value	When enabled	
	Four-parameter	N/A	0001	Immediate	
	Function code	Mapping	Data type	Accessibility	
	Po018	N	UINT16	RW	
	В				
		A	Z pulse output polarity		
		0	Negative polarity output		
2000h-13h			1 Positive polarity output		
		B 0	Z pulse command source Motor shaft		
		1	Virtual shaft		
			se frequency-division command s	ource	
		0	Motor shaft		
		1	Internal position given		
		2	Collector pulse input		
		3	High-speed counter 1		
		4	High-speed counter 2		
		5	Position command		

 Table 7.2.1
 Encoder frequency-division output pulse

2003h-01h.D (output pulse phase)	Forward rotation Pulse output	Reverse rotation Pulse output
0	A phase	A phase
	A phase is 90 degrees ahead of B	B phase is 90 degrees ahead of
	phase.	A phase.
1	A phase B phase	A phase B phase
	B phase is 90 degrees ahead of A	A phase is 90 degrees ahead
	phase.	of B phase.

Table 7.2.2 Z phase open collector output

2000h-13h.A (output pulse phase)	2000h-12h (Z phase expansion)	Forward rotation Pulse output	Reverse rotation Pulse output
0	500		
1	500		

(3) Wiring terminals

Signal	name	Terminal	Remarks
		code	
PA	PAO-	CN3-35	Encoder A phase pulse frequency-division output
phase	PAO+	CN3-36	Encoder A phase pulse frequency-division output
PB	PBO-	CN3-33	Encoder D phase pulse frequency division output
phase	PBO+	CN3-34	Encoder B phase pulse frequency-division output
	PZO-	CN3-17	Encoder Z phase home pulse output (no
PZ	PZO+	CN3-16	frequency-division)
phase	OZ	CN3-37	Z phase open collector output
	CM	CN3-30	Z phase open conector output

(4) Example of pulse frequency-division signal

Example: when 2000h-04h = 16, 2000h-06h = 32768, the each circle and each phase output pulse numbers of encoder is 16.




Fig 7-2-6 Encoder frequency-division output

When output signal is open collector output, frequency must not be higher than 100KHZ, 2000h-04h should not be set too high.

7.2 Servo Status Setting

Servo drive must be guided according to standard 402 protocol.




Fig 7.2.1 CiA402 status machine switchover

Status description:

Initialization	Initialization of servo drive and self-check have been done.
	Parameters setting or drive function cannot be implemented.
No fault	No fault exists in the servo drive or the fault is eliminated.
140 fault	Parameter setting of the servo drive is allowed.
Comro mondre	The servo drive is ready.
Servo ready	Parameters setting of servo drive is allowed.
Wait for servo	The drive waits for servo enabled.
enabled	Parameters setting of the servo drive is allowed.
Dunning	The servo drive is in normal running state, a certain drive mode is enabled,
Running	the motor is energized, and rotates when the reference is not 0.
Ovids ston	The quick stop function is enabled, and the servo drive executes quick
Quick stop	stop.
Stop at fault	At fault occurs, and the servo drive stops.
Fault The stop process is completed, and all the drive function are inhibited.	

Control command and state switchover.

	CiA402 state switchover	Control word 6040h	Status word 6041h bit0~bit9
0	power on Initialization	Natural transition, control command not required	0000h
1	Initialization No fault	Natural transition, control command not required If an error occurs during initialization, the servo drive directly goes to state 13	0270h
2	No fault Ready	0006h	0231h
3	Ready Wait for servo enabled	0007h	0233h
4	wait for servo enabled —running	000Fh	0237h
5	running Wait for servo enabled	0007h	0233h
6	Wait for servo enabled - Ready	0006h	0231h
7	Ready No fault	0000h	0250h
8	Running - Ready	0006h	0231h
9	Running No fault	0000h	0270h
10	Wait for servo enabled → No fault	0000h	0270h
11	Running Fast to stop	0002h	0217h
12	Fast to stop No fault	Set 605Ah to a value among 0 to 3. Natural transition is performed after stop, and no control command is required.	0270h
13	Stop at fault	Once a fault occurs in any state other than "fault", the servo drive automatically switchovers over to the stop at fault state, without control command.	021Fh
14	Stop at fault - Fault	Natural transition after stop at fault, control command not required.	0238h
15	Fault No fault	80h; Bit 7 is rising edge valid. If Bit7=1, the other control words are invalid.	0270h
16	Fast to stop Running	Set 605h to a value among 5 to 7. After the stop process is completed, 0Fh is sent after the stop process is completed.	0237h

7.2.1 Control word 6040h

Indov	Name	Control word		Setting type	 Data structure	VAR
Index 6040h	Access	RW	Mapping	RPDO	Data type	UINT16
004011	Related mode	ALL	Data range	0-65535	Default	0

It controls the state machine of the servo drive.

bit	Name	Description
0	Servo ready	1-Valid 0-Invalid
1	Switch on	1-Valid 0-Invalid
2	Fast to stop	1-Valid 0-Invalid
3	Running	1-Valid 0-Invalid
4-6		Related to the drive modes.
7	Fault reset	Falling edge is valid.
8	Halt	1-Valid 0-Invalid
9-10	NA	Reserved
11-15	Manufacturer specific	Reserved

NOTE:

- 1. The bits in the control word together specify a certain control commad, and are useless if set separately.
- 2. The meaning of bit0 to bit3 and bit7 keep the same in each control mode of the servo drive. The servo drive switches to the present state according to the CIA402 state machine only when the control words are sent in sequence. Each command indicates a state.
- 3. The meaning of bit4 to bit6 vary according to each control mode. For details, refer to the control command in each control mode.

7.2.2 Status word 6041h

Index	Name	Status word	Setting	Display	Data	VAR
6041h			mode		structure	

Access	RO	Mapping	TPDO	Data type	UINT16
Related	ALL	Data	0-65535	Default	_
mode		range			

It indicates the state of the servo drive.

Value (Binary)	Description
xxxx xxxx x0xx 0000	Not ready to switch on
xxxx xxxx x1xx 0000	Switch on disabled
xxxx xxxx x01x 0001	Ready to switch on
xxxx xxxx x01x 0011	Switch on
xxxx xxxx x01x 0111	Operation enabled
xxxx xxxx x00x 0111	Quick stop active
xxxx xxxx x01x 1111	Fault reaction active
xxxx xxxx x0xx 1000	Fault

Note:

- 1. The bits in the control word together specify the present state of the servo drive, and are usless if set separately.
- 2. The meaning of bit0-bit9 keep the same in each control mode of the servo drive. This parameter indicates the state of the servo drive when the control words in 6040h are sent in sequence.
- 3. The meaning of bit12-bit13 vary according to each control mode. For detains, refer to the control command in each control mode.
- 4. The meaning of bit10, bit11 and bit15 keep the same in each control mode of the servo drive, and indicates the status after a certain control mode is implemented.

7.3 Profile position mode (PP)

In this mode of operation, host controller uses the path generation function (an operation profile calculation function) inside the servo drive to perform PTP positioning operation. It executes path generation, position control, speed control, and torque control based on the target position, profile acceleration, profile deceleration, and other information.




Fig 7.3.1 Block diagram for the PP mode

7.3.1 Related objects

Control word 6040h						
Bit	Name	Description				
0	Switch on	If bit0 to bit3 are all 1, the servo drive starts running.				
1	Enable voltage					
2	Quick stop					
3	Enable operation					
4	New set-point	Starts positioning at rising edge from 0 to 1 of the signal. In this timing, the values of 607Ah (target position), 6081h (Profile velocity), 6083h (Profile acceleration), and 6084h (Profile deceleration) are obtained.				
5	Change set immediately	Not change set immediately. Change set immediately.				
6	abs/rel	O: Target position being absolute position reference. 1: Target position being relative position reference.				
Status	Status word 6041h					
Bit	Name		Description			
10	Target reached		0: Target position not reached 1: Target position reached			
12	Set-point acknowledge		Waiting for a new Target position Not update target position			

1			
	12	Follow error	0: No position deviation excessive fault
	15	Follow elloi	1: Position deviation excessive fault present

Index	Sub- index	Name	access	Date format	Unit	Setting range	default
603Fh	00h	Error code	RO	UINT16	_	_	
6040h	00h	Control word	RW	UINT16	_	0~65535	0
6041h	00h	Status word	RO	UINT16	_	0~65535	0
6060h	00h	Operation mode	RW	UINT16		0~10	0
6061h	00h	Mode display	RO	UINT16	_		
6062h	00h	Position command	RO	DINT32	Command		_
6063h	00h	Position feedback	RO	DINT32	Encoder		_
6064h	00h	Position actual value	RO	DINT32	Command		
6065h	00h	Following error window	RW	UINT16	Command unit	1~32000	_
6067h	00h	Position window	RW	DINT32	Command	1~32000	_
6068h	00h	Position window time	RW	INT16	ms	0~65535	0
606Ch	00h	Velocity actual value	RO	DINT32	0.1rpm		
6077h	00h	Torque actual value	RO	INT16	1%		
607Ah	00h	Target position	RW	DINT32	Command unit	-2^{31} ~ + $(2^{31}$ -1)	0
6083h	00h	profile acceleration	RW	UINT16	ms	1~32000	100
6084h	00h	profile deceleration	RW	UINT16	ms	1~32000	100
6091h	01h	numerator of gear ratio	RW	UDINT3 2	_	$0 \sim (2^{31} - 1)$	0
009111	02h	Denominator of gear ratio	RW	UDINT3 2	_	$1 \sim (2^{31} - 1)$	10000
60E0h	00h	Positive torque limit value	RW	UINT16	1%	0~800	100
60E1h	60E1h 00h Negative torque limit value		RW	UINT16	1%	0~800	100
60F4h	00h	Position deviation	RO	DINT32	Command		
6081h	6081h 00h Profile velocity		RW	UINT16	0.1rpm	0~65535	0

7.3.2 Related functions

1) Positioning completed:

Index	Sub-index	Name	Description
6067h	00h	Position reached	When the position deviation is within

		threshold	±6067h, and the time reaches 6068h, the
6068h	00h	Position window	servo drive considers that the position is reached, and sets status word 6041h bit10 = 1 in position control mode. The position reached DO signal is invalid when either of the condition is not met.

1) Following error window:

Index	Sub-index	Name	Description
6065h	00h	Following error window	When the position deviation exceeds 6065h, AL-09 is displayed on the keypad, and bit13 of the status word is set to 1.

7.3.3 Path Generator

1) Time sequence 1: change immediately

After receiving the rising edge of 6040h bit4, the dirve should execute current position reference immediately.

In the mode of change immediately, the drive immediately executes the new position reference once receiving it (6041h bit12 changes from 0 to 1).

In the mode of change immediately, after detecting that 6040h bit4 changes from 1 to 0, the drive sets 6041h bit12 to 0

In the mode of change immediately, if the drive receives a new position reference ② when executing the previous position reference ①, it does not abandon the position reference not finished in ①. With a relative position reference, after new position reference ② is finished, total position increment = target position increment 607Ah of ① + target position increment 607Ah of ②.

With an absolute position reference, after new position reference ② is finished, total position increment = target position increment 607Ah of ③.




Fig 7.3.2 Time sequence and motor profile in the mode of change immediately


• Operation description:

Example: two position references, change immediately, absolute Position reference ①:

Target position 607Ah=10000 6081h=600

Position reference 2:

Target position 607Ah=10000 6081h=1200



2) Time sequence 2: Not change immediately

After last position reference is finished and position arrival, the drive will execute current position reference after receving the rising edge of bit 4. The drive will not accept new position reference before position arrival. The drive changes 6041h bit 12 to 1, which indicates the drive has received the new position reference and execute it.

In the mode of not change immediately, after detecting that 6041h changes from 1 to 0, the drive sets 6041h bit12 to 0.

In the mode of not change immediately, during the executing process of position reference ①, new position reference ② is invalid. The current target position is still unfinished target position.




Fig 7.3.3 Time sequence motor profile in the mode of not change immediately




Fig 7.3.4 Difference between absolute and relative position reference

7.3.4 Recommended configuration

The basic configuration for the PP mode is described in the following table.

RPDO	TPDO	Remarks
6040h: Control word	6041h: Status word	Mandatory
607Ah: Target velocity	6064h: Position actual value	Mandatory
6081h: Profile velocity		Mandatory
6060h: Modes of operation	6061h: Modes of operation display	Optional

7.4 Profile velocity mode (PV)

In this mode of operation, the host controller gives the target speed, acceleration, and deceleration to the servo drive. Speed control and torque control are performed by the servo drive.




Fig 7.4.1 Block diagram for the PV mode

7.4.1 Related objects

	Control word 6040h					
Bit	Name	Description				
0	Switch on					
1	Enable voltage	If hit 0 to hit 2 are all 1, the samue drive				
2	Quick stop	If bit0 to bit3 are all 1, the servo drive starts running.				
3	Enable operation	starts running.				
8	Halt					
	Status word 604	11h				
Bit	Name	Description				
10	Toward wards	0: Target velocity not reached				
10	Target reach	1: Target velocity reached				
12	Drive follow the command value	0: The drive not follow command.				

				1: Th	e drive follo	w command.	
Index	Sub- index	Name	acce ss	Data format	Unit	Setting range	Defau lt
603Fh	00h	Error code	RO	UINT16			0
6040h	00h	Control word	RW	UINT16	_	0~65535	0
6041h	00h	Status word	RO	UINT16	_	0~65535	0
6060h	00h	Operation mode	RW	UINT16		_	0
6061h	00h	Mode display	RO	UINT16	_	_	0
607Fh	00h	Max profile velocity	RW	UDINT32	rpm	0~13000	
6063h	00h	Position feedback	RO	DINT32	Encoder unit	_	
6064h	00h	Position actual value	RO	DINT32	Comman d unit	_	_
60FFh	00h	Target velocity	RW	DINT32	0.1rpm	-130000 ~ 130000	0
60E0h	00h	Positive torque limit value	RW	INT16	1%	0~800	100
60E1h	00h	Negative torque limit value	RW	INT16	1%	0~800	100
606Ch	00h	Velocity actual value	RO	DINT32	0.1rpm	_	_
6077h	00h	Torque actual value	RO	INT16	1%		_
6083h	00h	Profile acceleration time	RW	UINT16	ms	0~32000	100

6084h 00h Profile deceleration time	RW	UINT16	ms	0~32000	100]
-------------------------------------	----	--------	----	---------	-----	---

7.4.2 Related functions

Index	Sub-index	Name	Description
606Dh	00h	Velocity threshold	When the difference between 60FFh (converted into motor speed/RPM) and actual motor speed is within ±606Dh, and the time reaches 606Eh,
606Eh	00h	Velocity window	the servo drive considers that the speed reference is reached, sets status word 6041h bit10 = 1 and activates the speed reached DO signal. This flag bit is valid only when the S-ON signal is valid in profile position mode and cyclic synchronous velocity mode.

7.4.3 Recommended configuration

RPDO	TPDO	Remarks
6040h: control word	6041h: status word	Mandatory
60FFh: target velocity		Mandatory
	6064h: position actual value	Optional
	606Ch:velocity actual value	Optional
6083h: profile acceleration		Optional
6084h: profile deceleration		Optional
6060h: modes of operation	6061h: Modes of operation display	Optional

7.5 Profile torque mode (PT)

In this mode of operation, the controller gives the target torque in 6071h to the servo drive. Torque control is performed by the servo drive. The servo drive will supply actual position value, actual velocity value and actual torque value.




Fig 7.5.1 Block diagram for the PT mode

7.5.1 Related objects

	Control word 6040h				
Bit	Function	Description			
0	Switch on				
1	Enable voltage	If hit0 to hit2 are all 1, the same drive			
2	Quick stop	If bit0 to bit3 are all 1, the servo drive			
3	Enable operation	starts running.			
8	Halt				
	Status	s word 6041h			
Bit	Function	Description			
10	Target Decel	0: Target torque not reached			
10	Target Reach	1: Target torque reached			
12	Internal limit active	0: Position feedback not exceeding limit			
12	internal mint active	1: Position feedback exceeding limit			

Index	Sub- index	Name	Access	Data format	Unit	Setting range	Defau lt
603Fh	00h	Error code	RO	UINT16	_		_
6040h	00h	Control word	RW	UINT16	_	0~65535	0
6041h	00h	Status word	RO	UINT16	_	0~65535	0
6060h	00h	Operation mode	RW	UINT16	_		0
6061h	00h	Mode display	RO	UINT16	_		_
6063h	00h	Position feedback	RO	DINT32	Encoder unit		
6064h	00h	Position actual value	RO	DINT32	Command unit		
6065h	00h	Position deviation threshold excessive	RW	UINT16	Command unit	1~32000	

6067h	00h	Position arrival	RW	DINT32	Command	1~32000	
		threshold			unit		
6068h	00h	Position arrival	RW	INT16	ms	0~65535	0
		window					
606Ch	00h	Velocity actual value	RO	DINT32	0.1rpm		
6071h	00h	Target torque	RW	INT16	1%	±800	0
6072h	00h	Max. torque	RW	UINT16	1%	0~800	200
6074h	00h	Torque demand value	RO	INT16	1%		
6077h	00h	Torque actual value	RO	INT16	1%		
607Fh	00h	Max profile velocity	RW	UDINT32	rpm	0~13000	

7.5.2 Related functions

1) Torque reached.

Index	Sub-index	Name	Description
2002h	26h	Range of torque reached	When the difference between the actual torque and based value is larger than 2002h-26h, the signal of torque reached is output, and status word 6041h bit10 is set to 1. When the difference is smaller than 2002h-26h, the signal of torque reached is invalid, and status word 6041h bit10 is cleared to 0.

2) Speed Limit in torque control:

Index	Sub inde	Name	Access	Data format	Unit	Setting range	D	efault
2002h	0Bh	Speed limit source	RW	INT16	N/A	0~2	0	
Value	Value Description							
0	Th	The speed limit is set in 2002h-0Ch.						
1	Re	Reserved						
2	Th	The speed limit is lower value between 607Fh and motor actual spe d.						

7.5.3 Recommended configuration

The basic configuration for the PT mode is as below table:

RPDO	TPDO	备注
6040h: control word	6041h: status word	Mandatory

6071h: target torque		Mandatory
6087h: torque slope		Optional
	6064h: position actual value	Optional
	606Ch: velocity actual value	Optional
	6077h: torque actual value	Optional
6060h: modes of operation	6061h: Modes of operation display	Optional

7.6 Cyclic Synchronous Position Mode (CSP)

In this mode of operation, the host controller generates the position references and gives the target position in 607Ah to the servo drive using cyclic synchronization. Position control, speed control, and torque control are performed by the servo drive.




Fig 7.6.1 Configuration block diagram for CSP mode

7.6.1 Related object

	Control word 6040h				
Bit	Function	Description			
0	Switch on				
1	Enable voltage	If hit 0 to hit 2 are all 1 the source drive starts			
2	Quick stop	If bit0 to bit3 are all 1, the servo drive starts			
3	Enable operation	running.			
8	Halt				
	Statu	s word 6041h			
Bit	Function	Description			
10	Target Deech	0: Target position not reached			
10	Target Reach	1: Target position reached			
		0: Both position references and feedback not			
11	Internal limit active	exceeding limit			
		1: Position references or feedback exceeding limit			
		0: Drive not following command			
	Drive follow the command	1: Drive following command			
12	value	If the servo drive is in running state and starts to			
	value	execute position references, this bit is set to 1,			
		otherwise, it is set to 0.			
13	Follow error	0: No position deviation excessive fault			
15	1.0110M CITOI	1: Position deviation excessive fault present			

Index	Sub- index	Name Code	Name Code access Data type Setting Unit		Setting range	Mfr's value	
603Fh	00h	Error code	RO	UINT16		_	_
6040h	00h	Control word	RW	UINT16		0~65535	0
6041h	00h	Status word	RO	UINT16	_	0~65535	0
6060h	00h	Operation mode	RW	UINT16	_	_	0
6061h	00h	Mode display	RO	UINT16			
6062h	00h	Actual position	RO	DINT32	Command unit	_	-
6063h	00h	Position feedback	RO	DINT32	Encoder unit		
6064h	00h	Position actual value	RO	DINT32	Command unit		
6065h	00h	Position deviation threshold excessive	RW	UINT16	Command unit	1~32000	_
6067h	00h	Position arrival threshold	RW	DINT32	Encoder unit	0-65535	734

6068h	00h	Position arrival window	RW	UINT16	ms	0-65535	x10
606Ch	00h	Velocity actual value	RO	DINT32	0.1rpm	_	
6072h	00h	Max torque	RW	UINT16	1%	0~800	200
6074h	00h	Torque demand value	RO	INT16	1%	_	
6077h	00h	Torque actual value	RO	INT16	1%	—	_
607Ah	00h	Target position	RW	DINT32	Command unit	-2^{31} \sim $+ (2^{31}$ -1)	0
6091h	01h	Numerator of Gear ratio	RW	UDINT32	_	$0\sim$ (2 ³¹ -1)	0
009111	02h	Denominator of electronic gear	RW	UDINT32	_	$1 \sim (2^{31} - 1)$	10000
60B0h	00h	Position offset	RW	DINT32	_	-2^{31} \sim + $(2^{31}$ -1)	0
60B1h	00h	Velocity offset	RW	DINT32	0.01rpm	-1300000 ~ 1300000	0
60B2h	00h	Torque offset	RW	DINT32	0.1%	-1000~ 1000	0
60F4h	00h	Positional deviation	RO	DINT32	Command unit	_	

7.6.2 Related function

1) Positioning completed:

Index	Sub- index	Name	Description
6067h	00h	Position arrival threshold	When the position deviation is within ±6067h, and the time reaches 6068h, the
6068h	00h	Position window	servo drive considers that the position is reached, and sets status word 6041h bit10 = 1 in position control mode. The position reached signal is invalid when either of the condition is not met.

2) Following error window:

Index	Sub- index	Name	Description
6065h	00h	Following error window	When the position deviation is higher than 6065h, AL-09 is displayed on the keypad, and bit13 of the status word is set to 1.

7.6.3 Recommended configuration

The basic configuration for the CSP mode is described in the following table:

RPDO	TPDO	Remarks
6040h: control word	6041h: status word	Mandatory
607Ah: target velocity	6064h: position actual value	Mandatory
6060h: modes of operation	6061h: Modes of operation display	Optional

7.7 Cyclic Synchronous Velocity Mode (CSV)

In this mode of operation, the host controller gives the target speed in 60FFh to the servo drive using cyclic synchronization. Speed control and torque control are performed by the servo drive.




Fig 7.7.1 Configuration block diagram for CSV mode

7.7.1 Related objects

	Control Word 6040						
Bit	Name	Description					
0	Switch on						
1	Enable voltage	T61:40 / 1:42					
2	Quick stop	If bit0 to bit3 are all 1, the servo drive starts					
3	Enable operation	running.					
8	Halt						
	Status word 6041						
Bit	Name	Description					

10	Target Reached	0: Target velocity not reached 1: Target velocity reached
12	Drive follow the command value	0: Drive not following command
12		1: Drive following command

Index	Sub- index	Name code	Access	Data type	Setting unit	Setting range	Mfr's value
603Fh	00h	Error code	RO	UINT16	_		_
6040h	00h	Control word	RW	UINT16	_	0~65535	0
6041h	00h	Status word	RO	UINT16	_	0~65535	0
6060h	00h	Operation mode	RW	UINT16	_	_	0
6061h	00h	Mode display	RO	UINT16	_	_	_
6063h	00h	Position feedback value	RO	DINT32	Encoder unit	_	
6064h	00h	Position actual value	RO	DINT32	Command unit	_	_
606Ch	00h	Velocity actual value	RO	DINT32	0.1rpm	_	_
6077h	00h	Torque actual value	RO	INT16	1%	_	_
607Fh	00h	Max profile velocity	RW	UDINT3 2	rpm	0~13000	
6083h	00h	Profile accel time	RW	UINT16	ms	0~32000	100
6084h	00h	Profile decel time	RW	UINT16	ms	0~32000	100
60B1h	00h	Velocity offset	RW	DINT32	0.01rpm	-1300000 ~ 1300000	0
60B2h	00h	Torque offset	RW	DINT32	0.1%	-1000∼ 1000	0
60E0h	00h	Forward torque limit	RW	INT16	1%	0~800	100
60FFh	00h	Target velocity	RW	DINT32	0.1rpm	-130000 ∼130000	0

7.7.2 Related functions

Index	Sub- index	Name	Description
-------	---------------	------	-------------

606Dh	00	Velocity arrival threshold	When the difference between 60FFh (converted into motor speed/RPM) and actual motor speed is within ±606Dh, and the time reaches 606Eh, the servo drive considers that the speed reference is reached, sets status word 6041h bit10 = 1 and activates the speed
606Eh	00	Velocity window	reached DO signal. This flag bit is valid only when S-ON signal is valid in profile position mode and cyclic synchronous velocity mode.

7.7.3 Recommended configuration

The basic configuration for the CSV mode is described in the following table:

RPDO	TPDO	Remarks
6040h: control word	6041h: status word	Mandatory
60FFh: target velocity		Mandatory
	6064h: position actual value	Optional
	606Ch: velocity actual value	Optional
6060h: modes of operation	6061h: Modes of operation display	Optional

7.8 Cyclic Synchronous Torque Mode (CST)

In this mode of operation, host controller gives the target torque in 6071h to the servo drive using cyclic synchronization. Torque control is performed by the servo drive. The servo drive will supply actual position value, actual speed value and actual torque value.




Fig 7.8.1 Configuration block diagram for CST mode

7.8.1 Related objects

Control Word 6040h				
Bit	Name	Description		
0	Switch on			
1	Enable voltage	If bit0 to bit3 are all 1, the servo		
2	Quick stop	drive starts running.		
3	Enable operation			

8	Halt	
	Status word 60411	h
Bit	Name	Description
10	Torget Decembed	0: Target torque not reached
10	Target Reached	1: Target torque reached
12	Drive follow the command value	0: Drive not following command
12	Drive follow the command value	1: Drive following command

Index	Sub -index	Name code	access	Data type	Setting unit	Setting range	Mfr's value
603Fh	00h	Error code	RO	UINT16		_	
6040h	00h	Control word	RW	UINT16		0~65535	0
6041h	00h	Status word	RO	UINT16		0~65535	0
6060h	00h	Operation mode	RW	UINT16		_	0
6061h	00h	Mode display	RO	UINT16		_	
6063h	00h	Position feedback value	RO	DINT32	Encoder unit	_	
6064h	00h	Position actual value	RO	DINT32	Command unit	_	
606Ch	00h	Velocity actual value	RO	DINT32	0.1rpm	_	
6071h	00h	Target torque	RW	INT16	1%	±800	0
6072h	00h	Max torque	RW	UINT16	1%	0~800	200
6074h	00h	Torque demand value	RO	INT16	1%	_	
6077h	00h	Torque actual value	RO	INT16	1%	_	_
607Fh	00h	Max profile velocity	RW	UDINT32	rpm	0~13000	_
60B2h	00h	Torque offset	RW	DINT32	0.1%	-1000 ~1000	0
60E0h	00h	Forward torque limit	RW	INT16	1%	0~800	100

7.8.2 Related functions

1) Torque reached

Index	Sub- index	Name	Description
2002h	26h	Torque reached range	When the difference between the actual torque and based value is larger than 2002h-26h, the torque reached signal is output, and status word 6041h bit10 is set to 1.

	When the difference is smaller than 2002h-26h,
	the torque reached signal is invalid, and status
	word 6041h bit10 is cleared to 0.

7.8.3 Recommended configuration

The basic configuration for the CST mode is described in the following table:

RPDO	TPDO	Remarks
6040h: control word	6041h: status word	Mandatory
6071h: target torque		Mandatory
	6064h: position actual value	Optional
	606Ch: velocity actual value	Optional
	6077h:torque actual value	Optional
6060h: modes of operation	6061h: Modes of operation display	Optional

7.9 Homing mode (HM)

This mode searches for home and determines the position relationship between home and zero.

Home: mechanical home reference point, that is, the motor Z signal.

Zero: absolute zero point in the machine

After homing is completed, the motor stops at the home. The relationship between home and zero is set in 607Ch.

Home = Zero + 607Ch (Home offset)

When 607Ch = 0, the zero is the same as the home.

7.9.1 Related objects

Control Word 6040h					
Bit	Name	Description			
0	Switch on	1: Valid, 0: Invalid If his 0 to his 2 are all 1, the			
1	Enable voltage	1: Valid, 0: Invalid If bit0 to bit3 are all 1, the			
2	Quick stop	1: Valid, 0: Invalid servo			
3	Enable operation	1: Valid, 0: Invalid	drive starts running.		
4	Homing star	0->1: Homing start 1: Homing ongoing 1->0: Homing end			
8	Halt	0: The servo drive determines whether to start homing according to bit4 setting. 1: The servo drive halts according to 605Dh.			
Status word 6041h					
Bit	Name	Description			
10	Target reached	0: Target position not reached 1: Target position reached			
12	Homing attained	0: Homing failed 1: Homing successful			

		This flag bit is valid when the drive is in homing mode in running state and the target reached signal is active.	
13 Homing error		0: No homing error 1: Homing timeout or deviation excessive	

Index	Sub- index	Name	Access	Data format	Unit	Setting range	Default
603Fh	00h	Error code RO		UINT16	_	0-65535	0
6040h	00h	Control word	RW	UINT16	_	0-65535	0
6041h	00h	Status word	RO	UINT16	_	0-xFFFF	0
6060h	00h	Operation mode	RW	INT8	_	0-10	0
6061h	00h	Mode display	RO	INT8	_	0-10	0
6062h	00h	Actual position	RO	DINT32	Command unit		-
6064h	00h	Position feedback	RO	DINT32	Command unit		1
6067h	00h	Position reached threshold	RW	DINT32	Encoder unit	0-65535	734
6068h	00h	Position window	RW	INT16	ms	0-65535	x10
6077h	00h	Torque actual value	RO	INT16	0.1%		0
606Ch	00h	Speed actual value	RO	DINT32	0.1rpm		-
6098h	00h	Homing method	RW	INT16	_	-1-35	0
6099h	01h	First speed during search for zero	RW	UINT16	0.1rpm	0-20000	500
	02h	Second speed during search for zero	RW	UINT16	0.1rpm	0-10000	200
609Ah	00h	Acceleration time	RW	UINT16	ms	0-1000	0
2001h	1Eh	Deceleration time	RW	UINT16	ms	100-65535	10000
60F4h	00h	Position deviation	RO	DINT32	Command unit	_	

7.9.2 Related functions

1) Homing timeout

Index	Sub-index	name	Description
2001h	1Eh	Duration limit of homing	If homing is not completed within the duration, AL-35 will be detected, indicating homing timeout.


7.9.3 Homing operation

1) 6098h=1

Home: motor Z signal

Deceleration point: negative limit switch


a) Deceleration point signal inactive at homing start



Note: in the figure, "H" represents high speed, "L" represents low speed.

When homing starts and R-INH=0, the motor starts homing in negative direction at high speed. After reaching the rising edge of the R-INH signal, the motor decelerates and changes to run in positive direction at low speed. After reaching the falling edge of the R-INH signal, the motor stops at the first motor Z signal.

b) Deceleration point signal active at homing start




When homing starts and R-INH=1, the motor directly starts homing in positive direction at low speed. After reaching the falling edge of the R-INH signal, motor stops at first motor Z signal.

2)6098h=2

Home: motor Z signal


Deceleration point: positive limit switch

a) Deceleration point signal inactive at homing start



When homing starts and F-INH=0, the motor starts homing in positive direction at high speed. After reaching the rising edge of the F-INH signal, the motor decelerates and changes to run in negative direction at low speed. After reaching the falling edge of the F-INH signal, the motor stops at the first motor Z signal.

b) Deceleration point signal active at homing start




When homing starts and F-INH=1, the motor directly starts homing in positive direction at low speed. After reaching the falling edge of F-INH signal, motor stops at the first motor Z signal.

3) 6098h=3

Home: motor Z signal

Deceleration point: home switch


a) Deceleration point signal inactive at homing start



When homing starts and ORGP=0, the motor starts homing in positive direction at high speed. After reaching the rising edge of the ORGP signal, the motor decelerates and changes to run in negative direction at low speed. After reaching the falling edge of the ORGP signal, the motor

stops at the first motor Z signal.

b) Deceleration point signal active at homing start




When homing starts and ORGP=1, the motor directly starts homing in positive direction at low speed. After reaching the falling edge of the ORGP signal, the motor stops at the first motor Z signal

4) 6098h=4

Home: motor Z signal

Deceleration point: home switch


a) Deceleration point signal inactive at homing start



When homing starts and ORGP=0, the motor directly starts homing in positive direction at low

speed. After reaching the rising edge of the ORGP signal, motor stops at first motor Z signal.

b) Deceleration point signal active at homing start




When homing starts and ORGP=1, the motor directly starts homing in negative direction at high speed. After reaching the falling edge of the ORGP signal, the motor decelerates and changes to run in negative direction at low speed. After reaching the rising edge of the ORGP signal, the motor stops at the first motor Z signal.

5) 6098h=5

Home: motor Z signal


Deceleration point: home switch

a) Deceleration point signal inactive at homing start



When homing starts and ORGP=0, the motor directly starts homing in negative direction at high speed. After reaching the rising edge of the ORGP signal, the motor decelerates and changes to run in positive direction at low speed. After reaching the falling edge of the ORGP signal, the motor stops at the first motor Z signal.

b) Deceleration point signal active at homing start




When homing starts and ORGP=1, the motor directly starts homing in positive direction at low speed. After reaching the falling edge of the ORGP signal, the motor stops at the first motor Z signal.

6) 6098h=6

Home: motor Z signal


Deceleration point: home switch

a) Deceleration point signal inactive at homing start



When homing starts and ORGP=0, the motor directly starts homing in positive direction at low speed. After reaching the rising edge of the ORGP signal, the motor stops at the first motor Z signal.

b) Deceleration point signal active at homing start




When homing starts and ORGP=1, the motor directly starts homing in positive direction at high speed. After reaching the falling edge of the ORGP signal, the motor decelerates and changes to run in negative direction at low speed. After reaching the rising edge of the ORGP signal, the motor stops at the first motor Z signal.

7) 6098h=7

Home: motor Z signal


Deceleration point: home switch

a) Deceleration point signal inactive at homing start, not reaching positive limit switch




When homing starts and ORGP=0, the motor directly starts homing in positive direction at high speed. If the motor does not reach the limit switch, it decelerates and changes to run in negative direction at low speed after reaching rising edge of the ORGP signal. After reaching falling edge of the ORGP signal, the motor stops at first motor Z signal.

b) Deceleration point signal inactive at homing start, reaching positive limit switch



When homing starts and ORGP=0, the motor directly starts homing in positive direction at high speed. If the motor does not reach the limit switch, it automatically changes to run in negative direction at high speed. After reaching the rising edge of the ORGP signal, the motor decelerates and continues to run in negative direction at low speed. After reaching the falling edge of ORGP signal, the motor stops at first motor Z signal.

c) Deceleration point signal active at homing start




When homing starts and ORGP=1, the motor directly starts homing in negative direction at low speed. After reaching the falling edge of the ORGP signal, the motor stops at the first motor Z signal.

8) 6098h=8

Home: motor Z signal


Deceleration point: home switch

a) Deceleration point signal inactive at homing start, not reaching positive limit switch




When homing starts and ORGP=0, the motor directly starts homing in positive direction at high speed. If the motor does not reach the limit switch, it decelerates and changes to run in negative direction at low speed after reaching the rising edge of the ORGP signal. After reaching the falling edge of the ORGP signal, the motor changes to run in positive direction at low speed. After reaching the rising edge of the ORGP signal, the motor stops at the first motor Z signal.

b) Deceleration point signal inactive at homing start, reaching positive limit switch



When homing starts and ORGP=0, the motor directly starts homing in positive direction at high speed. If the motor reaches the limit switch, it automatically changes to run in negative direction at high speed. After reaching the rising edge of the ORGP signal, the motor decelerates in negative direction at low speed. After reaching the falling edge of the ORGP signal, the motor changes to run in positive direction at low speed. After reaching the rising edge of the ORGP signal, the motor stops at the first motor Z signal.

c) Deceleration point signal active at homing start, not reaching positive limit switch




When homing starts and ORGP=1, the motor directly starts homing in negative direction at low speed. The motor changes to run in positive direction at low speed after reaching the falling edge of the ORGP signal. After reaching the rising edge of the ORGP signal, the motor stops at the first motor Z signal.

9) 6098h=9

Home: motor Z signal


Deceleration point: home switch

a) Deceleration point signal inactive at homing start, not reaching positive limit switch




When homing starts and ORGP=0, the motor directly starts homing in positive direction at high speed. If the motor does not reach the limit switch, the motor decelerates in positive direction at low speed after reaching the rising edge of the ORGP signal. After reaching the falling edge of the ORGP signal, the motor changes to run in positive direction at low speed. After reaching the rising edge of the ORGP signal, the motor stops at the first motor Z signal.

b) Deceleration point signal inactive at homing start, reaching positive limit switch



When homing starts and ORGP=0, the motor directly starts homing in positive direction at high speed. If the motor reaches the limit switch, it automatically changes to run in negative direction at high speed. After reaching the rising edge of the ORGP signal, the motor decelerates in positive direction at low speed. After reaching the falling edge of the ORGP signal, the motor changes to run in negative direction at low speed. After reaching the rising edge of the ORGP signal, the motor stops at the first motor Z signal.

c) Deceleration point signal active at homing start



When homing starts and ORGP=1, the motor directly starts homing in positive direction at low


speed. After reaching the falling edge of the ORGP signal, the motor changes to run in negative direction at low speed. After reaching the rising edge of the ORGP signal, the motor stops at the first motor Z signal

10) 6098h=10

Home: motor Z signal


Deceleration point: home switch

a) Deceleration point signal inactive at homing start, not reaching positive limit switch




When homing starts and ORGP=0, the motor directly starts homing in positive direction at high speed. If the motor does not reach the limit switch, the motor decelerates in positive direction at low speed after reaching the rising edge of the ORGP signal. After reaching the falling edge of the ORGP signal, the motor continues running in positive direction at low speed and the motor stops at the first motor Z signal.

b) Deceleration point signal inactive at homing start, reaching positive limit switch



When homing starts and ORGP=0, the motor directly starts homing in positive direction at high speed. If the motor reaches the limit switch, it automatically changes to run in negative direction at high speed. After reaching the rising edge of the ORGP signal, the motor decelerates and resumes to run in positive direction at low speed. After reaching the falling edge of the ORGP signal, the motor stops at the first motor Z signal.

c) Deceleration point signal active at homing start




When homing starts and ORGP=1, and the motor directly starts homing in positive direction at low speed. After reaching the falling edge of the ORGP signal, the motor stops at the first motor Z signal.

11) 6098h=11

Home: motor Z signal


Deceleration point: home switch

a) Deceleration point signal inactive at homing start, not reaching negative limit switch



When homing starts and ORGP=0, the motor directly starts homing in negative direction at high speed. If the motor does not reach the limit switch, the motor decelerates and runs in negative direction at low speed after reaching the rising edge of the ORGP signal. After reaching the falling edge of ORGP signal, the motor stops at first motor Z signal.


b) Deceleration point signal inactive at homing start, reaching negative limit switch



When homing starts and ORGP=0, the motor directly starts homing in negative direction at high speed. If the motor reaches the limit switch, the motor automatically changes to run in positive direction at high speed. After reaching the rising edge of the ORGP signal, the motor decelerates and continues to run in negative direction at low speed. After reaching the falling edge of the

ORGP signal, the motor stops at the first motor Z signal.

c) Deceleration point signal active at homing start




When homing starts and ORGP=1, and the motor directly starts homing in positive direction at low speed. After reaching the falling edge of the ORGP signal, the motor stops at the first motor Z signal.

12) 6098h=12

Home: motor Z signal


Deceleration point: home switch

a) Deceleration point signal inactive at homing start, not reaching negative limit switch




When homing starts and ORGP=0, the motor starts homing in negative direction at high speed. If the motor does not reach the limit switch, the motor decelerates and changes to run in positive direction at low speed after reaching the rising edge of the ORGP signal. After reaching the falling edge of the ORGP signal, the motor changes to run in negative direction at low speed. After reaching the rising edge of the ORGP signal, the motor stops at the first motor Z signal.

b) Deceleration point signal inactive at homing start, reaching positive limit switch



When homing starts and ORGP=0, the motor starts homing in negative direction at high speed. If the motor reaches the limit switch, the motor automatically changes to run in positive direction at high speed. After reaching the rising edge of the ORGP signal, the motor decelerates and runs in positive direction at low speed. After reaching the falling edge of the ORGP signal, the motor changes to run in negative direction at low speed. After reaching the rising edge of ORGP signal, the motor stops at first motor Z signal.

c) Deceleration point signal active at homing start




When homing starts and ORGP=1, the motor starts homing in positive direction at low speed. After reaching the falling edge of the ORGP signal, the motor changes to run in negative direction at low speed. After reaching the rising edge of the ORGP signal, the motor stops at the first motor Z signal.

13) 6098h=13

Home: motor Z signal


Deceleration point: home switch

b) Deceleration point signal inactive at homing start, not reaching negative limit switch




When homing starts and ORGP=0, the motor starts homing in negative direction at high speed. If the motor does not reach the limit switch, the motor decelerates and runs in negative direction at low speed after reaching the rising edge of the ORGP signal. After reaching the falling edge of the ORGP signal, the motor changes to run in positive direction at low speed. After reaching the rising edge of the ORGP signal, the motor stops at the first motor Z signal.

c) Deceleration point signal inactive at homing start, reaching negative limit switch



When homing starts and ORGP=0, the motor starts homing in negative direction at high speed. If the motor reaches the limit switch, the motor automatically changes the direction and runs in positive direction at high speed. After reaching the rising edge of the ORGP signal, the motor decelerates and changes to run in positive direction at low speed. After reaching the falling edge of the ORGP signal, the motor changes to run in positive direction at low speed. After reaching the rising edge of the OPGP signal, the motor stops at the first motor Z signal.

c) Deceleration point signal active at homing start




When homing starts and ORGP=1, the motor directly starts homing in positive direction at low speed. After reaching the falling edge of the ORGP signal, the motor changes to run in positive direction at low speed. After reaching the rising edge of ORGP signal, motor stops at first motor Z signal.

14) 6098h=14

Home: motor Z signal

Deceleration point: home switch


a) Deceleration point signal inactive at homing start, not reaching negative limit switch



When homing starts and ORGP=0, the motor starts homing in negative direction at high speed. If the motor does not reach the limit switch, the motor decelerates and runs in negative direction at low speed after reaching the rising edge of the ORGP signal. After reaching the falling edge


of the ORGP signal, the motor continues to run in negative direction at low speed, then the motor stops at the first motor Z signal.

b) Deceleration point signal inactive at homing start, reaching negative limit switch



When homing starts and ORGP=0, the motor starts homing in negative direction at high speed. If the motor reaches the limit switch, the motor automatically changes the direction and runs in positive direction at high speed. The motor decelerates and runs in negative direction at low speed after reaching the rising edge of the ORGP signal. After reaching the falling edge of the ORGP signal, the motor stops at the first motor Z signal.

c) Deceleration point signal active at homing start




When homing starts and ORGP=1, the motor starts homing in negative direction at low speed. After reaching the falling edge of the ORGP signal, the motor stops at the first motor Z signal.

15) 6098h=17

Home: negative limit switch


Deceleration point: negative limit switch

a) Deceleration point signal inactive at homing start



The R-INH signal is inactive initially. The motor starts homing in negative direction at high speed. After reaching the rising edge of the R-INH signal, the motor decelerates and changes to run in positive direction at low speed. After reaching the falling edge of the R-INH signal, the motor stops.

b) Deceleration point signal active at homing start




The R-INH signal is active initially, and the motor directly starts homing in positive direction at low speed.

After reaching the falling edge of the R-INH signal, the motor stops.

16) 6098h=18

Home: positive limit switch


Deceleration point: positive limit switch



The F-INH signal is inactive initially. The motor starts homing in positive direction at high speed.

After reaching the rising edge of the F-INH signal, the motor decelerates and changes to run in negative direction at low speed. After reaching the falling edge of the F-INH signal, the motor stops.

b) Deceleration point signal active at homing start



The F-INH signal is active initially, and the motor directly starts homing in negative direction at low speed.


After reaching the falling edge of the F-INH signal, the motor stops.

17) 6098h=19

Home: home switch


Deceleration point: home switch

a) Deceleration point signal inactive at homing start



The ORGP signal is inactive initially. The motor starts homing in positive direction at high speed. After reaching the rising edge of the ORGP signal, the motor decelerates and changes to run in negative direction at low speed. After reaching the falling edge of the ORGP signal, the motor stops.

b) Deceleration point signal active at homing start




The ORGP signal is active initially, and the motor directly starts homing in negative direction at low speed.

After reaching the falling edge of the ORGP signal, the motor stops.

18) **6098h=20 Home:** home switch


Deceleration point: home switch



The ORGP signal is inactive initially, and the motor starts homing in positive direction at low speed.

After reaching the rising edge of the ORGP signal, the motor stops.

b) Deceleration point signal active at homing start




The ORGP signal is active initially. The motor starts homing in negative direction at high speed. After reaching the falling edge of the ORGP signal, the motor decelerates and changes to run in positive direction at low speed.

After reaching the rising edge of the ORGP signal, the motor stops.

19) 6098h=21


Home: home switch

Deceleration point: home switch



The ORGP signal is inactive initially. The motor starts homing in negative direction at high speed. After reaching the rising edge of the ORGP signal, the motor decelerates and changes to run in positive direction at low speed. After reaching the falling edge of the ORGP signal, the motor stops.

b) Deceleration point signal active at homing start




The ORGP signal is active initially, and the motor directly starts homing in positive direction at low speed.

After reaching the falling edge of the ORGP signal, the motor stops.

20) 6098h=22

Home: home switch


Deceleration point: home switch



The ORGP signal is inactive initially, and the motor directly starts homing in negative direction at low speed.

After reaching the rising edge of the ORGP signal, the motor stops.

b) Deceleration point signal active at homing start




The ORGP signal is active initially. The motor starts homing in positive direction at high speed. After reaching the falling edge of the ORGP signal, the motor decelerates and changes to run in negative direction at low speed. After reaching the rising edge of the ORGP signal, the motor stops.

21) 6098h=23 **Home:** home switch


Deceleration point: home switch

a) Deceleration point signal inactive at homing start, not reaching positive limit switch



The ORGP signal is inactive initially. The motor starts homing in positive direction at high speed. If the motor does not reach the limit switch, it decelerates and changes to run in negative direction at low speed after reaching the rising edge of the ORGP signal. After reaching the falling edge of the ORGP signal, the motor stops.


b) Deceleration point signal inactive at homing start, reaching positive limit switch



The ORGP signal is inactive initially, and the motor starts homing in positive direction at high speed. If the motor reaches the limit switch, it automatically changes to run in negative direction at high speed. After reaching the rising edge of the ORGP signal, the motor decelerates and

continues to run in negative direction at low speed. After reaching the falling edge of the ORGP signal, the motor stops.

c) Deceleration point signal active at homing start



The ORGP signal is active initially, and the motor directly starts homing in negative direction at low speed.


After reaching the falling edge of the ORGP signal, the motor stops.

22) 6098h=24

Home: home switch

Deceleration point: home switch

a) Deceleration point signal inactive at homing start, not reaching positive limit switch




The ORGP signal is inactive initially, and the motor starts homing in positive direction at high speed.

If the motor does not reach the limit switch, it decelerates and changes to run in negative direction at low speed after reaching the rising edge of the ORGP signal. After reaching the falling edge of the ORGP signal, the motor changes to run in positive direction at low speed,

and stops at the rising edge of the ORGP signal.

c) Deceleration point signal inactive at homing start, reaching positive limit switch




The ORGP signal is inactive initially, and the motor starts homing in positive direction at high speed.

If the motor reaches the limit switch, it automatically changes to run in negative direction at high speed.

After reaching the rising edge of the ORGP signal, the motor decelerates and continues to run in negative direction at low speed. After reaching the falling edge of the ORGP signal, the motor changes to run in positive direction at low speed, and stops at the rising edge of the ORGP signal.

c) Deceleration point signal active at homing start



The ORGP signal is active initially, and the motor directly starts homing in negative direction at

low speed.

After reaching the falling edge of the ORGP signal, the motor changes to run in positive direction at low speed.


After reaching the rising edge of the ORGP signal, the motor stops.

23) 6098h=25

Home: home switch


Deceleration point: home switch

a) Deceleration point signal inactive at homing start, not reaching positive limit switch




The ORGP signal is inactive initially, and the motor starts homing in positive direction at high speed. If the motor does not reach the limit switch, it decelerates and continues to run in positive direction at low speed after reaching the rising edge of the ORGP signal. After reaching the falling edge of the ORGP signal, the motor changes to run in negative direction at low speed, and stops at the rising edge of the ORGP signal.

b) . Deceleration point signal inactive at homing start, reaching positive limit switch



The ORGP signal is inactive initially, and the motor starts homing in positive direction at high speed. If the motor reaches the limit switch, it automatically changes to run in negative direction at high speed. After reaching the rising edge of the ORGP signal, the motor decelerates and resumes to run in positive direction at low speed. After reaching the falling edge of the ORGP signal, the motor changes to run in negative direction at low speed, and stops at the rising edge of the ORGP signal.

c) Deceleration point signal active at homing start



The ORGP signal is active initially, and the motor directly starts homing in positive direction at low speed.

After reaching the falling edge of the ORGP signal, the motor changes to run in negative direction at low speed.


After reaching the rising edge of the ORGP signal, the motor stops.

24) 6098h=26

Home: home switch


Deceleration point: home switch

a) Deceleration point signal inactive at homing start, not reaching positive limit switch



The ORGP signal is inactive initially. The motor starts homing in positive direction at high speed. If the motor does not reach the limit switch, it decelerates and continues to run in positive direction at low speed after reaching the rising edge of the ORGP signal. After reaching the falling edge of the ORGP signal, the motor stops.


b) Deceleration point signal inactive at homing start, reaching positive limit switch



The ORGP signal is inactive initially, and the motor starts homing in positive direction at high speed. If the motor reaches the limit switch, it automatically changes to run in negative direction at high speed. After reaching the rising edge of the ORGP signal, the motor decelerates and

resumes to run in positive direction at low speed. After reaching the falling edge of the ORGP signal, the motor stops.

c) Deceleration point signal active at homing start



The ORGP signal is active initially, and the motor directly starts homing in positive direction at low speed.


After reaching the falling edge of the ORGP signal, the motor stops.

25) 6098h=27

Home: home switch

Deceleration point: home switch


a) Deceleration point signal inactive at homing start



The ORGP signal is inactive initially. The motor starts homing in negative direction at high speed. If the motor does not reach the limit switch, it decelerates and changes to run in positive


direction at low speed after reaching the rising edge of the ORGP signal. After reaching the falling edge of the ORGP signal, the motor stops.

b) Deceleration point signal inactive at homing start, reaching negative limit switch



The ORGP signal is inactive initially, and the motor starts homing in negative direction at high speed. If the motor reaches the limit switch, it automatically changes to run in positive direction at high speed. After reaching the rising edge of the ORGP signal, the motor decelerates and continues to run in positive direction at low speed. After reaching the falling edge of the ORGP signal, the motor stops.

c) Deceleration point signal active at homing start




The ORGP signal is active initially, and the motor directly starts homing in positive direction at low speed.

After reaching the falling edge of the ORGP signal, the motor stops.

26) 6098h=28 **Home:** home switch


Deceleration point: home switch

a) Deceleration point signal inactive at homing start




The ORGP signal is inactive initially, and the motor starts homing in negative direction at high speed. If the motor does not reach the limit switch, it decelerates and changes to run in positive direction at low speed after reaching the rising edge of the ORGP signal. After reaching the falling edge of the ORGP signal, the motor changes to run in negative direction at low speed, and stops at the rising edge of the ORGP signal.

b) Deceleration point signal inactive at homing start, reaching positive limit switch



The ORGP signal is inactive initially, and the motor starts homing in negative direction at high speed. If the motor reaches the limit switch, it automatically changes to run in positive direction at high speed. After reaching the rising edge of the ORGP signal, the motor decelerates and continues to run in positive direction at low speed. After reaching the falling edge of the ORGP signal, the motor changes to run in negative direction at low speed, and stops at the rising edge of the ORGP signal.




The ORGP signal is active initially, and motor directly starts homing in positive direction at low speed. After reaching the falling edge of the ORGP signal, the motor changes to run in negative direction at low speed. After reaching the rising edge of the ORGP signal, the motor stops.

27) 6098h=29

Home: home switch


Deceleration point: home switch

a) Deceleration point signal inactive at homing start, not reaching negative limit switch




The ORGP signal is inactive initially, and the motor starts homing in negative direction at high speed. If the motor does not reach the limit switch, it decelerates and continues to run in negative direction at low speed after reaching the rising edge of the ORGP signal. After reaching the falling edge of the ORGP signal, the motor changes to run in positive direction at low speed, and stops at the rising edge of the ORGP signal.

b) Deceleration point signal inactive at homing start, reaching negative limit switch



The ORGP signal is inactive initially, and the motor starts homing in negative direction at high speed. If the motor reaches the limit switch, it automatically changes to run in positive direction at high speed. After reaching the rising edge of the ORGP signal, the motor decelerates and changes to run in negative direction at low speed. After reaching the falling edge of the ORGP signal, the motor changes to run in positive direction at low speed, and stops at the rising edge of the ORGP signal.

c) Deceleration point signal active at homing start



The ORGP signal is active initially, and the motor directly starts homing in negative direction at low speed.


After reaching the falling edge of the ORGP signal, the motor changes to run in positive direction at low speed.

After reaching the rising edge of the ORGP signal, the motor stops.

28) 6098h=30


Home: home switch

Deceleration point: home switch




The ORGP signal is inactive initially. The motor starts homing in negative direction at high speed. If the motor does not reach the limit switch, it decelerates and continues to run in negative direction at low speed after reaching the rising edge of the ORGP signal. After reaching the falling edge of the ORGP signal, the motor stops.

b) Deceleration point signal inactive at homing start, reaching negative limit switch



The ORGP signal is inactive initially, and the motor starts homing in negative direction at high speed. If the motor reaches the limit switch, it automatically changes to run in positive direction at high speed. After reaching the rising edge of the ORGP signal, the motor decelerates and changes to run in negative direction at low speed.

After reaching the falling edge of the ORGP signal, the motor stops.



The ORGP signal is active initially, and the motor directly starts homing in negative direction at low speed.

After reaching the falling edge of the ORGP signal, the motor stops.

29) 6098h=31-32

These modes are not defined in CiA402.


30) 6098h=33-34

Home: Z signal

Deceleration point: None

Homing method 33: The motor runs in negative direction at low speed, and stops at the first motor Z signal.

Homing method 34: The motor runs in positive direction at low speed, and stops at the first motor Z signal.



31) 6098h=35

The current position is the home. The motor starts homing after the homing signal is triggered.

32) 6098h=-1

Motor starts homing after the homing signal is triggered, which mechanical home is recorded when 6098h=35.

7.9.4 Recommended configuration

RPDO	TPDO	Remark

6040h: control word	6041h: status word	Required
6098h: Homing method		Optional
609Ah: Homing acceleration		Optional
	6064h: position actual value	Optional
6060h: modes of operation	6061h: Modes of operation display	Optional

7.10 Auxiliary Function

Servo drives supply auxiliary function in order to make sure system work correctly.

7.10.1 Setting password

10.1 Detting pa	35 W OI U				
	Setting password PP PV PT CSP CSV CST HM. (Avoid modifying parameters by mistake)				
2008h-02h	Setting range Setting unit Mfr's value When enabled				
200011-0211	0~9999	999 N/A 0 Restart			
	Function code	Mapping	Data type	Accessibility	
	So-01	N	UINT16	RW	

Setting password is used to avoid modifying parameters by mistake. The mfr's value is 0, which means password is invalid and users can modify parameters anytime. If users want to use this function, please set a password for this parameter and restart servo, then this function is valid. Except monitor function parameters, most auxiliary function and main function parameters can be modified when the password is input into this parameter. If password is not input, err will occur. Master station is used to operate SDO to return to stop code.

7.10.2 Servo drive status display

10.2 Servo drive status display					
	Servo drive statu	CSV CST HM			
	Setting range	Setting unit	Mfr's value	When enabled	
2008h-0Ah	0~38	N/A	2	Immediate	
	Function code	Mapping	Data type	Accessibility	
	So-09	N	UINT16	RW	

Setting value	Definition	Setting value	Definition
0	Servo drive output current	14	DI8~DI5 status display
1	Servo drive bus voltage	15	DI4~DI1status display
2	Servo motor rotating speed	16	Other output interface status display
3	Servo motor feedback pulse displays high 5 digits.	17	DO4~DO1 status display
4	Servo motor feedback pulse displays low 5 digits	18	Drive current temperature display
5	Servo motor feedback speed displays high 5 digits	19	Rotating inertia display

6	Servo motor feedback speed displays low 5 digits	20	Output torque display
7	Given command pulse numbers display high 5digits	21	Current gain group
8	Given command pulse numbers display low 5 digits	22	Discharge time
9	Given command pulse error numbers	23	Encoder absolute position high digit pulse
10	Given speed	24	Encoder absolute position low digit pulse
11	Given torque	25	High 5 digits of number of turns of encoder absolute position
12	Reserved	26	Low 5 digits of number of turns of encoder absolute position
13	Reserved	27-37	Reserved

The parameter is to set default display content in keypad. Refer to next table about the display item:

7.10.3 Fan setting


	Fan control	PP PV	PT CSP CS	V CST HM
	Setting range	Setting unit	Mfr's value	When enabled
	0~2	N/A	2	Immediate
2008h-1Bh	Function code	Mapping	Data type	Accessibility
	So-26	N	UINT16	RW
	0: Fan is controlled by temperature.			
	1: As soon as power on, fan starts to run.			
	2: Fan is controlled by servo drive			

So-26=0, when radiator temperature reaches setting temperature, fan starts to run; when radiator temperature is lower than So-27-5°C, fan stops running.

So-26=2, fan starts to run when servo drive is running or temperature is higher than 45° C; When servo drive is stopped or radiator temperature is lower than 40° C;, fan will keep running for 500ms before stop.

	Fan temperature setting PP PV PT CSP CSV CST HM				
	Setting range	Setting unit	Mfr's value	When enabled	
2008h-1Ch	10~100	°C	45	Immediate	
	Function code	Mapping	Data type	Accessibility	
	So-27	N	UINT16	RW	

7.10.4 Parameter copy



7.10.5 Reverting to Mfr's Value

When there is disorder with parameters, mfr's value needs to be reset.

Related Parameters

	Reverting to Mfr	's value PP PV	PT CSP CSV	CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
2008h-32h	0~1	N/A	0	Restart
	Function code	Mapping	Data type	Accessibility
	So-49	N	UINT16	RW

The procedure is: set So-49=1 and holding press SET key for 0.5s, "00000" is displayed. After 5 seconds, all parameters revert to mfr's value automatically.

7.10.6 Motor Protection Function

(1) Motor Overload Protection

Servo motor output current continuously generates heat, and releases heat into surroundings.

When generated heat is more than released heat, motor temperature will rise. Over-high temperature can lead to motor excitation-loss and damage. Servo drive provides motor overload protection in case of over-high temperature.

Setting motor overload protection (2008h-26h) can set motor overload fault (AL-06) time. In general, 2008h-26h remains default value. Under below condition, 2008h-26h can be modified by motor heating state.

- the occasion of higher operating ambient temperature for servo motor;
- the occasion that servo motor runs circularly, one-time motion period is short and frequent switching;

(1) Related Parameter

	Motor overload c	oefficient setting	PP PV PT CSP	CSV CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
2008h-26h	1~500	%	100	Immediate
	Function code	Mapping	Data type	Accessibility
	So-37	N	UINT16	RW




Fig 7.10.1Motor overload curve and alarm time curve graph

(2) Motor lock-rotor protection

Motor speed is almost 0 when servo-motor lock-rotor occurs, but actual current is very high, servo drive and servo motor may be damaged because of long time lock-rotor, therefore, servo drive provides the motor lock-rotor protection to prevent the damage from excessive temperature in the situation of motor lock-rotor.

Related Parameter

	Motor lock-rotor protection PP PV PT CSP CSV CST			
2008h-23h	Setting Range	Setting Unit	Mfr's Value	Effect
200611-2511	0~1	N/A	1	Immediate
	Function code	Mapping	Data type	Accessibility

	So-34	N	UINT16	RW
	Delay time of lock-rotor protection PP PV PT CSP CSV CST HM			
	Setting Range	Setting Unit	Mfr's Value	Effect
2008h-29h	10~1000	10ms	100	Immediate
	Function code	Mapping	Data type	Accessibility
	So-40	N	UINT16	RW

(3) Motor overheat protection

	Motor overheat protection PP PV PT CSP CSV CST HM			
	Setting range Setting unit		Mfr's value	When enabled
2008h-33h	0~1	N/A	0	Immediate
200611-3311	Function code	Mapping	Data type	Accessibility
	So-50	N	UINT16	RW
	0: Invalid 1: Valid			

	Motor disconnected protection of temperature detection				
PP V PT CSP CSV CST HM					
	Setting range	Setting unit	Mfr's value	When enabled	
2008h-34h	0~1	N/A	1	Immediate	
	Function code	Mapping	Data type	Accessibility	
	So-51	N	UINT16	RW	
	0: Invalid 1: Valid				

7.10.7 DI Terminals Filter Function

Servo drive has 8 DI terminals.

DI terminal filter setting: if terminal signal has interference, users can carry on filter processing by setting 2008h-27h $\sim\!2008\text{h-}2E\text{h}$.

	DI1 filter time	PP PV I	PT CSP CSV	CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
2008h-27h	0~30000	N/A	2	Immediate
	Function code	Mapping	Data type	Accessibility
	Po438	N	UINT16	RW
2008h-28h	DI2 filter time	PP PV I	PT CSP CSV	CST HM

	Setting Range	Setting Unit	Mfr's Value	Effect
	0~30000	N/A	2	Immediate
	Function code	Mapping	Data type	Accessibility
	Po439	N	UINT16	RW
	DI3 filter time	PP PV I	PT CSP CSV	CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
2008h-29h	0~30000	N/A	2	Immediate
	Function code	Mapping	Data type	Accessibility
	Po440	N	UINT16	RW
	DI4 filter time	PP PV	PT CSP CS	V CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
2008h-2Ah	0~30000	N/A	2	Immediate
	Function code	Mapping	Data type	Accessibility
	Po441	N	UINT16	RW
	DI5 filter time	PP PV P	T CSP CSV	CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
2008h-2Bh	0~30000	N/A	2	Immediate
	Function code	Mapping	Data type	Accessibility
	Po442	N	UINT16	RW
	DI6 filter time	PP PV P	CSP CSV	CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
2008h-2Ch	0~30000	N/A	2	Immediate
	Function code	Mapping	Data type	Accessibility
	Po443	N	UINT16	RW
	DI7 filter time	PP PV PT	CSP CSV	CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
2008h-2Dh	0~30000	N/A	2	Immediate
	Function code	Mapping	Data type	Accessibility
	Po444	N	UINT16	RW
	DI8 filter time	PP PV	PT CSP CSV CS	ГНМ
2000h 2Eh	Setting Range	Setting Unit	Mfr's Value	Effect
2008h-2Eh	0~30000	N/A	2	Immediate
	Function code	Mapping	Data type	Accessibility

D 445	N.T.	I III ITTI C	DW
Po445	N	UINT16	RW

7.10.8 Touch probe function

Touch probe function is position latch function, which can latch position when DI or motor Z signal is changing.

1) Related objects

Index	Sub- index	Name	Access	Data type	Unit	Setting Range	Mfr's Value
2004h	0Eh	DI7terminal function	RW	UINT16	-	Two- parameter	d1 34
2004h	0Fh	DI8 terminal function	RW	UINT16	-	Two- parameter	d1 35
60B8h	00h	Touch probe function	RW	UINT16		0~ 65535	0
60B9h	00h	Touch probe state	RO	UINT16		-	
60BAh	00h	Touch probe pos1 position value	RO	DINT	Command unit	-	0
60BBh	00h	Touch probe neg1 position value	RO	DINT	Command unit	-	0
60BCh	00h	Touch probe pos2 position value	RO	DINT	Command unit	-	0
60BDh	00h	Touch probe neg2 position value	RO	DINT	Command unit	-	0

2) Set touch probe (60B8h)

Definition for each bit:

Bit	Definition	
0	Touch probe 1 setting 0—disabled; 1—enabled	
1	Touch probe 1 trigger mode 0—single-shot trigger, only trigger when trigger signal is value for the first time 1—continue trigger	Bit0-bit5: Touch probe 1 setting
2	Touch probe 1 signal 0—DI7; 1—Z signal	

4	Touch probe pos1 0—not latch; 1—latch	
5	Touch probe neg1	
3	0—not latch; 1—latch	
8	Touch probe 2 setting	
0	0 disabled; 1—enabled	
	Touch probe 2 trigger mode	
9	0—single-shot trigger, only trigger when trigger signa is	
9	value for the first time	
	1—continue trigger	Bit8-bit13: Touch
10	Touch probe 2 signal	probe 2 setting
10	0—DI8; 1—Z signal	
12	Touch probe pos 2	
12	0—not latch; 1—latch	
13	Touch probe neg 2	
13	0—not latch; 1—latch	

3) Set touch probe (60B9h)

Bit	Definition	
0	Touch probe 1 setting	
U	0—disabled; 1—enabled	
1	Touch probe pos1	
1	1—not latch; 1—latch	DitO hit5 Touch much a 1
2	Touch probe 2 setting	Bit0-bit5: Touch probe 1
2	0 disabled; 1—enabled	setting Bit8-bit13: Touch probe 2
8	Touch probe 2 setting	
0	0 disabled; 1—enabled	setting
9	Touch probe pos 2	
9	0—not latch; 1—latch	
10	Touch probe neg 2	
10	0—not latch; 1—latch	

7.10.9 Digital I/O signal function

Digital signal includes input (DI) and output (DO) signal. User can use keypad or (PLC /PC communication) to set DI, DO function and terminal logic. So PC/PLC can control servo drive by DI terminal, or servo drive DO signal is applied by PC/PLC.

Besides, servo drive has mandatory I/O function, mandatory DI input can be used to test drive DI function, mandatory DO output can be used to check the connection between PC/PLC and drive DO signal.

1) DI signal mandatory input

When the function is valid, every DI signal is only controlled by mandatory input 2008h-3Ah (So-57), not related to external DI signal.

	Name	Forced i	nput setting	of DI	setting	_	Mode	ALL
Sub-index	unit	N/A	Range	0~255	effect	Immediate	Mfr's value	0
3Ah	parameter	So-57	Access	RW	Mapping	N	Data type	UINT16
This do	This data represents the aureant terminal status, see datails in Chapter 7 10 0							

This data represents the current terminal status, see details in Chapter 7.10.9

Operation process

- 2. Set DI function and logic referring to PO407-Po414
- 3. Set So-58, select mandatory DI or DO
- 4. Set So-57, set mandatory DI high level and low level.
- 5. Monitor DI terminal level by Lo-14, Lo-15

Related parameter:

	Forced input setting of DI PP PV PT CSP CSV CST HM				
	Setting Range	Setting Unit	Mfr's Value	Effect	
2008h-3Ah	-	N/A	0	Immediate	
	Function code	Mapping	Data type	Accessibility	
	So-57	N	UINT16	RW	

2008h-3Ah (So-57) setting value is decimal, convert it to 8 bit binary number, which is corresponding to DI1-DI8 (high bit is ahead, low bit is after). For example, if mandatory DI1ouput is required, binary number of DI1-DI8 is 00000001; corresponding decimal number is 1, just set 2008h-3Ah (So-57) as 1 of decimal.

	Overload pre-alar	rm filter time	PP PV PT CSP CSV CST HM		
	Setting Range	Setting Unit	Mfr's Value	Effect	
2008h-3Bh	-	N/A	d 0 0	Immediate	
	Function code	Mapping	Data type	Accessibility	
	So-58	N	UINT16	RW	

The parameter setting format of 2008h-3Bh as below:



Master station can monitor DI state by reading 60FDh bit state.

60FDh definition is as following table:

Table 7.10.1 60FDh definition

Bit	definition		
0	Reverse run prohibited		
1	Forward run prohibited		
2	Home switch		
3-15	Reserved		
16-23	DI8-DI1		
25-31	Reserved		

Quit function

DI signal mandatory input is not remembered in the face of power loss; restart can return to normal DI, setting So-58 also can quit mandatory DI function.

2) DO signal mandatory output

Operation process

- 1. Set DO function and logic referring to PO421-Po425
- 2. Set So-58, select mandatory DO
- 3. Set DO referring to 60Feh definition
- 4. Monitor DO terminal level by Lo-16, Lo-17

Ouit function

DO signal mandatory output is not remembered in the face of power loss, restart can return to normal DO, setting So-58 also can return to normal DO function.

Table 7.10.2 60FEh definition

Bit	Definition		
0	Brake	Brake	
1-15	Reserved		
16-19	DO1-DO4		
20	Alarm		
21-24	Reserved		

Terminal output state is set by setting corresponding bit. If one of Bit16- Bit19 is set brake function, Bit 0 is prior.

7.10.10 Other Output Signals

(1) Servo Alarm Terminal Output

ALM is activated when the servo drive has detected a fault condition. ON signal is output when

servo works well, OFF signal is output when there is a malfunction.

Signal Name	Name	Terminals	Remarks
Servo Alarm	ALM	ALM-	Servo alarm output signal, can provide
Output	ALM	ALM+	failure indication

(2) Servo Ready Output

Signal Name	Name	Terminals	Remarks	
SRDY	SRDY	SRDY+	Comic modely output	
		SRDY-	Servo ready output	

Output ON means that the servo drive is ready to receive signal, control circuit and main circuit power supply are normal, there is no servo alarms. Output OFF means that servo drive is not ready.

• Overload pre-alarm signal output

When servo output current reaches or exceeds overload pre-alarm current, and after overload pre-alarm filter time, the output current still reachers or higher than pre-alarm current, then this signal is output.

Signal Name	Default terminal	Remarks
OL-W	Allocated by users	Pre-alarm signal of overload

Related parameters:

	Overload pre-alarm current PP PV PT CSP CSV CST HM			
	Setting Range	Setting Unit	Mfr's Value	Effect
2008h-24h	0~800	%	120	Immediate
	Function code	Mapping	Data type	Accessibility
	So-35	N	UINT16	RW
	Overload pre-al	larm filter time	PP PV PT CSP	CSV CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
2008h-25h	0~1000	10ms	10	Power on again
	Function code	Mapping	Data type	Accessibility
	So-36	N	UINT16	RW

• Signal output in speed limit

When rotate speed is limited, DO outputs this signal, and not related to motor rotation but valid for forward/reverse .It should allocate 1 DO terminal(speed limiting) to servo drive and set DO terminal logic.




Fig 7.10.2 Output in speed limit under torque mode sketch map

VIII. Object dictionary and parameter list

8.1 Object dictionary classification

Object dictionary is most important part in equipment specifications, which is a set of parameters and variables. Object dictionary includes equipment description and all parameters of network state. It can be accessed by sequential predefined method.

Servo drive object has below items:

Index
Data type
Mapping
Mode
Mfr's value

Sub-index
Accessibility
Setting method
Setting range
Function code

★Word explanation:

In parameter list, object dictionary address is assigned by index and sub-index. Index assigns the address of objects of the same type, represented by hexadecimal. Sub-index assigns each object address under the same index.

Data type: Refer to below table:

Data type	Setting range	length	DS301vaule
SINT8	-128~+127	1byte	0002h
INT16	-32768~+32767	2 bytes	0003h
DINT32	-2147483647~+2147483647	4 bytes	0004h
UINT8	0~255	1 byte	0005h
UINT16	0~65535	2 bytes	0006h
UDINT32	0~4294967295	4 bytes	0007h
STRING	ASCII	_	0009h

Accessibility: Refer to below table:

Accessibility	Definition
RW	Read-write
WO	Write only
RO	Read only
CONST	Constant, read only

Mapping: Refer to below table:

Mapping	Definition
NO	No mapping in PDO
RPDO	Write only
TPDO	Read only

Master station sets parameter by SDO.

If setting value is larger than upper limit, drive returns to abort message 13h.

If setting value is smaller than lower limit, drive returns to abort message 14h.

If user modifies parameter that is not allowed to be modified in running state, drive returns to 1Ah.

If user password is not entered, drive returns to abort message 19h.

8.2 Communication parameter (1000h~1FFFh)

	Device type	PP PV P	CSP CSV	CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
Index 1000h	N/A	N/A	00020192h	
	Function code	Mapping	Data type	Accessibility
		N	UDINT32	RO
	Error register	PP PV P	CSP CSV	CST HM
Index 1001h	Setting Range	Setting Unit	Mfr's Value	Effect
	N/A	N/A		_

	Function code	Mapping		Data type		Accessi	bility
		N		USINT8		RO	
	Hardware versio	n PP P	V	PT CSP	CSV	/ CST	HM
	Setting Range	Setting Ur	nit	Mfr's V	Value	Effe	ct
Index 1009h	N/A	N/A		_	-		-
	Function code	Mapping	,	Data 1	ype	Accessi	bility
		N		STRIN	IG24	RC)
	Software version	n PP PV	I	PT CSP	CSV	CST	HM
	Setting Range	Setting Ur	nit	Mfr's V	Value	Effe	ct
Index 100Ah	N/A	N/A		_	=		=
	Function code	Mapping	;	Data 1	ype	Accessi	bility
	So-00	N		STRIN	IG40	RC)
	Vendor ID	PP PV	F	CSF	CSV	CST	HM
Index	Setting Range	Setting Unit		Mfr's Value		Effe	ct
1018h-01h	N/A	N/A		768h			=
101011-0111	Function code	Mapping		Data type		Accessi	bility
	_	N		UDINT32		RC)
	Product code	PP PV	PT	CSP	CSV	CST	HM
Index	Setting Range	Setting Unit		Mfr's V	<i>V</i> alue	Effe	ct
1018h-02h	N/A	N/A		1h	l		-
101011-0211	Function code	Mapping	,	Data type		Accessi	bility
	_	N		UDIN	T32	RC	
	Revision	PP PV	Р7	CSP	CSV	CST	HM
Index	Setting Range	Setting Ur	it	Mfr's V	Value	Effe	ct
1018h-03h	N/A	N/A		64	h		-
101011 0011	Function code	Mapping	,	Data 1	ype	Accessi	bility
		N		UDIN		RC	
	Serial Number	PP PV	PT		CSV		HM
Index	Setting Range	Setting Ur	it	Mfr's V		Effe	ct
1018h-04h	N/A	N/A		011	h		-
101011 0 111	Function code	Mapping	,	Data 1		Accessi	bility
	_	N		UDIN	T32	RC)

	Communication	type SM0 PP	PV PT CSP CSV	V CST HM
T. J.	Setting Range	Setting Unit	Mfr's Value	Effect
Index 1C00h-01h	N/A	N/A	01h	_
1Coon-oin	Function code	Mapping	Data type	Accessibility
	_	N	USINT8	RO
	Communication	type SM1 PP	PV PT CSP CSV	CST HM
T 1	Setting Range	Setting Unit	Mfr's Value	Effect
Index 1C00h-02h	N/A	N/A	02h	_
1C00n-02n	Function code	Mapping	Data type	Accessibility
	_	N	USINT8	RO
	Communication	type SM2 PP	PV PT CSP CSV	V CST HM
Index	Setting Range	Setting Unit	Mfr's Value	Effect
1C00h-03h	N/A	N/A	03h	
	Function code	Mapping	Data type USINT8	Accessibility
	Communication	N trung SM2 DD	PV PT CSP CSV	RO CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
Index	N/A	N/A	04h	
1C00h-04h	Function code	Mapping	Data type	Accessibility
		N	USINT8	RO
	Synchronization type		T CSP CSV CS	T HM
Total and	Setting Range	Setting Unit	Mfr's Value	Effect
Index 1C32h-01h	N/A	N/A	2	_
1C32n-01n	Function code	Mapping	Data type	Accessibility
	_	N	UINT16	RO
	Cycle time	PP PV PT	CSP CSV	CST HM
T. J.	Setting Range	Setting Unit	Mfr's Value	Effect
Index	N/A	ns	0	_
1C32h-02h	Function code	Mapping	Data type	Accessibility
	_	N	UDINT32	RO
T., 3.	Synchronization	types supported	PP PV PT CSP	CSV CST HM
Index 1C32h-04h	Setting Range	Setting Unit	Mfr's Value	Effect
103211-0411	N/A	N/A	4	


	T			I I	
	Function code	Mapping	Data type	Accessibility	
	_	N	UINT16	RO	
	Minimum cycle	time PP PV	PT CSP CSV C	ST HM	
Index	Setting Range	Setting Unit	Mfr's Value	Effect	
1C32h-05h	N/A	N/A	500000		
103211-0311	Function code	Mapping	Data type	Accessibility	
		N	UDINT32	RO	
	Sync error	PP PV PT	CSP CSV CST	HM	
T., J.,	Setting Range	Setting Unit	Mfr's Value	Effect	
Index 1C32h-20h	N/A	N/A	0		
1C32n-20n	Function code	Mapping	Data type	Accessibility	
	_	N	BOOL	RO	
	Synchronization	type PP PV	PT CSP CSV	CST HM	
T 1	Setting Range	Setting Unit	Mfr's Value	Effect	
Index	N/A	N/A	2	_	
1C33h-01h	Function code	Mapping	Data type	Accessibility	
	_	N	UINT16	RO	
	Cycle time	PP PV P	CSP CSV	CST HM	
T 1	Setting Range	Setting Unit	Mfr's Value	Effect	
Index 1C33h-02h	N/A	ns	0	_	
1C5511-0211	Function code	Mapping	Data type	Accessibility	
	_	N	UDINT32	RO	
	Synchronization	types supported [PP PV PT CSP CSV CST HM		
T . 1.	Setting Range	Setting Unit	Mfr's Value	Effect	
Index 1C33h-04h	N/A	N/A	4	_	
1C33n-04n	Function code	Mapping	Data type	Accessibility	
		N	UINT16	RO	
	Minimum cycle	time PP PV	PT SP CSV	CST HM	
T . 1.	Setting Range	Setting Unit	Mfr's Value	Effect	
Index 1C33h-05h	N/A	N/A	500000	_	
1C3Sn-USn	Function code	Mapping	Data type	Accessibility	
	_	N	UDINT32	RO	

	Sync error	PP PV P	T CSP CSV	CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
Index	N/A	N/A	0	_
1C33h-20h	Function code	Mapping	Data type	Accessibility
	_	N	BOOL	RO

8.3 Manufacturer defined parameters 8.3.1 Monitor parameter (Lo- $\square\square$)

User can monitor servo drive command and internal state by monitor parameter

Parameter	Display content	Unit	Remark
Lo-00	Servo drive output current	0.1A	
Lo-01	Servo drive bus voltage	V	
Lo-02	Servo motor speed	0.1rpm	
Lo-03	Servo motor feedback pulse displays high 5 digits.	100000	
Lo-04	Servo motor feedback pulse displays low 5 digits	Command unit	
Lo-05	Servo motor feedback rotation displays high 5 digits	100000	
Lo-06	Servo motor feedback rotation displays low 5 digits	Command unit	
Lo-07	Given command pulse displays high 5 digits	Command unit	Valid in position mode.
Lo-08	Given command pulse displays low 5 digits	Command unit	Valid in position mode.
Lo-09	Command pulse deviation counting	Command unit	Valid in position mode.
Lo-10	Given speed	0.1rpm	Valid in speed mode.
Lo-11	Given torque	1% of rated torque	Valid in torque mode.
Lo-12	Reserved		
Lo-13	Reserved		
Lo-14	DI8~DI5 state	None	



		A DO1 0 Disconnected 1 Connected B DO2 0 Disconnected 1 Connected C DO3 0 Disconnected 1 Connected D DO4 0 Disconnected 1 Connected
Lo-18	Servo drive current temperature	$^{\circ}$ C
Lo-19	Rotation inertia ratio display	0.01
Lo-20	Current output torque	%
Lo-21	Current gain group	N/A
Lo-22	Discharge time	10ms
Lo-23	One-loop pulse high 5 digits of motor absolute position	100000
Lo-24	One-loop pulse low 5 digits of motor absolute position	Command unit
Lo-25	Multi-loop pulse high 5 digits of motor absolute position	100000
Lo-26	Multi-loop pulse low 5 digits of motor absolute position	Command unit
Lo-27	Reserved	
Lo-28	Reserved	
Lo-29	Reserved	
Lo-30	Reserved	
Lo-31	Reserved	
Lo-32	Reserved	
Lo-33	Pulse numbers of high-speed counter 1	Command unit
Lo-34	Pulse numbers of high-speed counter 2	Command unit
Lo-36	Temperature of motor	$^{\circ}$

Note: This group of parameters can only be checked, not be set.

8.3.2 Index segment 2000h (function code Po0 ==)

Sub-index 01h Motor 0	Code PP	PV	PT	CSP	CSV	CST	HM	
-----------------------	---------	----	----	-----	-----	-----	----	--

	Setting Range	Setting Unit	Mfr's Value	Effect			
		N/A					
	Function code	Mapping o	Data type	Accessibility			
	Po000	N	UINT16	RO			
	Control mode an	nd forward direc	tion setting	•			
	PP PV PT	CSP CSV	CST HM				
	Setting Range	Setting Unit	Mfr's Value	Effect			
Sub-index 02h	Two-parameter	N/A	1 21	Restart			
	Function code	Mapping o	Data type	Accessibility			
	Po001	N	UINT16	RW			
d		1	1				
		X Control mode setting					
		0 Internal register speed	1 mode				
		Position pulse mode Internal register torqu	ia mada				
		Internal register torquReserved	le mode				
		4 Reserved					
		5 Internal register positi	Internal register position mode				
		6 Mix mode of internal	Mix mode of internal register speed and position pulse				
			Mix mode of internal register speed and internal register torque				
		8 Reserved					
		9 Reserved					
			ister speed and internal register				
			egister torque and position pu	lise			
	_	12 Reserved					
	_	13 Reserved					
	_		pulse and internal register po	sition			
	<u> </u>	15 Reserved					
	-	16 Reserved17 Mix mode of internal reg	istor torque and internal register	r position			
	-	18 Reserved					
		19 Reserved					
	=	20 Reserved	Reserved				
		21 Bus mode	Bus mode				
		Y Motor forward direc	Motor forward direction setting				
L		0 Clockwise as viewed	from servo motor shaft				
		1 Counterclockwise as	viewed from servo motor sha	aft			
Sub-index 04h	Encoder frequen	ncy-division num	bers				

	PP PV PT CSP CSV CST HM							
	Setting Range	Setting Unit	Mfr's Value	Effect				
	1~65535	N/A	_	immediate				
	Function code	Mapping o	Data type	Accessibility				
	Po003	N	UINT16	RW				
	set frequency-divisifect time is 100ms.	on numbers for ea	ach phase.					
	Encoder pulse fr		numbers denom	•				
Ch : 1 0/h	Setting Range	Setting Unit	Mfr's Value	Effect				
Sub-index 06h	$1\sim (2^{31}-1)$	N/A		immediate				
	Function code	Mapping o	Data type	Accessibility				
	Po005	N	UDINT32	RW				
Po005 is used to	set frequency-divi	sion numbers for	each motor					
	Motion range for	movement of in	ertia recognition					
	PP PV PT	CSP CSV CST HM						
Sub-index 08h	Setting Range	Setting Unit	Mfr's Value	Effect				
Sub-maex von	1~100	N/A	10	immediate				
	Function code	Mapping	Data type	Accessibility				
	Po007	N	INT16	RW				
	Inertia recognition	on mode selection	PP PV PT CSP	CSV CST HM				
	Setting Range	Setting Unit	Mfr's Value	Effect				
Sub-index 09h	0~3	N/A	0	immediate				
	Function code	Mapping	Data type	Accessibility				
	Po008	N	INT16	RW				

Po008=0: Not start rotational inertia identification function.

Po008=1: Offline fwd/rev direction identification, which is suitable for the equipment with limit motion range.

Po008=2: Offline single direction identification, suitable for the equipment, which cannot reverse.

Po008=3: Online automatic inertia identification; in this mode, servo drive maintains online automatic identification status, when jog running, it displays not "JOG", but the value of current rotational inertia.

Sub-index 0Ah | Movement of inertia recognition gap time

PP PV PT CSP CSV CST HM							
	Setting Range	Setting Unit	Mfr's Value	Effect			
	10~2000	ms	100	immediate			
	Function code	Mapping	Data type	Accessibility			
	Po009	N	INT16	RW			
	Rigidity selection	PP PV PT C	SP CSV CST HM				
	Setting Range	Setting Unit	Mfr's Value	Effect			
Sub-index 0Bh	1~30	N/A	6	immediate			
	Function code	Mapping	Data type	Accessibility			
	Po010	N	INT16	RW			
Po010 is used to	set servo drive rigid	lity. Please refer to	9.3.				
	Rotation inertia	ratio PP PV PT	CSP CSV CST	НМ			
	Setting Range	Setting Unit	Mfr's Value	Effect			
Sub-index 0Eh	1~30000	0.01	0.01 200				
	Function code	Mapping	Data type	Accessibility			
	Po013	N	INT16	RW			
Please refer to 9.3.							
	Movement of iner	tia acele/decel tim	ne PP PV PT CSF	CSV CST HM			
	Setting Range	Setting Unit Mfr's Value		Effect			
Sub-index 0Fh	200~5000	ms	1000	immediate			
	Function code	Mapping	Data type	Accessibility			
	Po014	N	INT16	RW			
Please refer to 9.3	3.						
	Motion range of	off-line inertia re	ecognition				
	PP PV PT	CSP CSV	CST HM				
Sub-index 10h	Setting Range	Setting Unit	Mfr's Value	Effect			
Sub-maex 10n	$200\sim(2^{31}-1)$	N/A	_	immediate			
	Function code	Mapping	Data type	Accessibility			
	Po015	N	DINT32	RW			
Please refer to 9.	3.						
Sub-index 12h	Z pulse frequenc	y-division output	width				

PP PV PT CSP CSV CST HM							
	Setting Range	Settin	g Unit	Mfr's Value	Effect		
	50~30000	N.	/ A	_	immediate		
	Function code	Map	ping	Data type	Accessibility		
	Po017	1	7	INT16	RW		
Please refer to 7.	.1.12.						
	Pulse output con	figuratio	n PP F	PV PT CSP CSV	CST HM		
	Setting Range	Settin	g Unit	Mfr's Value	Effect		
Sub-index 13h	Four-parameter	N.	/ A	0001	immediate		
	Function code	Map	ping	Data type	Accessibility		
	Po018	ľ	V	INT16	RW		
b							
	<u> </u>	Τ		alse output polarity			
			— <u> </u>	ative polarity output			
				tive polarity output			
			B Z pu	lse command source			
			1	Motor shaft Virtual shaft			
			Dulce	e frequency-division			
				ommand source			
			0	Motor shaft			
				nternal position given			
				follector pulse input			
			 	igh-speed counter 1			
			—	igh-speed counter 2			
			5 P	osition command			
	Virtual Z output	period	PP PV	PT CSP CSV C	STHM		
	Setting Range	Settin	g Unit	Mfr's Value	Effect		
Sub-index 14h	$1 \sim (2^{31} - 1)$	N.	/A	10000	immediate		
	Function code	Map	ping	Data type	Accessibility		
	Po019	ı	V	DINT32	RW		
One Z pulse is ou	tput per number of	Po019 p	ulse, outp	out pulse source is	set by Po018.		

8.3.3 Index segment 2001h (function code Po1 $\Box\Box$)

First speed loop proportional gain PP PV CSP CSV							
	Setting Range	Setting Unit	Mfr's Value	Effect			
Sub-index 02h	0~30000	0.1Hz	600	immediate			
	Function code	Mapping	Data type	Accessibility			
	Po101	N	INT16	RW			
Please refer to 9.3	3.3						
	First speed loop	integral time	PP PV CSP	CSV			
	Setting Range	Setting Unit	Mfr's Value	Effect			
Sub-index 03h	0~10000	0.1ms	500	immediate			
	Function code	Mapping	Data type	Accessibility			
	Po102	N	INT16	RW			
Please refer to 9.3	3.3						
	Second speed loop proportional gain PP PV CSP CSV						
	Setting Range	Setting Unit	Mfr's Value	Effect			
Sub-index 04h	0~30000	0.1Hz	240	immediate			
	Function code	Mapping	Data type	Accessibility			
	Po103	N	INT16	RW			
Please refer to 9.3.3							
	Second speed lo	op integral time	PP PV CSP	CSV			
	Setting Range	Setting Unit	Mfr's Value	Effect			
Sub-index 05h	0~30000	0.1ms	1250	immediate			
	Function code	Mapping	Data type	Accessibility			
	Po104	N	INT16	RW			
Please refer to 9.3.3							

Index segment 2001h (function code Po1□□)

	First speed loop	filter time const	First speed loop filter time constant PP PV CSP CSV				
	Setting Range	Setting Unit	Mfr's Value	Effect			
Sub-index 06h	1~20000	0.01ms		immediate			
	Function code	Mapping	Data type	Accessibility			
	Po105	N	INT16	RW			
Please refer to 9.3	3.3						
	Second speed lo	op filter time cor	nstant PP PV C	SP CSV			
	Setting Range	Setting Unit	Mfr's Value	Effect			
Sub-index 07h	1~20000	0.01ms		immediate			
	Function code	Mapping	Data type	Accessibility			
	Po106	N	INT16	RW			
Please refer to 9.3	3.3						
	Torque feed for	ward gain PP	PV PT CSP CSV	CST HM			
	Setting Range	Setting Unit	Mfr's Value	Effect			
Sub-index 08h	0~1000	N/A	0	immediate			
	Function code	Mapping	Data type	Accessibility			
	Po107	N	INT16	RW			
Under non- torqu	e mode, multiply	feedforward signa	l by Po107 to get	torque			
feedforward gain	. As a part of torqu	e command, incre	easing this parame	eter can improve			
response to chang	ging speed, improv	e position comma	and response and	decrease position			
deviation at const	ant speed.						
	Torque feedforv						
	PP PV PT	CSP CSV	CST HM				
Sub-index 09h	Setting Range	Setting Unit	Mfr's Value	Effect			
Sub-maca 0711	1~30000	0.01ms	100	immediate			
	Function code	Mapping	Data type	Accessibility			
	Po108	N	INT16	RW			
Please refer to 9.3	3.3						

Index segment 2001h (function code $Po1 \square \square$)

	S curve accele/d	lecele time	PV CSV	
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 0Ch	1~15000	1ms	100	immediate
	Function code	Mapping	Data type	Accessibility
	Po111	N	INT16	RW
	S curve starting	gindication	P	V CSV
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 0Dh	0~1	N/A	0	immediate
	Function code	Mapping	Data type	Accessibility
	Po112	N	INT16	RW
0: disabled 1: e	nabled			
	Rotation detect	ion value	P	V CSV
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 13h	0~30000	0.1rpm	300	immediate
	Function code	Mapping	Data type	Accessibility
	Po118	N	INT16	RW
When absolute va outputs.	alue of speed is hig	gher than the para	meter, rotation de	tection signals
	Speed value in the	ne zero clamp		PV CSV
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 1Bh	0~30000	0.1rpm	50	immediate
	Function code	Mapping	Data type	Accessibility
	Po126	N	UINT16	RW
	Zero clamp enab	oled		PV CSV
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 1Ch	0~1	N/A	0	immediate
	Function code	Mapping	Data type	Accessibility
	Po127	N	UINT16	RW
0: disabled 1:	enabled			

Index segment 2001h (function code $Po1 \square \square$)

	l	home searching s		
	PP PV PT	CSP CSV	CST HM	
Sub-index 1Dh	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-maex 1Dii	1~30000	10ms	100	immediate
	Function code	Mapping	Data type	Accessibility
	Po128	N	INT16	RW
	signal in the time			f not, home
found signal isn't	output. The entry			
	Delay time of ho	me searching	PP PV PT CSP C	SVCSTHM
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 1Eh	10~65535	ms	10000	Immediate
	Function code	Mapping	Data type	Accessibility
	Po129	N	UINT16	RW
If home searching	g time is more than	n Po129, servo dri	ve will trip into A	L-35.
The entry-into-ef	fect time is 10ms.			
	Gain switchover	mode	PP PV CSP	CSV
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 1Fh	0~6	N/A	0	Immediate
	Function code	Mapping	Data type	Accessibility
	Po130	N	INT16	RW
Please refer to 9.3.4				
	Gain switchover	speed	PP PV CSP	CSV
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 20h	1~32000	0.1rpm	100	Immediate
	Function code	Mapping	Data type	Accessibility
	Po131	N	INT16	RW
Please refer to 9.3	3.4			

Index segment 2001h (function code Po1□□)

Index segment 2001n (function code Pol ==)							
	Gain switching p	pulse	PP PV	CSP CSV			
	Setting Range	Setting Unit	Mfr's Value	Effect			
Sub-index 21h	1~32000	N/A	100	Immediate			
	Function code	Mapping	Data type	Accessibility			
	Po132	N	INT16	RW			
Please refer to 9	Please refer to 9.3.4.						
	Position loop gai	in switching time	PP PV	CSP CSV			
	Setting Range	Setting Unit	Mfr's Value	Effect			
Sub-index 22h	1~32000	0.1ms	20	Immediate			
	Function code	Mapping	Data type	Accessibility			
	Po133	N	INT16	RW			
Please refer to 9	.3.4.						
	Speed loop gain	switching time	PP PV	CSP CSV			
	Setting Range	Setting Unit	Mfr's Value	Effect			
Sub-index 23h	0~20000	0.1ms	100	Immediate			
	Function code	Mapping	Data type	Accessibility			
	Po134	N	INT16	RW			
Please refer to 9.3	3.4						
	Gain switchover	delay time (from	gain 2 to 1)				
	PP PV CSF	CSV		_			
Sub-index 24h	Setting Range	Setting Unit	Mfr's Value	Effect			
Sub-maex 24m	0~32000	0.1ms	1000	Immediate			
	Function code	Mapping	Data type	Accessibility			
	Po135	N	INT16	RW			
Please refer to 9.3	3.4						
	Mechanical hon	ne one-loop Pl	PPV PT CSP CS	SV CST HM			
	Setting Range	Setting Unit	Mfr's Value	Effect			
Sub-index 25h	$0\sim 2^{31}$	N/A	0	Power on again			
	Function code	Mapping	Data type	Accessibility			
	Po136	N	DINT32	RW			

	Mechanical hom	e multi-loop PP	PV PT CSP CSV	CSTHM
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 27h	$0\sim 2^{31}$	N/A	0	Immediate
	Function code	Mapping	Data type	Accessibility
	Po138	N	DINT32	RW
	Forward running	range pulse when	n overtravel protec	ction
	PP PV PT	CSP CSV	CST HM	
Sub-index 29h	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-muex 29m	$0\sim 2^{31}$	N/A	0	Immediate
	Function code	Mapping	Data type	Accessibility
	Po140	N	DINT32	RW
	Forward running	range multi-loop	numbers when ov	vertravel
	protection PP	PV PT	CSP CSV	CST HM
Sub-index 2Bh	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-macx 2Bit	0~32000	N/A	1000	Immediate
	Function code	Mapping	Data type	Accessibility
	Po142	N	INT16	RW
	Reverse running PP PV PT	range pulse wher	overtravel protec	etion
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 2Ch	$0 \sim 2^{31}$	N/A	0	Immediate
	Function code	Mapping	Data type	Accessibility
	Po143	N	DINT32	RW
	Reverse running protection PP		loop numbers v	when overtravel ST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 2Eh	0~32000	N/A	1000	Immediate
	Function code	Mapping	Data type	Accessibility
	Po145	N	INT16	RW
		222		

	Speed order filter ti	me constant F	PP PV CSP	CSV
Sub-index 36h	Setting Range	Setting Unit	Mfr's Value	Effect
	1~30000	0.01ms	1	Immediate
	Function code	Mapping	Data type	Accessibility
	Po153	N	INT16	RW

8.3.4 Index segment 2002h (function code $Po2\square\square$)

	First current loop	bandwidth PP	PV PT CSP CSV	CST HM		
	Setting Range	Setting Unit	Mfr's Value	Effect		
Sub-index 01h	10~3000	Hz		Immediate		
	Function code	Mapping	Data type	Accessibility		
	Po200	N	INT16	RW		
Please refer to 9	Please refer to 9.3.3.					
	Second current le	oop bandwidth PI	PV PT CSP CS	V CST HM		
	Setting Range	Setting Unit	Mfr's Value	Effect		
Sub-index 02h	10~3000	Hz		Immediate		
	Function code	Mapping	Data type	Accessibility		
	Po201	N	INT16	RW		
Please refer to 9	.3.3.					
	Forward/reverse		d emergency stop CST HM	torque		
	Setting Range	Setting Unit	Mfr's Value	Effect		
Sub-index 08h	1~300	1% of rated torque	100	Immediate		
	Function code	Mapping	Data type	Accessibility		
	Po207	N	INT16	RW		
	verse run prohibite					
motor instant reverse stop torque is limited by Po207. Po207 is absolute value, which is valid for forward/reverse run. The entry-into-effect time is 100ms						
vanu 101 101 waru		filter time consta				
Sub-index 0Fh	PP PV PT	1 — —	CST HM			
Sub-muca of ii	Setting Range	Setting Unit	Mfr's Value	Effect		

	0~30000	0.01ms	—	Immediate
	Function code	Mapping	Data type	Accessibility
	Po214	N	INT16	RW
Please refer to 9.	.3.3.			
	Second torque lo	oop filter time con	stant	
	PP PV PT	CSP CSV	CST HM	
Sub-index 10h	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-maex 10n	0~30000	0.01ms	_	Immediate
	Function code	Mapping	Data type	Accessibility
	Po215	N	INT16	RW
Please refer to 9.	.3.3.			
	Forward/reverse	run prohibited to	que setting	PT CST
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 11h	0~1	N/A	1	Immediate
	Function code	Mapping	Data type	Accessibility
	Po216	N	INT16	RW
0: prohibited torq	ue is Po207 1:	prohibited torque	is 0.	
	The first notch f	ilter center freque	ncy	
	PP PV PT CSP CSV CST HM			
Sub-index 12h	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 12n	50~30000	Hz	2000	Immediate
	Function code	Mapping	Data type	Accessibility
	Po217	N	INT16	RW
Please refer to 9.	.4.			
	The first notch f	ilter width		
	PP PV PT	CSP CSV	CST HM	
Sub-index 13h	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-maex 13n	0~30000	Hz	5	Immediate
	Function code	Mapping	Data type	Accessibility
	Po218	N	INT16	RW
Please refer to 9.	4.			
Sub-index 14h	The first notch f	ilter depth		

	PP PV PT CSP CSV CST HM			
	Setting Range	Setting Unit	Mfr's Value	Effect
	0~100	N/A	0	Immediate
	Function code	Mapping	Data type	Accessibility
	Po219	N	INT16	RW
Please refer to 9	.4.			
	The second note	h filter center freq	uency	
	PP PV P	T CSP CSV	CST HM	
Sub-index 15h	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-ilidex 15ll	50~30000	Hz	2000	Immediate
	Function code	Mapping	Data type	Accessibility
	Po220	N	INT16	RW
Please refer to 9	.4.			
	The second note	h filter width		
	PP PV P	T CSP CSV	CST HM	
Sub-index 16h	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 10ff	0~30000	Hz	5	Immediate
	Function code	Monning	Data type	Accessibility
	Fullction code	Mapping	Bata type	riccossionity
	Po221	N	INT16	RW
Please refer to 9	Po221		· -	_
Please refer to 9	Po221	N	· -	_
Please refer to 9	Po221	N h filter depth	INT16	_
	Po221 .4. The second note:	N h filter depth	INT16	_
Please refer to 9 Sub-index 17h	Po221 .4. The second note: PP PV P	N h filter depth T CSP CSV	INT16 // CST HM	RW
	Po221 .4. The second note: PP PV P Setting Range	N h filter depth T CSP CSV Setting Unit	INT16 / CST HM Mfr's Value	RW
	Po221 .4. The second note: PP PV P Setting Range 0~100	N h filter depth T CSP CSV Setting Unit N/A	INT16 CST HM Mfr's Value 0	RW Effect Immediate
	Po221 A. The second note: PP PV P Setting Range 0~100 Function code Po222	N h filter depth T CSP CSV Setting Unit N/A Mapping	INT16 // CST HM Mfr's Value 0 Data type	RW Effect Immediate Accessibility
Sub-index 17h	Po221 .4. The second note: PP PV P Setting Range 0~100 Function code Po222 .4.	N h filter depth T CSP CSV Setting Unit N/A Mapping	INT16 CST HM Mfr's Value 0 Data type INT16	RW Effect Immediate Accessibility
Sub-index 17h	Po221 .4. The second note: PP PV P Setting Range 0~100 Function code Po222 .4. The third notch for the second note: The second note: PP PV P	N h filter depth T CSP CSV Setting Unit N/A Mapping N	INT16 CST HM Mfr's Value 0 Data type INT16	RW Effect Immediate Accessibility
Sub-index 17h	Po221 .4. The second note: PP PV P Setting Range 0~100 Function code Po222 .4. The third notch for the second note: The second note: PP PV P	N h filter depth T CSP CSV Setting Unit N/A Mapping N	INT16 CST HM Mfr's Value 0 Data type INT16	RW Effect Immediate Accessibility
Sub-index 17h Please refer to 9	Po221 .4. The second note: PP PV P Setting Range 0~100 Function code Po222 .4. The third notch for the present and th	N h filter depth T CSP CSV Setting Unit N/A Mapping N filter center freque T CSP CSV	INT16 CST HM Mfr's Value 0 Data type INT16 ency CST HM	Effect Immediate Accessibility RW

	Po223	N	INT16	RW
Please refer to 9.	4.			
	The third notch f	filter width		
	PP PV P	T CSP CSV	CST HM	
Sub-index 19h	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 19ff	0~30000	Hz	5	Immediate
	Function code	Mapping	Data type	Accessibility
	Po224	N	INT16	RW
Please refer to 9.	4.			
	The third notch f	ilter depth PP	PV PT CSP CSV	CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 1Ah	0~100	N/A	0	Immediate
	Function code	Mapping	Data type	Accessibility
	Po225	N	INT16	RW
Please refer to 9.	4.			
	The fourth notch	filter center frequ	iency	
	PP PV	PT CSP CS	CST HM	
Sub-index 1Bh	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-mack 1Dii	50~30000	Hz	2000	Immediate
	Function code	Mapping	Data type	Accessibility
	Po226	N	INT16	RW
Please refer to 9.	4.			

	The fourth notch	The fourth notch filter width PP PV PT CSP CSV CST HM			
	Setting Range	Setting Unit	Mfr's Value	Effect	
Sub-index 1Ch	0~30000	Hz	5	Immediate	
	Function code	Mapping	Data type	Accessibility	
	Po227	N	INT16	RW	
Please refer to 9	.4.				
	The fourth notch	filter depth PP	PV PT CSP CSV	CST HM	
Sub-index 1Dh	Setting Range	Setting Unit	Mfr's Value	Effect	
	0~100	N/A	0	Immediate	

	Function code	Mapping	Data type	Accessibility
	Po228	N	INT16	RW
Please refer to 9	.4.			
	Notch filter func	tion enabled PP	PV PT CSP CSV	CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 1Eh	0~3	N/A	0	Immediate
	Function code	Mapping	Data type	Accessibility
	Po229	N	INT16	RW
	unction disabled s being auto-confi		otch filter functio	n enabled
	No. of notch filte	er PP PV	PT CSP CS	V CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 1Fh	1~4	N/A	2	Immediate
	Function code	Mapping	Data type	Accessibility
	Po230	N	INT16	RW
	Load observer ga	ain PP I	PV PT CSP CS	SV CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 23h	0~1000	N/A	0	Immediate
	Function code	Mapping	Data type	Accessibility
	Po234	N	INT16	RW
The compensation set too high, there	n for load torque e is noise.	can improve syste	em rigidity. But if	the parameter is
	Filter time of loa	d observer PP	PV PT CSP CSV	CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 24h	0~30000	0.01ms	1000	Immediate
	Function code	Mapping	Data type	Accessibility
	Po235	N	INT16	RW
Setting Po235 can compensate load torque, which can improve system rigidity. If the parameter is set too small, there is noise.				
		pensation coefficie	ent	
Sub-index 25h	PP PV PT	CSP CSV	CST HM	
	Setting Range	Setting Unit	Mfr's Value	Effect

	0~1000	0.1%	500	Power on again	
	Function code	Mapping	Data type	Accessibility	
	Po236	N	INT16	RW	
	Target torque rar	nge PP PV	PT CSP CSV C	CST HM	
	Setting Range	Setting Unit	Mfr's Value	Effect	
Sub-index 26h	1~50	1%	2	Immediate	
	Function code	Mapping	Data type	Accessibility	
	Po237	N	INT16	RW	
Torque filter frequency PP PV PT CSP CSV CST HM					
	Setting Range	Setting Unit	Mfr's Value	Effect	
Sub-index 27h	0~1000	0.1Hz	10	Immediate	
	Function code	Mapping	Data type	Accessibility	
	Po238	N	INT16	RW	
	Center frequency	of jitter inhibitio	n		
	PP PV P	T CSP CSV	CST HM	,	
Sub-index 29h	Setting Range	Setting Unit	Mfr's Value	Effect	
Sub-maex 29m	50~2000	0.1Hz	2000	Immediate	
	Function code	Mapping	Data type	Accessibility	
	Po240	N	INT16	RW	
	Intensity of jitter	inhibition PP P	PV PT CSP CSV	CST HM	
	Setting Range	Setting Unit	Mfr's Value	Effect	
Sub-index 2Bh	0~100	N/A	0	Immediate	
	Function code	Mapping	Data type	Accessibility	
	Po242	N	INT16	RW	

8.3.5 Index segment 2003h (function code Po3 \(\sigma \))

Sub-index 01h	Pulse command setting	PP PV PT CSP CSV CST HM	

	Setting Range	Se	etting Unit	Mfr's Value	Effect
	Four-parameter		N/A	1000	Immediate
	Function code	l	Mapping	Data type	Accessibility
	Po300		N	INT16	RW
b			0 Pt 1 Pt 2 (fou B Fi 0 1 2 3 4 5 6 C 0 PULS 1 1 PULS 2 2 PULS 3 PULS 5 4 PULS 5 5 Frequen 0 Ne	Pulse mode alse+direction alse+pulse Orthogonal arfold frequency) lter frequency 4MHz 2MHz 1MHz 500KHz 200KHz 150KHz 80 KHz Pulse input logic negative,SIGN negative,SIGN positive,SIGN positive, SIGN negative, SIGN ne	ve ive ive N
	First position loc Setting Range		in etting Unit	Mfr's Value	PP CSP Effect
Sub-index 02h	1~30000	50	N/A	— —	Immediate
	Function code	1	Mapping	Data type	Accessibility
	Po301		N	INT16	RW
Please refer to 9.3	3.3				

	Second position	loop gain		PP CSP		
	Setting Range	Setting Unit	Mfr's Value	Effect		
Sub-index 03h	1~30000	N/A	—	Immediate		
	Function code	Mapping	Data type	Accessibility		
Dlagga rafar to 0.2	Po302	N	INT16	RW		
Please refer to 9.3	3.3					
	Position loop fee	d forward gain		PP CSP		
	Setting Range	Setting Unit	Mfr's Value	Effect		
Sub-index 04h	0~1000	N/A	0	Immediate		
	Function code	Mapping	Data type	Accessibility		
	Po303	N	INT16	RW		
Please refer to 9.3.3						
	First group electr	ronic gear numera	tor	PP CSP		
	Setting Range	Setting Unit	Mfr's Value	Effect		
Sub-index 05h	0~65535	N/A	0	Immediate		
	Function code	Mapping	Data type	Accessibility		
	Po304	N	INT16	RW		
The entry-into-ef	fect time is 100ms					
	First group electronic gear denominator PP CSP					
	Setting Range	Setting Unit	Mfr's Value	Effect		
Sub-index 06h	1~65535	N/A	10000	Immediate		
	Function code	Mapping	Data type	Accessibility		
	Po305	N	INT16	RW		
The entry-into-ef	fect time is 100ms					
	Position loop filt	er time constant		PP CSP		
	Setting Range	Setting Unit	Mfr's Value	Effect		
Sub-index 07h	1~10000	ms	1	Immediate		
	Function code	Mapping	Data type	Accessibility		
	Po306	N	INT16	RW		
Please refer to 9.3	3.3					
Sub-index 09h	Command pulse	clear function		PP CSP		
Sub-maex vyn	Setting Range	Setting Unit	Mfr's Value	Effect		

	Four-parameter	N/A	_	Immediate
	Function code	Mapping	Data type	Accessibility
	Po308	N	INT16	RW
b			inhibiting pulse signal	
			nvalid	
			port must be allocated)	
		B Comm 0	and pulse clear	
			Invalid ort must be allocated)	
			nit for position loop racking error	
		0	1 pulse	
			00 pulses	
			it for position loop cking error	
		0	1 pulse	
		1 1	00 pulses	
	Filter time consta	ant of position fee	edforward	PP CSP
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 1Bh	1~32000	0.01ms	1000	Immediate
	Function code	Mapping	Data type	Accessibility
	Po326	N	UINT16	RW
	Filter time consta	ant of position fee	dforward	PP CSP
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 1Ch	1~30000	N/A	_	Immediate
	Function code	Mapping	Data type	Accessibility
	Po327	N	UINT16	RW
	Internal position	given speed unit		PP CSP
Sub-index 27h	Setting Range	Setting Unit	Mfr's Value	Effect
i	0~1	N/A	0	Immediate

	Function code	Mapping	Data type	Accessibility
	Po338	N	INT16	RW
	peed, no related to			
1:0.01KHz, frequ	ency division proc		electronic gear ra	
	Electronic gear s			PP CSP
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 28h	0~2	N/A	1	Immediate
	Function code	Mapping	Data type	Accessibility
	Po339	N	INT16	RW
The entry-into-eff 0: The first electron 1: The second electron 3: DI terminal sel	ctronic gear ratio			
	Position feedback	k source		PP CSP
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 4Dh	0~2	N/A	0	Immediate
	Function code	Mapping	Data type	Accessibility
	Po376	N	INT16	RW
0: encoder 1:	Po376 high-speed counter	,	INT16 peed counter 2	RW
0: encoder 1:	high-speed counte	,	peed counter 2	RW PP CSP
0: encoder 1:	high-speed counte	er 1 3: high-s _l	peed counter 2	
0: encoder 1: Sub-index 4Eh	high-speed counter External encoder	er 1 3: high-sp	peed counter 2	PP CSP
	high-speed counted External encoder Setting Range	er 1 3: high-sp proportion nume Setting Unit	peed counter 2 rator Mfr's Value	PP CSP Effect
	high-speed counted External encoder Setting Range 1~65535	er 1 3: high-sp proportion nume Setting Unit N/A	peed counter 2 rator Mfr's Value	PP CSP Effect Immediate
	high-speed counted External encoder Setting Range 1~65535 Function code	er 1 3: high-sp proportion nume Setting Unit N/A Mapping	peed counter 2 rator Mfr's Value 1 Data type	PP CSP Effect Immediate Accessibility
	high-speed counter External encoder Setting Range 1~65535 Function code Po377	er 1 3: high-sp proportion nume Setting Unit N/A Mapping	peed counter 2 rator Mfr's Value 1 Data type UINT16	PP CSP Effect Immediate Accessibility
	high-speed counter External encoder Setting Range 1~65535 Function code Po377	er 1 3: high-sp proportion nume Setting Unit N/A Mapping N	peed counter 2 rator Mfr's Value 1 Data type UINT16	PP CSP Effect Immediate Accessibility RW
	high-speed counter External encoder Setting Range 1~65535 Function code Po377 External encoder	er 1 3: high-sportion numer Setting Unit N/A Mapping N proportion denor	peed counter 2 rator Mfr's Value 1 Data type UINT16	PP CSP Effect Immediate Accessibility RW PP CSP
Sub-index 4Eh	high-speed counter External encoder Setting Range 1~65535 Function code Po377 External encoder Setting Range	r proportion numer Setting Unit N/A Mapping N proportion denore Setting Unit	peed counter 2 rator Mfr's Value 1 Data type UINT16 minator Mfr's Value	PP CSP Effect Immediate Accessibility RW PP CSP Effect
Sub-index 4Eh	high-speed counter External encoder Setting Range 1~65535 Function code Po377 External encoder Setting Range 1~65535	ser 1 3: high-sproportion numers Setting Unit N/A Mapping N reproportion denore Setting Unit N/A	peed counter 2 rator Mfr's Value 1 Data type UINT16 minator Mfr's Value 1	PP CSP Effect Immediate Accessibility RW PP CSP Effect Immediate
Sub-index 4Eh	high-speed counter External encoder Setting Range 1~65535 Function code Po377 External encoder Setting Range 1~65535 Function code	r proportion numer Setting Unit N/A Mapping N proportion denorement Setting Unit N/A Mapping N Mapping N Mapping N Mapping	peed counter 2 rator Mfr's Value 1 Data type UINT16 minator Mfr's Value 1 Data type	PP CSP Effect Immediate Accessibility RW PP CSP Effect Immediate Accessibility
Sub-index 4Eh	high-speed counter External encoder Setting Range 1~65535 Function code Po377 External encoder Setting Range 1~65535 Function code	er 1 3: high-sproportion numer Setting Unit N/A Mapping N proportion denore Setting Unit N/A Mapping N Mapping N	peed counter 2 rator Mfr's Value 1 Data type UINT16 minator Mfr's Value 1 Data type	PP CSP Effect Immediate Accessibility RW PP CSP Effect Immediate Accessibility

	0~32000	N/A	0	Immediate
	Function code	Mapping	Data type	Accessibility
	Po379	N	INT16	RW
	Mixed error alar	m value		PP CSP
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 51h	1~65535	N/A	1000	Immediate
	Function code	Mapping	Data type	Accessibility
	Po380	N	UINT16	RW
	OP abnormal p	rotection time	PP PV PT CSI	CSV CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 5Eh	0~65535	10ms	20	Immediate
	Function code	Mapping	Data type	Accessibility
	Po393	N	UINT16	RW

8.3.6 Index segment 2004h (function code Po4 \square)

	DI1 terminal fun	ction selection	PP PV PT CSP	PV PT CSP CSV CST HM		
	Setting Range	Setting Unit	Mfr's Value	Effect		
Sub-index 08h	Two-parameter	N/A	_	Restart		
	Function code	Mapping	Data type	Accessibility		
	Po407	N	UINT16	RW		
Please refer to 8.3	Please refer to 8.3.10					
	DI2 terminal function selection		PP PV PT CSP CSV CST HM			
	Setting Range	Setting Unit	Mfr's Value	Effect		
Sub-index 09h	Two-parameter	N/A	_	Restart		
	Function code	Mapping	Data type	Accessibility		
	Po408	N	UINT16	RW		
Please refer to 8.3	3.10					
	DI3 terminal fun	ction selection PF	PV PT CSP CS	V CST HM		
Sub-index 0Ah	Setting Range	Setting Unit	Mfr's Value	Effect		
	Two-parameter	N/A	_	Restart		

	Function code	Mapping	Data type	Accessibility
	Po409	N	UINT16	RW
Please refer to 8.3	3.10			
	DI4 terminal fun	ction selection	PP PV PT CSP C	SV CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 0Bh	Two-parameter	N/A	_	Restart
	Function code	Mapping	Data type	Accessibility
	Po410	N	UINT16	RW
Please refer to 8.3	3.10			
DI5 terminal function selection PP PV PT CSP CSV CST HM				
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 0Ch	Two-parameter	N/A		Restart
	Function code	Mapping	Data type	Accessibility
	Po411	N	UINT16	RW
Please refer to 8.3	3.10			
	DI6 terminal fun	ction selection PI	PV PT CSP CS	V CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 0Dh	Two-parameter	N/A	_	Restart
	Function code	Mapping	Data type	Accessibility
	Po412	N	UINT16	RW
Please refer to 8.3	3.10			
	DI7 terminal fun	ction selection	PP PV PT CSP C	SV CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 0Eh	Two-parameter	N/A		Restart
	Function code	Mapping	Data type	Accessibility
	Po413	N	UINT16	RW
Please refer to 8.3	3.10			
	DI8 terminal fun	ction selection	PP PV PT CSP C	SV CST HM
Sub-index 0Fh	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-muca of II	Two-parameter	N/A	_	Restart
	Function code	Mapping	Data type	Accessibility

	Po414	N	UINT16	RW		
Please refer to 8.3	3.10					
	DO1 terminal function selection PP PV PT CSP CSV CST HM					
	Setting Range	Setting Unit	Mfr's Value	Effect		
Sub-index 16h	Two-parameter	N/A	_	Restart		
	Function code	Mapping	Data type	Accessibility		
	Po421	N	UINT16	RW		
Please refer to 8.3.10						
	DO2 terminal fu	nction selection P	PP PV PT CSP CS	SV CST HM		
	Setting Range	Setting Unit	Mfr's Value	Effect		
Sub-index 17h	Two-parameter	N/A		Restart		
	Function code	Mapping	Data type	Accessibility		
	Po422	N	UINT16	RW		
Please refer to 8.3	3.10					
	DO3 terminal function selection PP PV PT CSP CSV CST HM					
	Setting Range	Setting Unit	Mfr's Value	Effect		
Sub-index 18h	Two-parameter	N/A	_	Restart		
	Function code	Mapping	Data type	Accessibility		
	Po423	N	UINT16	RW		
Please refer to 8.3	3.10					
	DO4 terminal fu	nction selection	PP PV PT CSP CSV CST HM			
	Setting Range	Setting Unit	Mfr's Value	Effect		
Sub-index 19h	Two-parameter	N/A	_	Restart		
	Function code	Mapping	Data type	Accessibility		
	Po424	N	UINT16	RW		
Please refer to 8.3	3.10					
	ALM terminal fu	nction selection	PP PV PT CSP	CSV CST HM		
	Setting Range	Setting Unit	Mfr's Value	Effect		
Sub-index 1Ah	Two-parameter	N/A	_	Restart		
	Function code	Mapping	Data type	Accessibility		
	Po425	N	UINT16	RW		
Please refer to 8.3	3.10					
Sub-index 27h	DI1 filter time	PP PV F	CSP CSV CST	НМ		

	Setting Range	Setting Unit	Mfr's Value	Effect
	0~30000	N/A	2	Immediate
	Function code	Mapping	Data type	Accessibility
	Po438	N	UINT16	RW
	DI2 filter time	PP PV	PT CSP CSV C	ST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 28h	0~30000	N/A	2	Immediate
	Function code	Mapping	Data type	Accessibility
	Po439	N	UINT16	RW
	DI3 filter time	PP P	PT CSP CSV	CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 29h	0~30000	N/A	2	Immediate
	Function code	Mapping	Data type	Accessibility
	Po440	N	UINT16	RW
	DI4 filter time	PP P	V PT CSP CSV (CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 2Ah	0~30000	N/A	2	Immediate
	Function code	Mapping	Data type	Accessibility
	Po441	N	UINT16	RW
	DI5 filter time	PP PV F	T CSP CSV CST	НМ
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 2Bh	0~30000	N/A	2	Immediate
	Function code	Mapping	Data type	Accessibility
	Po442	N	UINT16	RW
	DI6 filter time	PP PV	PT CSP CSV C	CST HM
Sub-index 2Ch	Setting Range	Setting Unit	Mfr's Value	Effect
	0~30000	N/A	2	Immediate

	Function code	Mapping	Data type	Accessibility
	Po443	N	UINT16	RW
				1
	DI7 filter time	PP PV	PT CSP CSV C	STHM
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 2Dh	0~30000	N/A	2	Immediate
	Function code	Mapping	Data type	Accessibility
	Po444	N	UINT16	RW
	DI8 filter time	PP PV F	T CSP CSV CST	НМ
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 2Eh	0~30000	N/A	2	Immediate
	Function code	Mapping	Data type	Accessibility
	Po445	N	UINT16	RW
8.3.7 Index segr	ment 2005h (fu	nction code Po	5□□)	
	Communication address PP PV PT CSP CSV CST HN			
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 01h	1~254	N/A	1	Immediate
	Function code	Mapping	Data type	Accessibility
	Po500	N	UINT16	RW
Please refer to 6.2	2. The entry-into-e	effect time is 1000	ms.	
	Communication	mode [PP PV PT CSP C	SV CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 02h	0~1	N/A	0	Immediate
	Function code	Mapping	Data type	Accessibility
	Po501	N	UINT16	RW
Please refer to 6.2	•	-effect time is 100		
	Stop bit settings	PP	PV PT CSP CS	V CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 03h	0~1	N/A	0	Immediate
	Function code	Mapping	Data type	Accessibility
	Po502	N	UINT16	RW
		247		

0: one stop bit 1: two stop bit					
	Odd/even calibra	ation PP	PV PT CSP CSV (CST HM	
	Setting Range	Setting Unit	Mfr's Value	Effect	
Sub-index 04h	0~2	N/A	0	Immediate	
	Function code	Mapping	Data type	Accessibility	
	Po503	N	UINT16	RW	
0: no calibration	1: odd calibra		calibration		
The entry-into-ef	fect time is 1000m			T COM VD 4	
	Baud rate	<u></u>	P PV PT CSP CSV		
	Setting Range	Setting Unit	Mfr's Value	Effect	
Sub-index 05h	0~5	bit/s	2	Immediate	
	Function code	Mapping	Data type	Accessibility	
	Po504	N	UINT16	RW	
0: 2400 1:4800	2: 9600 3: 192	200 4:38400		refer to 6.2	
	Whether commu	Whether communication is valid PP PV PT CSP CSV CST HM			
	Setting Range	Setting Unit	Mfr's Value	Effect	
Sub-index 06h	Two-parameter	N/A	1	Immediate	
	Function code	Mapping	Data type	Accessibility	
	Po505	N	UINT16	RW	
d					
		Whether	Modbus data is allow	ed to be	
			into servodrive data st	orage.	
		0	Yes		
		1	No		
			EtherCAT data is allo		
		0 be witter	n into servodrive data	storage.	
		1	Yes No		
d Two-parameter mode					
Please refer to 6.2. The entry-into-effect time is 1000ms.					
Sub-index 07h	Time interval of	serial data pack	et PP PV PT CSI	CSV CST HM	
Sub-maca 0/II	Setting Range	Setting Unit	Mfr's Value	Effect	

-20~2000	0.1rpm	0	Immediate
Function code	Mapping	Data type	Accessibility
Po506	N	INT16	RW

8.3.8 Index segment 2006h (function code Ho

	Rated voltage	PP	PV PT CSP CS	V CST HM			
	Setting Range	Setting Unit	Mfr's Value	Effect			
Sub-index 01h	1~30000	V					
	Function code	Mapping	Data type	Accessibility			
	Ho000	N	UINT16	RO			
	Rated current		PP PV PT CSP	CSV CST HM			
	Setting Range	Setting Unit	Mfr's Value	Effect			
Sub-index 02h	0~30000	0.1A		Immediate			
	Function code	Mapping	Data type	Accessibility			
	Ho001	N	UINT16	RW			
	Max rotary spe	ed PP PV PT CSP CSV CST HM					
	Setting Range	Setting Unit	Mfr's Value	Effect			
Sub-index 03h	0~32000	rpm	_	Immediate			
	Function code	Mapping	Data type	Accessibility			
	Ho002	N	UINT16	RW			
	Rated rotary sp	eed	PP PV PT CSP C	SV CST HM			
	Setting Range	Setting Unit	Mfr's Value	Effect			
Sub-index 04h	1~32000	rpm	_	Immediate			
	Function code	Mapping	Data type	Accessibility			
	Ho003	N	UINT16	RW			
	Motor pole pair	·s PP	PV PT CSP CSV	CST HM			
Sub-index 05h	Setting Range	Setting Unit	Mfr's Value	Effect			
	1~30	Pairs		Immediate			

	Function code	Mapping	Data type	Accessibility	
	Ho004	N	UINT16	RW	
For example, if n	notor pole number	is 8, pole pairs is 4	1.		
	Resistance between phases PP PV PT CSP CSV CST HM				
	Setting Range	Setting Unit	Mfr's Value	Effect	
Sub-index 06h	0~65535	$10^{\text{-}3}\Omega$	_	Immediate	
	Function code	Mapping	Data type	Accessibility	
	Ho005	N	UINT16	RW	
	D-axis inductan	ice PP P	Y PT CSP CSV	CST HM	
	Setting Range	Setting Unit	Mfr's Value	Effect	
Sub-index 07h	0~65535	10 ⁻⁶ H	_	Immediate	
	Function code	Mapping	Data type	Accessibility	
	Ho006	N	UINT16	RW	
	Q-axis inductar	nce PP	PV PT CSP CSV	CST HM	
	Setting Range	Setting Unit	Mfr's Value	Effect	
Sub-index 08h	0~65535	10 ⁻⁶ H	_	Immediate	
	Function code	Mapping	Data type	Accessibility	
	Ho007	N	UINT16	RW	
	Back EMF line voltage value PP PV PT CSP CSV CST HM				
	Setting Range	Setting Unit	Mfr's Value	Effect	
Sub-index 09h	0~30000	0.1V/1000rpm	_	Immediate	
	Function code	Mapping	Data type	Accessibility	
	Ho008	N	UINT16	RW	
	Motor rated po	wer PI	PV PT CSP CS	V CST HM	
	Setting Range	Setting Unit	Mfr's Value	Effect	
Sub-index 0Ch	1~30000	0.01Kw		Immediate	
	Function code	Mapping	Data type	Accessibility	
	Ho011	N	UINT16	RW	

	Motor moveme	nt inertia	PP PV PT CSP CSV CST HM		
Sub-index 0Dh	Setting Range	Setting Unit	Mfr's Value	Effect	
	$0\sim (2^{31}-1)$	10 ⁻⁶ Kg•m ²		Immediate	
	Function code	Mapping	Data type	Accessibility	
	Ho012	N	UINT16	RW	
	Encoder line nu	mber [PP PV PT CSP CS	SV CST HM	
	Setting Range	Setting Unit	Mfr's Value	Effect	
Sub-index 11h	$0\sim (2^{31}-1)$	PPR	_	Immediate	
	Function code	Mapping	Data type	Accessibility	
	Ho016	N	DINT32	RW	
	Encoder installa	ation angle (num	ber of pulses)		
	PP PV PT CSP	CSV CST HM			
	Setting Range	Setting Unit	Mfr's Value	Effect	
Sub-index 13h	- (2 ³¹ -1)	N/A		Immediate	
	\sim + (2 ³¹ -1))	N/A			
	Function code	Mapping	Data type	Accessibility	
	Ho018	N	DINT32	RW	
	Overload sensit	ivity setting	PP PV PT CSP (CSV CST HM	
Sub-index 48h	Setting Range	Setting Unit	Mfr's Value	Effect	
	1~30000	N/A	500	Immediate	
	Function code	Mapping	Data type	Accessibility	
	Ho121	N	INT16	RW	

8.3.9 Index segment 2008h (function code So-

	Software versio	n of firmware 1	PP PV PT CSP CSV CST HM		
Sub-index 01h	Setting Range	Setting Unit	Mfr's Value	Effect	
	N/A	N/A			

	Function code	Mapping	Data type	Accessibility
	So-00	N	UINT16	RO
So-00 displays software version of firmware 1. For example, 100 is 1.00 version.				
	User's password	(Avoid modifying CSP CSV	parameters by mi CST HM	stake)
Ch : d 02h	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 02h	0~9999	N/A	_	Restart
	Function code	Mapping	Data type	Accessibility
	So-01	N	UINT16	RW
Please refer to 7.	10.1.			
	Delay time for se	ervo OFF	PP PV PT CSP (CSV CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 03h	0~500	10ms	0	Immediate
	Function code	Mapping	Data type	Accessibility
	So-02	N	UINT16	RW
Please refer to 7.	1.3. The entry-into	-effect time is 100)ms.	
Delay time for electro-magnetic braking OFF PP PV PT CSP CSV CST HM				
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 04h	10~100	10ms	50	Immediate
	Function code	Mapping	Data type	Accessibility
	So-03	N	UINT16	RW
Please refer to 7.	1.3. The entry-into	-effect time is 100)ms.	
	Braking resistor	r value	PP PV PT CSP	CSV CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 05h	8~1000	Ω		Immediate
	Function code	Mapping	Data type	Accessibility
	So-04	N	UINT16	RW
So-04 is used to set servo drive external resistor value. External resistor and internal				
resistor cannot be used at the same time. If user select external resistor, please remove the jumper between terminal B1 and B2. Please refer to 7.1.7.				
Discharge duty ratio PP PV PT CSP CSV CST HM				
Sub-index 06h	Setting Range	Setting Unit	Mfr's Value	Effect
	0~100	%	50	Immediate

	Function code	Mapping	Data type	Accessibility
	So-05	N	UINT16	RW
The higher the di	scharge duty ratio,	, the fast the disch	arge speed.	
	Input power ph	ase-loss protectio	on PP PV PT CSF	CSV CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 07h	0~1	N/A	_	Immediate
	Function code	Mapping	Data type	Accessibility
	So-06	N	UINT16	RW
0: disabled	l; enabled			
	Servo OFF stop	mode	PP PV PT CSP CS	SV CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 08h	0~5	N/A	0	Immediate
	Function code	Mapping	Data type	Accessibility
	So-07	N	UINT16	RW

- 0: Free stop
- 1: Dynamic brake, only valid for servo drive with dynamic brake.
- 2: Fast enabled.

When servo drive is power on and receives enable signal, after 10ms delay, servo is on.

- 3: Deceleration stop.
- 4: Deceleration stop and dynamic brake.
 5: Deceleration stop and fast enabled.

3. Deceleration s						
	Dynamic brakii	Dynamic braking delay time PP PV PT CSP CSV CST HM				
	Setting Range	Setting Unit	Mfr's Value	Effect		
Sub-index 09h	100~30000	0.1ms	5000	Immediate		
	Function code	Mapping	Data type	Accessibility		
	So-08	N	UINT16	RW		
	Servo drive stat	us display	PP PV PT CSP C	SV CST HM		
	Setting Range	Setting Unit	Mfr's Value	Effect		
Sub-index 0Ah	0~38	N/A	2	Immediate		
		11/12	_	Illillediate		
	Function code	Mapping	Data type	Accessibility		
	Function code So-09	- "				
Please refer to 7.	So-09	Mapping	Data type	Accessibility		

	PP PV PT	CSP CSV	CST HM	
	Setting Range	Setting Unit	Mfr's Value	Effect
	N/A	N/A	_	_
	Function code	Mapping	Data type	Accessibility
	So-10	N	UINT16	RO
So-10 can only be checked, but cannot be modified.				
	Record of malfu	ınction type for t	he last second tir	ne
	PP PV PT	CSP CSV	CST HM	
Sub-index 0Ch	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index och	N/A	N/A		
	Function code	Mapping	Data type	Accessibility
	So-11	N	UINT16	RO
So-11 can only be	e checked, but can	not be modified.		
	Record of malfu	ınction type for t	he last third time	ė
	PP PV PT	CSP CSV	CST HM	
Sub-index 0Dh	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index vDii	N/A	N/A		
	Function code	Mapping	Data type	Accessibility
	So-12	N	UINT16	RO
So-12 can only be	e checked, but can	not be modified.		
	Jog speed	PP	PV PT CSP CSV	CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 0Eh	0~30000	0.1rpm	1000	Immediate
	Function code	Mapping	Data type	Accessibility
	So-13	N	UINT16	RW
So-13 can only be	e checked, but can	not be modified.	Γhe entry-into-effe	ect time is 10ms.
	Encoder discon	nection protectio	n PP PV PT CSP	CSV CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 10h	0~1	N/A	1	Immediate
	Function code	Mapping	Data type	Accessibility
	So-15	N	UINT16	RW
0: Invalid 1:	Valid			

The entry-into-ef	fect time is 10ms.			
	Speed threshold	of electromagno	etic braking CST HM	
0 1 1 1 11	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 11h	0~30000	0.1rpm	1000	Immediate
	Function code	Mapping	Data type	Accessibility
	So-16	N	UINT16	RW
Please refer to 7	.1.3			
	Forward run p	orohibited	PP PV PT CSP C	CSV CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 12h	0~1	N/A	1	Immediate
	Function code	Mapping	Data type	Accessibility
	So-17	N	UINT16	RW
When So-17=1, Sallocated, user ca	valid So-18=1 and termi n use overtravel fund So-18 is valid	ınction by externa	al terminal. For sec	curity, Mfr's
protection in case	Reverse run pi	rohibited	PP PV PT CSP	CSV CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 13h	0~1	N/A	1	Immediate
	Function code	Mapping	Data type	Accessibility
	So-18	N	UINT16	RW
When So-17=1, S allocated, user ca	valid So-18=1 and termi n use overtravel fund So-18 is valid of malfunction.	ınction by externa	al terminal. For sec	curity, Mfr's

protection in case of manufaction.					
	Analog monitor channel 1		PP PV PT CSP CSV CST HM		
	Setting Range	Setting Unit	Mfr's Value	Effect	
Sub-index 14h	0~3	N/A	0	Immediate	
	Function code	Mapping	Data type	Accessibility	
	So-19	N	UINT16	RW	

0: servo drive output current.

Servo drive output current corresponding to 10V is set by So-20.

1: servo drive output voltage.

Servo drive max voltage corresponding to 10V is set by So-21.

- 2: servo motor speed. Max rotation speed corresponding to 10V is set by So-22.
- 3: Output voltage 0V+offset. Offset voltage is set by So-24.


3: Output voltage	0V+offset. Offset	t voltage is set by	So-24.		
Servo drive output current corresponding to 10V					
	PP PV PT CSP	CSV CST HM			
a	Setting Range	Setting Unit	Mfr's Value	Effect	
Sub-index 15h	1~1000	0.1A	200	Immediate	
	Function code	Mapping	Data type	Accessibility	
	So-20	N	UINT16	RW	
The entry-into-ef	fect time is 1000m	ns.			
	Servo drive max voltage corresponding to 10V PP PV PT CSP CSV CST HM				
	Setting Range	Setting Unit	Mfr's Value	Effect	
Sub-index 16h	1~500	1V	500	Immediate	
	Function code	Mapping	Data type	Accessibility	
	So-21	N	UINT16	RW	
The entry-into-ef	fect time is 1000m	ıs.			
	Max rotation speed corresponding to 10V PP PV PT CSP CSV CST HM				
Sub-index 17h	Setting Range	Setting Unit	Mfr's Value	Effect	
Sub-maex 17m	1~32000	0.1rpm	30000	Immediate	
	Function code	Mapping	Data type	Accessibility	
	So-22	N	UINT16	RW	
The entry-into-ef	fect time is 1000m	ıs.			
	Motor parameter storing location PP PV PT CSP CSV CST HM				
Sub-index 18h	Setting Range	Setting Unit	Mfr's Value	Effect	
Sub-maex 1011	0~1	N/A	1	Immediate	
	Function code	Mapping	Data type	Accessibility	
0. 3371	So-23	N	UINT16	RW	

^{0:} When servo drive finishes auto-tuning motor parameter, motor parameters are stored in servo drive.

^{1:} When servo drive finishes studying motor parameter, motor parameters are stored in encoder. (Only for encoder with EEPROM)

	Analog monitor PP PV PT	voltage compens	csation 1 CST HM		
	Setting Range	Setting Unit	Mfr's Value	Effect	
Sub-index 19h	-10000~10000	mv	0	Immediate	
	Function code	Mapping	Data type	Accessibility	
	So-24	N	INT16	RW	
The entry-into-effect time is 1000ms.					
	Motor parameter PP PV PT CSP	identification set	ting		
Sub-index 1Ah	Setting Range	Setting Unit	Mfr's Value	Effect	
Sub-macx TAII	0~4	N/A	0	Immediate	
	Function code	Mapping	Data type	Accessibility	
	So-25	N	UINT16	RW	
Please refer to ch	apter 7.				
	Fan control		PP PV PT CSP	CSV CST HM	
	Setting Range	Setting Unit	Mfr's Value	Effect	
Sub-index 1Bh	0~2	N/A	2	Immediate	
	Function code	Mapping	Data type	Accessibility	
	So-26	N	UINT16	RW	
	Fan temperature setting		PP PV PT CSP	CSV CST HM	
	Setting Range	Setting Unit	Mfr's Value	Effect	
Sub-index 1Ch	10~100	°C	45	Immediate	
	Function code	Mapping	Data type	Accessibility	
	So-27	N	UINT16	RW	
	Power off and b	raking	PP PV PT CSF	CSV CST HM	
	Setting Range	Setting Unit	Mfr's Value	Effect	
Sub-index 1Dh	0~1	N/A	1	Immediate	
	Function code	Mapping	Data type	Accessibility	
	So-28	N	UINT16	RW	
0: disabled 1	: enabled				

	Time of power of	off and braking	PP PV PT CSP	CSV CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 1Eh	500~30000	0.1ms	1000	Immediate
	Function code	Mapping	Data type	Accessibility
	So-29	N	UINT16	RW
The entry-into-ef	fect time is 100ms			
	Setting of absol	ute position and	relative position	
	PP PV PT	CSP CSV	CST HM	
Sub-index 1Fh	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-muex IFH	0~1	N/A	_	Immediate
	Function code	Mapping	Data type	Accessibility
	So-30	N	UINT16	RW
0: Absolute position. Under internal position absolute mode, encoder feedback absolute position is adopted.1: Relative position. Under internal position absolute mode, encoder feedback absolute position is not adopted. Battery protection is shielded.				
	Communication	related error	PP PV PT CSP	CSV CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 20h	-	N/A	b1111	Immediate
	Function code	Mapping	Data type	Accessibility
	So-31	N	UINT16	RW
So-31 is used to s	set related EtherCA	AT protection.		



	Motor lock-roto	or protection fun	ction		
	Setting Range	Setting Unit	Mfr's Value	Effect	
Sub-index 23h	0~1	N/A	1	Immediate	
	Function code	Mapping	Data type	Accessibility	
	So-34	N	UINT16	RW	
0: disabled 1: enabled					
	Overload pre-al	larm current	PP PV PT CSP C	SV CST HM	
	Setting Range	Setting Unit	Mfr's Value	Effect	
Sub-index 24h	0~800	%	120	Immediate	
	Function code	Mapping	Data type	Accessibility	
	So-35	N	UINT16	RW	
	Overload pre-al	Overload pre-alarm filter time PP PV PT CSP CSV CS		CSV CST HM	
	Setting Range	Setting Unit	Mfr's Value	Effect	
Sub-index 25h	0~1000	10ms	10	Power on again	
	Function code	Mapping	Data type	Accessibility	
	So-36	N	UINT16	RW	
	Motor overload coefficient setting PP PV PT CSP CSV CST HM				
	Setting Range	Setting Unit	Mfr's Value	Effect	
Sub-index 26h	1~500	%	100	Immediate	
	Function code	Mapping	Data type	Accessibility	
	So-37	N	UINT16	RW	
Please refer to 7.	10.6.				
		rotection of LI b	oattery		
	PP PV PT CSP	CSV CST HM	T		
Sub-index 27h	Setting Range	Setting Unit	Mfr's Value	Effect	
Sub maca 27m	0~1	N/A	1	Immediate	
	Function code	Mapping	Data type	Accessibility	
	So-38	N	UINT16	RW	
0: disabled 1:	enabled				

	Overtravel limit	function	PP PV PT CSP CS	SV CST HM		
	Setting Range	Setting Unit	Mfr's Value	Effect		
Sub-index 28h	0~2	N/A	-	Immediate		
	Function code	Mapping	Data type	Accessibility		
	So-39	N	UINT16	RW		
0: disabled 1:	enabled 2: stop b	ut no alarm				
	I	Delay time of lock-rotor protection PPPV PT CSP CSV CST HM				
	Setting Range	Setting Unit	Mfr's Value	Effect		
Sub-index 29h	10~1000	10ms	100	Immediate		
	Function code	Mapping	Data type	Accessibility		
	So-40	N	UINT16	RW		
	Alarm output duty ratio PP PV PT CSP CSV CST HM					
	Setting Range	Setting Unit	Mfr's Value	Effect		
Sub-index 2Bh	1~100	%	100	Immediate		
	Function code	Mapping	Data type	Accessibility		
	So-42	N	UINT16	RW		
	Encoder reset	PP PV F	T CSP CSV CST	HM		
	Setting Range	Setting Unit	Mfr's Value	Effect		
Sub-index 2Ch	0~1	N/A	0	Immediate		
	Function code	Mapping	Data type	Accessibility		
	So-43	N	UINT16	RW		
0: encoder cannot be reset when alarm occurs. 1: encoder can be reset when alarm occurs. Encoder reset is used to reset when encoder alarm occurs. User needs to long press SET key for panel reset.						
neg for panel los	Parameter copy	P	PPV PT CSP CS	V CST HM		
	Setting Range	Setting Unit	Mfr's Value	Effect		
Sub-index 2Dh	Four-parameter	N/A	0000	Immediate		
	Function code	Mapping	Data type	Accessibility		

So-44

UINT16

RW

A Copy function 0 disabled 1 enabled B Motor parameter copy 0 disabled 1 enabled C Gain parameter copy 0 disabled 1 enabled D Notch filter paramter copy 0 disabled 1 enabled					
	FPGA software v	ersion PP	PV PT CSP CSV	CST HM	
	Setting Range	Setting Unit	Mfr's Value	Effect	
Sub-index 2Fh	_	N/A		Immediate	
	Function code	Mapping	Data type	Accessibility	
	So-46	N	UINT16	RW	
For example, 1	00 is 1.00 version				
	Motor parameters setting area password PP PV PT CSP CSV CST HM				
Sub-index 31h	Setting Range	Setting Unit	Mfr's Value	Effect	
Sub-maex 31n	0~9999	N/A	0	Immediate	
	Function code	Mapping	Data type	Accessibility	
, , , , , , , , , , , , , , , , , , ,	So-48	N	UINT16	RW	
When So-48=1	, motor parameter ca				
	Revert to Mfr's v	<u> </u>	PPV PT CSP CS		
	Setting Range	Setting Unit	Mfr's Value	Effect	
Sub-index 32h	0~1	N/A	0	Restart	
	Function code	Mapping	Data type	Accessibility	
	So-49	N	UINT16	RW	
	Motor overheat p	rotection	PP PV PT CSP	CSV CST HM	
	Setting Range	Setting Unit	Mfr's Value	Effect	
Sub-index 33h	0~1	N/A	0	Immediate	
	Function code	Mapping	Data type	Accessibility	
	So-50	N	UINT16	RW	
0: disabled	1: enabled		•		

	Motor disconnected protection of temperature detection PP PV PT CSP CSV CST HM			
			T	
Sub-index 34h	Setting Range	Setting Unit	Mfr's Value	Effect
	0~1	N/A	1	Immediate
	Function code	Mapping	Data type	Accessibility
	So-51	N	UINT16	RW
0: disabled	1: enabled			
	Torque detuning	protection Pl	PV PT CSP CS	V CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 37h	0~1	N/A	1	Immediate
	Function code	Mapping	Data type	Accessibility
	So-54	N	UINT16	RW
	: enabled			
When So-54 is v	alid, motor is phase-			ps into AL-23.
	Torque detuning protection filter time PP PV PT CSP CSV CST HM			
G 1 1 1 201	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 38h	1~100	10ms	10	Immediate
	Function code	Mapping	Data type	Accessibility
	So-55	N	UINT16	RW
Motor cable dis	sconnected protection	on time.		
	Air-cooling motor	r mode selection	PP PV PT CSP	CSV CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 39h	0~1	N/A	0	Immediate
	Function code	Mapping	Data type	Accessibility
	So-56	N	UINT16	RW
0: self-cooling	1: air-cooling			
	Forced input setti	ing of DI	PV PT CSP CS	V CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
Sub-index 3Ah	_	N/A	0	Immediate
	Function code	Mapping	Data type	Accessibility
	So-57	N	UINT16	RW

Please refer to	Please refer to 7.10.9.							
	Forced input and output mode of DI/DO PP PV PT CSP CSV CST HM							
G 1 1 1 2D1	Setting Range	Setting Unit	Mfr's Value	Effect				
Sub-index 3Bh		N/A	d00	Immediate				
	Function code	Mapping	Data type	Accessibility				
	So-58	N	UINT16	RW				
Please refer to	Please refer to 7.10.9.							
	Station alias	PP	PV PT CSP CSV	CST HM				
	Setting Range	Setting Unit	Mfr's Value	Effect				
Sub-index 3Ch	0~65535	N/A	0	Immediate				
	Function code	Mapping	Data type	Accessibility				
	So-59	N	UINT16	RW				
	The version of fir	mware 3	PP PV PT CSI	PCSV CST HM				
	Setting Range	Setting Unit	Mfr's Value	Effect				
Sub-index 3Dh		N/A	100	Immediate				
	Function code	Mapping	Data type	Accessibility				
	So-60	N	UINT16	RO				

Index segment 2008h (Parameter So-□□)

Sub-	Name	Analog r	Analog monitor channel 2		Setting mode	_	Mode	ALL
index 3Eh	Unit	N/A	Setting range	0~3	Effect	Immediate	Mfr's value	0
SEII	Paramete r	So-61	Access	RW	Mapping	N	Data type	UINT16

Analogue monitoring function selection setting:

Value	Definition	Remark
0	Servo drive output current	10V corresponding servo drive output current
	_	is determined by So-20.
1	Servo drive output voltage	10V corresponding servo drive output voltage
1	Servo drive output voltage	is determined by So-21.
2	G	10V corresponding servo motor speed is
2	Servo motor speed	determined by So-22.
3	Output 0V voltage+offset	The offset voltage is decided by So-62.

	compensation 2		Setting mode	_	Mode	ALL		
Sub- index 3Fh	Unit	mv	Setting range	-10000 ∼ 10000	Effect	Immediate	Mfr's value	0
	paramete r	So-62	Access	RW	Mapping	N	Data type	INT16

Analog monitor voltage compensation. The entry-into-effect time is 1000ms.

Sub-	Name	Alarm st	op mode		Setting mode	_	Mode	ALL
index 41h	Unit	N/A	A Setting range $0\sim 1$ Effective		Effect	Immediate	Mfr's value	0
1111	paramete r	So-64	Access	RW	Mapping	N	Data type	UINT16
Sub-	Name	Alarm de	Alarm deceleration stop time		Setting mode	_	Mode	ALL
index 42h	Unit	N/A	Setting range	0~ 65535	Effect	Immediate	Mfr's value	0
.211	paramete r	So-65	Access	RW	Mapping	N	Data type	UINT16

Sub-	Name	Speed to	Speed torque display unit			tting ode	_	Mode	ALL
index 43h	Unit	N/A	Setting range		Ef	fect	Immediate	Mfr's value	0
	paramete r	So-66	Access	RW	M	apping	N	Data type	UINT16
	b								
				Гг	A	Spee	ed unit	7	
					0	0.1	rpm		
					1	1	rpm		
					В	Torq	ue unit		
			<u> </u>		0	1	%		
					1	0.	1%		
					C	Res	served		
				——Г	D	Re	served		
				_					

8.3.10 Index segment 2009h (communication monitor group)

	LoParam 1 add	ress	PP PV PT CSP CSV CST HM		
	Setting Range	Setting Unit	Mfr's Value	Effect	
Sub-index 01h	_	N/A	900	Immediate	
	Function code	Mapping	Data type	Accessibility	
		N	UINT16	RW	
Please refer to	6.2.3.				
	LoParam 2 add	ress	PP PV PT CSP (CSV CST HM	
	Setting Range	Setting Unit	Mfr's Value	Effect	
Sub-index 02h	_	N/A	923	Immediate	
	Function code	Mapping	Data type	Accessibility	
	_	N	UINT16	RW	
Please refer to	6.2.3.				
	LoParam 3 add	ress	PP PV PT CSP CSV CST HM		
	Setting Range	Setting Unit	Mfr's Value	Effect	
Sub-index 03h		N/A	925	Immediate	
	Function code	Mapping	Data type	Accessibility	
	_	N	UINT16	RW	

Please refer to 6.2.3.						
	LoParam 1 valu	ie	PP PV PT CSP CSV CST HM			
	Setting Range Setting Unit		Mfr's Value	Effect		
Sub-index 04h		N/A	_	Immediate		
	Function code	Mapping	Data type	Accessibility		
		N	UINT16	RO		
Please refer to	6.2.3.					
	LoParam 2 valu	ie	PP PV PT CSP (CSV CST HM		
	Setting Range	Setting Unit	Mfr's Value	Effect		
Sub-index 05h		N/A	_	Immediate		
	Function code	Mapping	Data type	Accessibility		
		N	UINT16	RO		
Please refer to	6.2.3.					
	LoParam 3 valu	ie I	PP PV PT CSP C	SV CST HM		
	Setting Range	Setting Unit	Mfr's Value	Effect		
Sub-index 06h		N/A	_	Immediate		
	Function code	Mapping	Data type	Accessibility		
	_	N	UINT16	RO		
Please refer to 6.2.3.						

8.3.11 Function setting of DI and DO

Programmable terminals include DI1~DI8. (Related parameters are from Po407 to Po414). Common-open or common-close contact can be selected by input contact selection. For example, for servo drive safety stop, when malfunction occurs, user should select common-close switch.

Servo drive must be restarted after terminal function is set.




Fig 8.1.1 Programmable input terminal function

Setting value	Function	Name	Instruction	Signal type
0	Reserved	Reserved	Reserved	
1	Alarm reset	AL-RST	A number of faults (Alarms) can be cleared by activating AL-RST.	Edge trigger
2~7	Reserved	Reserved	Reserved	
8	Gain switchover	GAIN-SEL	Gain switchover	Level trigger
9	Reserved	Reserved	Reserved	
10	Pulse clear	CLR	Position deviation register returns to 0 at the position mode.	Edge trigger

11	Command pulse	INH-P	External pulse command is	Level
	prohibited		invalid at the position mode.	trigger
12	Emergency stop	ESP	Motor stops urgently.	Level
12	Emergency stop	LSI	wiotor stops argentry.	trigger
13	Reverse run	R-INH	Motor is forbidden reverse run.	Level
13	prohibited	IX-IIVII	iviolor is forbidden reverse fun.	trigger
14	Forward run	F-INH	Motor is forbidden forward run.	Level
14	prohibited	L-IIVII	Wiotor is forbidden forward fun.	trigger
15~21	Reserved	Reserved	Reserved	
22	External reference	ODGD	ORGP is external reference	Edge
22	origin	ORGP	origin.	trigger
23	Reserved	Reserved	Reserved	
24	Reserved	Reserved	Reserved	
25	Reserved	Reserved	Reserved	
2.5	Terminal forward	TO CITY	B 11 11 11 11 11 11	Level
26	jogging	JOGU	Realized by controlling terminal.	trigger
27	Terminal reverse	TOOD	B 11 11 11 11 11 11 11 11	Level
27	jogging	JOGD	Realized by controlling terminal.	trigger
• •		***		Level
28	Motor overheat	НОТ	Realized by controlling terminal.	trigger
29~33	Reserved	Reserved	Reserved	88
24	T 1 1 1	TD 1 1 1	Tr. 1 1 1	Level
34	Touchprobe-1	Touchprobe-1	Touchprobe-1	trigger
25	T 1 1 2	m 1 1 2	T 1 1 2	Level
35	Touchprobe-2	Touchprobe-2	Touchprobe-2	trigger

Programmable output terminals include DO1 \sim DO4 (Related parameters are Po421 \sim Po424), ALM (Related parameter is Po425).

Servo drive must be restarted after terminal function is set.




Fig 8.1.2 Programmable output terminal function

Function instruction of programmable output terminal:

Setting value	Function	Name	Instructions
0	Servo ready	S-RDY	S-RDY is activated when the servo drive is ready to run. All fault and alarm conditions, if present, have been cleared.
1	Servo on	SON-O	SON-O is activated when the servo motor is ON.
2	Rotation Detection	TGON	When the absolute value of speed is higher than the value of at rotation detection, TGON is activated.
3	At speed reached	V-CMP	V-CMP is activated when the servo motor has reached the target rotation speed.

4	At position reached	P-CMP	Position completed
5	At torque limit	T-LT	T-LT is activated when toque is limited.
6	Servo alarm activated	ALM	ALM is activated when the drive has detected a fault condition.
7	Electromagnetic brake control	BRAKE	BRAKE is activated actuation of motor brake.
8	Overload warning	OL-W	Overload pre-alarm signal
9	At speed limit	S-LT	S-LT is activated when speed is limited.
10	Reserved	Reserved	Reserved
11	Large position deviation pre-warning	PER-W	PER-W is activated when position deviation is too large.
12	Homing completed	НОМЕ	HOME is activated when the servo drive has detected that the HOME sensor has been detected.
13-15	Reserved	Reserved	Reserved
16	Dynamic brake	DRN_BR	Dynamic brake is valid, output this signal.

8.4 Parameters defined by sub-protocol (6000h)

	Error code	PP PV PT CSP CSV CST HM			
	Setting Range	Setting Unit	Mfr's Value	Effect	
Index 603Fh	_		_	_	
	Function code	Mapping	Data type	Accessibility	
	_	TPDO	UINT16	RO	
Please refer to	6.1.9.				
	Control word		PP PV PT CSP	CSV CST HM	
	Setting Range	Setting Unit	Mfr's Value	Effect	
Index 6040h	0~65535		0	immediate	
	Function code	Mapping	Data type	Accessibility	
	_	RPDO	UINT16	RW	
Please refer to 7.2.1.					

	Status word		PP PV PT CSP CSV CST HM		
	Setting Range	Setting Unit	Mfr's Value	Effect	
Index 6041h	_	_	_		
	Function code	Mapping	Data type	Accessibility	
	_	TPDO	UINT16	RO	
Please refer to	7.2.2.				
	Quick stop option	ı code	PP PV PT	CSP CSV CST HM	
	Setting Range	Setting Unit	Mfr's Value	Effect	
Index 605Ah	0~7	_	2	immediate	
	Function code	Mapping	Data type	Accessibility	
	_	N	INT16	RW	
	Halt option code		PP PV PT	CSP CSV CST HM	
	Halt option code Setting Range	Setting Unit	PP PV PT (Mfr's Value	CSP CSV CST HM Effect	
Index 605Dh		Setting Unit			
Index 605Dh	Setting Range	Setting Unit — Mapping	Mfr's Value	Effect	
Index 605Dh	Setting Range 0~7	_	Mfr's Value 1	Effect immediate	
Index 605Dh	Setting Range 0~7	— Mapping	Mfr's Value 1 Data type	Effect immediate Accessibility	
Index 605Dh	Setting Range 0~7	— Mapping N	Mfr's Value 1 Data type INT16	Effect immediate Accessibility	
Index 605Dh	Setting Range 0~7 Function code —	— Mapping N	Mfr's Value 1 Data type INT16	Effect immediate Accessibility RW	
Index 605Dh Index 6060h	Setting Range 0~7 Function code — Modes of operation	— Mapping N	Mfr's Value 1 Data type INT16 PP PV PT CSE	Effect immediate Accessibility RW CSV CST HM	
	Setting Range 0~7 Function code — Modes of operation Setting Range	— Mapping N	Mfr's Value 1 Data type INT16 PP PV PT CSE	Effect immediate Accessibility RW CSV CST HM Effect	
	Setting Range $0\sim7$ Function code — Modes of operation Setting Range $0\sim10$	Mapping N on Setting Unit —	Mfr's Value 1 Data type INT16 PP PV PT CSF Mfr's Value —	Effect immediate Accessibility RW CSV CST HM Effect immediate	

- 1: profile position mode(PP)
- 3: profile velocity mode(PV)
- 4: profile torque mode(PT)
- 5: NA
- 6: home mode (HM)
- 7: interpolation mode(IP)
- 8: cycle synchronous position mode(CSP)
- 9: cycle synchronous velocity mode(CSP)
- 10: cycle synchronous torque mode(CST)

Please refer to mode instruction.

Note: IP mode is not supported in this product.

	Modes of operati	on display	PP PV PT CSP	CSV CST HM		
	Setting Range	Setting Unit	Mfr's Value	Effect		
Index 6061h		_	_	_		
	Function code	Mapping	Data type	Accessibility		
		TPDO	UINT16	RO		
	Position demand	value	PP PV PT	CSP CSV CST HM		
	Setting Range	Setting Unit	Mfr's Value	Effect		
Index 6062h		Command unit	0			
	Function code	Mapping	Data type	Accessibility		
		TPDO	DINT32	RO		
	<u>, </u>					
	Position feedback	value	PP PV PT (CSP CSV CST HM		
	Setting Range	Setting Unit	Mfr's Value	Effect		
Index 6063h		Encoder unit	_	_		
	Function code	Mapping	Data type	Accessibility		
		TPDO	DINT32	RO		
Reflect motor	absolute position.					
	Position actual va	alue	PP PV PT CSI	CSV CST HM		
	Setting Range	Setting Unit	Mfr's Value	Effect		
Index 6064h	_	command unit	_			
	Function code	Mapping	Data type	Accessibility		
	_	TPDO	DINT32	RO		
Reflect real tir	ne user absolute pos	sition.				
6064h*6091h=	=6063h					
	Following error v	vindow		PP CSP HM		
	Setting Range	Setting Unit	Mfr's Value	Effect		
Index 6065h	1~32000	encoder unit	_	Immediate		
	Function code	Mapping	Data type	Accessibility		
	_	N	UINT16	RW		
						

	Position window	PP CSP HM			
	Setting Range	Setting Unit	Mfr's Value	Effect	
Index 6067h	1~32000		_	Immediate	
	Function code	Mapping	Data type	Accessibility	
	_	N	DINT32	RW	
	Position window	time		PP CSP HM	
	Setting Range	Setting Unit	Mfr's Value	Effect	
Index 6068h	0~65535	ms	0	Immediate	
	Function code	Mapping	Data type	Accessibility	
	_	N	UINT16	RW	
	Velocity actual va	oluo	PP PV PT CSP	CSVCSTHM	
	Setting Range	Setting Unit	Mfr's Value	Effect	
Index 606Ch	Setting Range		- Will S value		
maca oooch	Function code	Mapping	Data type	Accessibility	
		TPDO	DINT32	RO	
		1120	DII(132	, Ro	
	Velocity window			PV CSV	
	Setting Range	Setting Unit	Mfr's Value	Effect	
Index 606Dh	0~30000	0.1rpm	300	Immediate	
	Function code	Mapping	Data type	Accessibility	
	_	N	UINT16	RW	
	ı	<u>'</u>	<u> </u>	<u> </u>	
	Velocity window	time		PV CSV	
	Setting Range	Setting Unit	Mfr's Value	Effect	
Index 606Eh	0~65535	ms	0	Immediate	
	Function code	Mapping	Data type	Accessibility	
	_	N	UINT16	RW	
	•		•		

	Target Torque			PV CST
	Setting Range	Setting Unit	Mfr's Value	Effect
Index 6071h	-800~800			Immediate
	Function code	Mapping	Data type	Accessibility
	_	RPDO	INT16	RW
	Max Torque		PP PV PT	CSP CSV CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
Index 6072h	0~800	_	_	Immediate
	Function code	Mapping	Data type	Accessibility
	Po202	N	UINT16	RW
The entry-into	effect time is 100m	S.		
	Torque Demand	Value	PP PV P	CSP CSV CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
Index 6074h	1%	_	_	
	Function code	Mapping	Data type	Accessibility
	_	TPDO	INT16	RO
	Torque Demand	Value	PP PV P1	CSP CSV CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
Index 6077h	1%		_	_
	Function code	Mapping	Data type	Accessibility
	_	TPDO	INT16	RO
	Position Target V	alue		PP CSP
	Setting Range	Setting Unit	Mfr's Value	Effect
Index 607Ah	$-(2^{31}-1) \sim + (2^{31}-1)$	_	0	Immediate
	Function code	Mapping	Data type	Accessibility
	Po350	RPDO	DINT32	RW

	Home offset		HM	
	Setting Range	Setting Unit	Mfr's Value	Effect
Index 607Ch	$-(2^{31}-1) \sim + (2^{31}-1)$	_	0	Immediate
	Function code	Mapping	Data type	Accessibility
	Po123	RPDO	DINT32	RW

The entry-into-effect time is 100ms.

The effect condition: finish homing operation in this running, bit15=1 of status word 6041h.

	Polarity		PP PV PT	CSP CSV CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
Index 607Eh	00∼FF	_	_	Immediate
	Function code	Mapping	Data type	Accessibility
	_	RPDO	UINT16	RW

607Eh is used to set polarity of position command, velocity command and torque command.

Bit	Definition	
0~4	None	
	Torque command polarity:	
	0: keep existing value	
5	1: command X(-1)	
	PT: converse target torque 6071h	
	CST: converse torque command(6071h+60B2h)	
	Velocity command polarity:	
	0: keep existing value	
6	1: command X(-1)	
	PV: converse target velocity 60FFh	
	CSV: converse velocity command(60FFh+60B1h)	
	Position command polarity	
	0: keep existing value	
7	1: command X(-1)	
	PP: converse target position 607Ah	
	CSP: converse position command (607Ah+60B0h)	

Max profile veloc	rity	PP PV PT CS	P CSV CST HM		
Setting Range	Setting Unit	Mfr's Value	Effect		
0~13000	rpm	_	Immediate		
Function code	Mapping	Data type	Accessibility		
_	N	UDINT32	RW		
The entry-into-effect time is 100ms.					
Profile velocity			PP		
Setting Range	Setting Unit	Mfr's Value	Effect		
0~65535	0.1rpm	0	Immediate		
Function code	Mapping	Data type	Accessibility		
_	RPDO	UINT16	RW		
Profile acceleration	on		PP PV		
Setting Range	Setting Unit	Mfr's Value	Effect		
0~65535	ms		Immediate		
Function code	Mapping	Data type	Accessibility		
_	N	UINT16	RW		
effect time is 100m	S.				
Profile decelerati	on		PP PV		
Setting Range	Setting Unit	Mfr's Value	Effect		
0~65535	ms		Immediate		
Function code	Mapping	Data type	Accessibility		
Po311	N	UINT16	RW		
-effect time is 100m	S.				
Quick stop decele	eration	PP PV PT	CSP CSV CST HM		
Setting Range	Setting Unit	Mfr's Value	Effect		
0~65535	ms		Immediate		
Function code	Mapping	Data type	Accessibility		
_	N	UINT16	RW		
	Setting Range 0~13000 Function code —effect time is 100m Profile velocity Setting Range 0~65535 Function code — Profile acceleration Setting Range 0~65535 Function code —effect time is 100m Profile deceleration Setting Range 0~65535 Function code —feffect time is 100m Profile deceleration Setting Range 0~65535 Function code Po311 effect time is 100m Quick stop deceleration Setting Range 0~65535	$0\sim13000$ rpmFunction codeMapping—Neffect time is 100 ms.Profile velocitySetting RangeSetting Unit $0\sim65535$ 0.1 rpmFunction codeMapping—RPDOProfile accelerationSetting RangeSetting Unit $0\sim65535$ msFunction codeMapping—Neffect time is 100 ms.Profile decelerationSetting UnitSetting RangeSetting Unit $0\sim65535$ msFunction codeMappingPo311Neffect time is 100 ms.Setting UnitQuick stop decelerationSetting UnitSetting RangeSetting Unit $0\sim65535$ msFunction codeMapping	Setting Range Setting Unit Mfr's Value 0~13000 rpm — Function code Mapping Data type — N UDINT32 eeffect time is 100ms. Profile velocity Setting Range Setting Unit Mfr's Value 0~65535 0.1rpm 0 Function code Mapping Data type — RPDO UINT16 Profile acceleration Setting Range Setting Unit Mfr's Value 0~65535 ms — Function code Mapping Data type Po311 N UINT16 eeffect time is 100ms. Quick stop deceleration PP PV PT C Setting Range Setting Unit Mfr's Value 0~65535 ms — Function code Mapping Data type		

Under PP, CSV, PV, HM mode, quick stop option code (605Ah) is equal to 2 or 6 and quick stop command is valid, 6085h is slope deceleration time.

Under PP, CSV, PV, HM mode, halt option code (605Dh) is equal to 2 and halt command is

Under PP, CSV, PV, HM mode, halt option code (605Dh) is equal to 2 and halt command is valid, 6085h is slope deceleration time.

	Torque slope			PT		
	Setting Range	Setting Unit	Mfr's Value	Effect		
Index 6087h	0~65535	0.1ms		Immediate		
	Function code	Mapping	Data type	Accessibility		
		N	UINT16	RW		
	Numerator of Ge	ar ratio		PP CSP HM		
Index	Setting Range	Setting Unit	Mfr's Value	Effect		
6091h-01h	$0\sim (2^{31}-1)$	N/A	0	Immediate		
009111-0111	Function code	Mapping	Data type	Accessibility		
	Po344	N	UDINT32	RW		
The entry-into	-effect time is 100m	S				
	Denominator of (Gear ratio		PP CSP HM		
T., J.,	Setting Range	Setting Unit	Mfr's Value	Effect		
Index 6091h-02h	$1 \sim (2^{31} - 1)$	N/A	1000	Immediate		
009111-0211	Function code	Mapping	Data type	Accessibility		
	Po346	N	UDINT32	RW		
The entry-into-	effect time is 100ms	;				
	Homing method			HM		
	Setting Range	Setting Unit	Mfr's Value	Effect		
Index 6098h	-1~35	_	0	Immediate		
	Function code	Mapping	Data type	Accessibility		
		N	INT16	RW		
	First Homing spe	ed	,	НМ		
T., J.,	Setting Range	Setting Unit	Mfr's Value	Effect		
Index 6099h-01h	0~20000	0.1rpm	500	Immediate		
009911-0111	Function code	Mapping	Data type	Accessibility		
	Po120	N	UINT16	RW		
The entry-into	-effect time is 100m	S.				

	Second Homing s	speed		HM		
T., J.,	Setting Range	Setting Unit	Mfr's Value	Effect		
Index 6099h-02h	0~20000	0.1rpm	200	Immediate		
009911-0211	Function code	Mapping	Data type	Accessibility		
	Po121	N	UINT16	RW		
The entry-into-effect time is 100ms.						
	Homing accelera	tion		HM		
	Setting Range	Setting Unit	Mfr's Value	Effect		
Index 609Ah	0~1000	ms	0	Immediate		
	Function code	Mapping	Data type	Accessibility		
		N	UINT16	RW		
	Position offset			CSP		
	Setting Range	Setting Unit	Mfr's Value	Effect		
Index 60B0h	-2^{31} ~ $(2^{32}$ -1)	Command unit	0	Immediate		
	Function code	Mapping	Data type	Accessibility		
	_	RPDO	DINT32	RW		
The entry-int	o-effect time is 100	ms.				
	Velocity offset			CSP CSV		
	Setting Range	Setting Unit	Mfr's Value	Effect		
Index 60B1h	-1300000~ 1300000	0.01rpm	0	Immediate		
	Function code	Mapping	Data type	Accessibility		
	_	RPDO	DINT32	RW		
	Torque offset			CST CSP CSV		
	Setting Range	Setting Unit	Mfr's Value	Effect		
Index 60B2h	-1000~1000	0.1%	0	Immediate		
	Function code	Mapping	Data type	Accessibility		
		RPDO	INT16	RW		

	Touch probe function		PP PV PT CSP CSV CST HM		
	Setting Range	Setting Unit	Mfr's Value	Effect	
Index 60B8h	0~65535	_	_	Immediate	
	Function code	Mapping	Data type	Accessibility	
	_	RPDO	UINT16	RW	
	Touch probe state	us	PP PV PT	CSP CSV CST HM	
	Setting Range	Setting Unit	Mfr's Value	Effect	
Index 60B9h		_			
	Function code	Mapping	Data type	Accessibility	
		RPDO	UINT16	RO	
	Touch probe posi	l position value	PP PV PT	CSP CSV CST HM	
	Setting Range	Setting Unit	Mfr's Value	Effect	
Index 60BAh	Command unit	-2^31~2^31-1	_	_	
	Function code	Mapping	Data type	Accessibility	
	_	TPDO	DINT32	RO	
	Touch probe neg	l position value	PP PV PT C	SP CSV CST HM	
	Setting Range	Setting Unit	Mfr's Value	Effect	
Index 60BBh	Command unit	-2^31~2^31-1	_	_	
	Function code	Mapping	Data type	Accessibility	
	_	TPDO	DINT32	RO	
	Touch probe pos2	2 position value	PP PV PT CS	P CSV CST HM	
	Setting Range	Setting Unit	Mfr's Value	Effect	
Index 60BCh	Command unit	-2^31~2^31-1			
	Function code	Mapping	Data type	Accessibility	
	_	TPDO	DINT32	RO	

	Touch probe neg2	2 position value	PP PV PT CS	P CSV CST HM		
	Setting Range	Setting Unit	Mfr's Value	Effect		
Index 60BDh	Command unit	-2^31~2^31-1	_			
	Function code	Mapping	Data type	Accessibility		
		TPDO	DINT32	RO		
	Forward Direction	on Torque Limit V	Value PP PV PT	CSP CSV CST HM		
	Setting Range	Setting Unit	Mfr's Value	Effect		
Index 60E0h	0~800	%	<u> </u>	Immediate		
	Function code	Mapping	Data type	Accessibility		
	Po208	RPDO	UINT16	RW		
The entry-into-en	ffect time is 100ms.					
	Reverse Direction Torque Limit Value PP PV PT CSP CSV CST HM					
	Setting Range	Setting Unit	Mfr's Value	Effect		
Index 60E1h	0~800	%		Immediate		
	Function code	Mapping	Data type	Accessibility		
	Po209	RPDO	UINT16	RW		
The entry-into-en	ffect time is 100ms.					
	Following error actual value			PP CSP		
	Setting Range	Setting Unit	Mfr's Value	Effect		
Index 60F4h	-2^31~2^31-1	Command unit	_	_		
	Function code	Mapping	Data type	Accessibility		
		TPDO	DINT32	RO		
	Digital Input		PP PV PT	CSP CSV CST HM		
	Setting Range	Setting Unit	Mfr's Value	Effect		
Index 60FDh	0~2^32			_		
	Function code	Mapping	Data type	Accessibility		
	_	TPDO	UDINT32	RO		

	Digital Output		PP PV PT CS	SP CSV CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
Index 60FEh	0~2^32			Immediate
	Function code	Mapping	Data type	Accessibility
	_	RPDO	UDINT32	RW
	Target velocity			PV CSV
	Setting Range	Setting Unit	Mfr's Value	Effect
Index 60FFh	-130000~130000	0.1rpm		Immediate
	Function code	Mapping	Data type	Accessibility
	_	RPDO	DINT32	RW
	Supported drive r	nodes	PP PV P1	CSP CSV CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
Index 6502h				
	Function code	Mapping	Data type	Accessibility
	_	N	UDINT32	RO

IX Adjustments

9.1 Summary

The servo drive is required to run the motor in least time delay and as faithful as possible against commands from the host controller or internal setting. Gain adjustment needs to be performed to meet the requirements.

Gain adjustment process:




Fig 9.1.1Gain adjustment flow chart

Note:

- Jog test running is recommended firstly before gain adjustment to ensure motor runs normally.
- •Servo gain can be set by combination of multi-parameter (position-loop, speed-loop, filter, load rotational inertia ratio etc.), these parameters interact on each other. Therefore, balance of parameters must be considered.

9.2 Inertia Identification

When motor is connected to machine or load simulator, before normal production, servo drive must "study" the rotational inertia of machine, which is convenient for user to adjust related parameters and make sure servo system run in proper inertia.

Inertia ratio=Total load inertia of machine/Motor rotor inertia

The inertia ratio is an important parameter of the servo system, and quick commissioning can be implemented with the correct setting of this parameter. It can be set manually or auto-tuned automatically by the servo drive.

The servo drive supports two identification methods:

1) Offline identification

When the offline inertia identification function is enabled in (Po008), press the keys on the keypad of the servo drive to run the motor and obtain the inertia ratio.

2) Online identification

The servo drive obtains the inertia ratio through load situation and writes the value to "rotational inertia ratio (Po013)".



CALITION

- 1. If the actual inertia ratio is very large the drive gain is low, motor action will be slow, which cannot meet the requirements for maximum motor speed and actual acceleration rate. In this case, increase **rigidity** in **Po010** and perform inertia identification again.
- 2. If vibration occurs during identification, stop identification immediately and decrease the gain.

9.2.1 Offline Identification

Servo drive can drive the load running by servo motor according to forward/reverse curve to calculate the rotational inertia ratio of load and confirm the rotational inertia.

Confirm the following before performing offline identification:

1) The movement travel of the motor meet the following requirements:

Ensure that the limit switches have been installed and required movement travel is reserved to prevent overtravel which may cause accidents during identification; Ensure that the movement

travel for the motor in stop position is larger than Po015. If not, user can increase it properly.

2) Evaluate the value of Po013

a) Preset a large initial value for Po013.

The recommended preset value is 400. Increase Po013 gradually till the value on the keypad is updated.

b) Increase the rigidity level of the servo drive properly:

Increase the rigidity level (Po010) properly to meet the requirements of inertia identification. The following figure shows the offline inertia identification flowchart.




Fig 9.2.1 Offline inertia identification flowchart

Related Parameters:

1) Motion range of offline inertia identification (pulse)

Signal Name	Parameter	Setting Range	Mfr's value	Content
Motion	2000h-10h	$200 \sim (2^{31} - 1)$	_	Approximate value, One-time identification action finished in setting pulse range.
range	Function code	Mapping	Data type	Accessibility

Po015	N	DINT32	RW

2) Inertia identification mode selection

	Inertia identification mode selection		PP	PV PT CSP	CSV CST HM
	Setting Range			Mfr's Value	Effect
2000h-09h	 Disabled Offline fwd/rev direction identification. Offline single direction identification. Online auto inertia identification 	N/A		0	Immediate effect Lost if power's off
	Function code		ng	Data type	Accessibility
	Po008	N		INT16	RW

Illustration:

- (1) Po008=0: Inertia identification is disabled.
- (2) Po008=1: Offline fwd/rev identification, suitable for the equipment with limit motion range.
- (3) Po008=2: Offline single direction identification, suitable for the equipment that cannot run reversely.
- (4) Po008=3: Online inertia auto identification, servo drive always keeps online auto identification, if servo drive is jog running, inertia is displayed, not JOG".

3) Offline inertia identification action gap time

	Offline rotational in PP PV PT C	ertia identification	action gap time	
2000b 0Ab	Setting Range	Setting Unit	Mfr's Value	Effect
2000h-0Ah	1~2000	ms	100	Immediate
	Function code	Accessibility		
	Po009	N	INT16	RW

4) Motor accel/decel time at offline inertia identification

	Movement of inertia	PP PV PT CSP CSV CST HM		
2000h-0Fh	Setting Range	Setting Unit	Mfr's Value	Effect
	200~5000	ms	1000	Immediate

Function code	Mapping	Data type	Accessibility
Po014	N	INT16	RW

5) Inertia ratio

	Rotation inertia ratio	o PP PV	PT CSP CS	V CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
2000h-0Eh	1~30000	0.01	200	Immediate
	Function code	Mapping	Data type	Accessibility
	Po013	N	INT16	RW

Note: Rotation inertia identification just measures inertia ratio, but doesn't match with speed position parameter. After finishing inertia identification, please make sure to select rigidity.

9.2.2 Online Inertia Identification

Online inertia automatic identification: Po008=3, servo drive enters inertia online automatic identification state and identifies inertia automatically according to load situation.

Note: The condition of online automatic inertia identification shows as below:

- Max rotary speed is higher than 200rpm in the motion process of servomotor.
- The acceleration/deceleration of servomotor is higher than 3000rpm/s.
- The machinery that rigid load is not easy to generate small vibration.
- Slow changing of load inertia
- Mechanical clearance is not big in the motor process




Fig 9.2.2 online rotational inertia setting flow chart

9.3 Gain Adjustment

9.3.1 Summary

User needs to adjust servo gain to improve servo drive response, which requires setting parameter combinations, which influence each other. Therefore, parameter relation must be considered for gain adjustment.

In general, response of high rigidity machine can be improved by increasing servo gain. But for low rigidity machine, vibration may occur when servo gain increases. Therefore, if high response is required, high rigidity machine is required to avoid vibration.

Response frequency of position or speed must be selected according to the machine rigidity and application.

In general, high precise machining requires high response frequency, but high response frequency may bring vibration. If allowable response frequency is unknown, user can increase gain gradually to raise response frequency until vibration occurs and then decrease gain. Gain adjustment principle is as following:

Servo rigidity is the ability that motor rotor withstands load inertia, which is self-locking ability of motor rotor. The stronger the servo rigidity, the larger the corresponding speed-loop gain, the faster the system response.

Servo rigidity must be used along with the load rotational inertia, the larger the load inertia, the

lower the allowable rigidity level. If servo rigidity is higher than inertia ratio, high-frequency self-excited oscillation will occur. Otherwise, motor response is slow, motor takes long time to reach specified location.

The servo system consists of three control loops, namely, position loop, speed loop, and current loop from external to internal. The following figure shows the basic control block diagram.




Fig 9.3.1 Servo drive internal frame diagram

The most internal loop must have the highest response. If it is not observed, the system may be unstable.

The default current loop gain of the servo drive ensures the response, and need not be adjusted. You only need to adjust the position loop gain, speed loop gain and other auxiliary gains.

9.3.2 Automatic Gain Adjustment

Automatic gain adjustment means that the servo drive automatically produces the matching gain parameters based on the setting of Po010 (Rigidity level selection) to achieve fast response and stability.



CAUTION:

Ensure that the correct inertia ratio has been obtained before enabling automatic gain adjustment.

Related Parameter:

	Rigidity Selection	1	PP PV PT CSP CSV CST HM		
	Setting Range	Setting Unit	Mfr's Value	Effect	
2000h-0Bh	1~30	N/A	6	Immediate	
	Function code	Mapping	Data type	Accessibility	
	Po010	N	INT16	RW	

The setting range of Po010 (Rigidity selection) is 0–19. the bigger value is, stronger rigidity is.

System will generate first group parameters of gain. The first gain group includes: first position loop gain Po301, first speed loop proportional gain Po101, first speed loop integral time Po102, first speed filter time constant Po105, first torque filter time constant Po214, first current loop bandwidth Po200.

Setting method of rigidity level:

- 1) Confirm that inertia identification has been executed and the inertia ratio is reasonable, estimate proper rigidity level Po010 according to inertia ratio and drive connection mode (the bigger mechanical load is, the lower rigidity level is).
- 2) So-14 enters jog test running, check the normal operation and noise. Reduce rigidity level Po010 properly if there is any noise. Otherwise, user can try to improve the rigidity level and test running again until satisfying the system requirement.

When changing rigidity level, speed loop gain and position loop gain will change too. After setting rigidity level, user can still make a fine-tuning for the first gain group (not influence rigidity Po010).

The data of table above is related to the parameter of Po010 rigidity level, check the table above for reference when rigidity selection.

Note: The entry-into-effect time of the parameter is 100ms.

9.3.3 Manual Gain Adjustment

User can make fine adjustment manually when the automatic gain adjustment cannot reach the expected effect.

Table 9.3.2Manual Gain Adjustment Parameter Table

Parameter	Name	Parameter	Name
Po101	1stSpeed loop proportional	Po135	Gain 2 switch to gain 1 delay
10101	gain	10133	time
Po102	1 st Speed loop integral time	Po200	1st current loop bandwidth
Po103	2 nd Speed loop proportional	Po201	2 nd current loop bandwidth
P0103	gain	P0201	
Po104	2 nd Speed loop integral time	Po214	1 st torque filter time constant
Po105	1stSpeed loop time constant	Po215	2 nd torque filter time constant
Po106	2 nd Speed loop filter time	D 201	1 st position loop gain
P0106	constant	Po301	
Po107	Torque feedforward gain	Po302	2 nd position loop gain
Po108	Torque feedforward gain filter	Po303	Position loop feedforward gain
Po130	Gain switching mode	Po306	Position loop filter time constant
Po131	Gain switching speed	Po343	Position mode acel/decel time
Po132	Gain switching pulse	Po229	Notch filter start

Po133	Position loop gain switching time	Po217	1st Notch filter center frequency
Po134	Speed loop gain switching time	Po218	1 st Notch filter width
Po219	1stNotch filter depth	Po220	2 nd Notch filter center frequency
Po221	2 nd Notch filter width	Po222	2 nd Notch filter depth
Po223	3 rd Notch filter center frequency	Po224	3 rd Notch filter width
Po225	3 rd Notch filter depth	Po226	4 th Notch filter center frequency
Po227	4 th Notch filter width	Po228	4 th Notch filter depth
Po240	Low-frequency vibration abatement center frequency	Po241	Low-frequency vibration abatement width
Po242	Low-frequency vibration abatement intensity		

(1) User Parameter Illustration

A) Position Loop Gain

	1st position loop g	ain		PP CSP
	Setting Range	Setting Unit	Mfr's Value	Effect
2003h-02h	1~30000	N/A	-	Immediate
	Function code	Mapping	Data type	Accessibility
	Po301	N	INT16	RW
	2 nd position loop g	gain		PP CSP
	Setting Range	Setting Unit	Mfr's Value	Effect
2003h-03h	1~30000	N/A	-	Immediate
	Function code	Mapping	Data type	Accessibility
	Po302	N	INT16	RW
	Position loop feed	PP CSP		
	Setting Range	Setting Unit	Mfr's Value	Effect
2003h-04h	0~1000	N/A	0	Immediate
	Function code	Mapping	Data type	Accessibility
	Po303	N	INT16	RW
	Position filter time	e constant		PP CSP
2003h-07h	Setting Range	Setting Unit	Mfr's Value	Effect
200511-0711	1~10000	1ms	1	Immediate
	Function code	Mapping	Data type	Accessibility

Po306	N	INT16	PW/
1 0300	1.4	111110	KW

Position loop gain determines position control response. The bigger the setting value, the higher the gain, the larger the rigidity, the better the following feature of position instruction for same frequency pulse, the lower the position error, the shorter the positioning time. But overlarge setting value could cause vibration or position overshoot. Internal servo drive uses feedforward compensation for position control to decrease positioning time, but if the setting value is overlarge, mechanical vibration may occur.

If position control command changes smoothly, increasing gain can reduce position following error; if position control command does not change smoothly, decreasing gain can reduce system vibration.

B) Speed Loop Gain

	1stSpeed loop proj	portional gain	PP PV PT CSP	CSV CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
2001h-02h	0~30000	0.1Hz	600	Immediate
	Function code	Mapping	Data type	Accessibility
	Po101	N	INT16	RW
	1stSpeed loop inte	gral time	PP PV PT CSP	CSV CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
2001h-03h	0~10000	0.1ms	500	Immediate
	Function code	Mapping	Data type	Accessibility
	Po102	N	INT16	RW
	2 nd Speed loop pro	portional gain	PP PV PT CSP	CSV CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
2001h-04h	0~30000	0.1Hz	240	Immediate
	Function code	Mapping	Data type	Accessibility
	Po103	N	INT16	RW
	2 nd Speed loop into	egral time	PP PV PT CSP CS	V CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
2001h-05h	0~30000	0.1ms	1250	Immediate
	Function code	Mapping	Data type	Accessibility
	Po104	N	INT16	RW
	1stSpeed loop time	e constant	PP PV PT CSP CS	V CST HM
2001b 07	Setting Range	Setting Unit	Mfr's Value	Effect
2001h-06h	1~20000	0.01ms		Immediate
	Function code	Mapping	Data type	Accessibility

	Po105	N	INT16	RW
	2 nd Speed loop filt	er time constant	PP PV PT CSP	CSV CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
2001h-07h	1~20000	0.01ms		Immediate
	Function code	Mapping	Data type	Accessibility
	Po106	N	INT16	RW

Speed loop proportional gain determines position control response. The bigger the setting value is, the higher the gain is, the better the following feature of speed instruction is, but ovelarge setting could cause mechanical resonance. The frequency in speed mode control is 4~6 times higher than that in position mode control, when position response frequency is higher than speed response frequency, machine may have shaken or position overshoot. When inertia ratio becomes larger, speed response of control system goes down and becomes unstable, the solution is to increase speed loop gain, but if speed loop gain is too large, motor may have vibration in running or stop status (abnormal sound). Therefore, user must set speed loop gain at 50%~80% of vibration gain. Increasing integral time can reduce acel/decel overshoot; reducing integral time can improve rotation stability. Reducing speed control integral time can improve speed response and narrow speed control error. But too small value may cause vibration and noise. Reduce the noises in speed mode and position mode; Increasing filter time constant can reduce noise but response may become slow.

C) Torque Loop Gain

	1st current loop ba	st current loop bandwidth		P CSV CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
2002h-01h	10~3000	HZ		Immediate
	Function code	Mapping	Data type	Accessibility
	Po200	N	INT16	RW
	2 nd current loop ba	ndwidth	PP PV PT CSP CS	V CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
2002h-02h	10~3000	HZ		Immediate
	Function code	Mapping	Data type	Accessibility
	Po201	N	INT16	RW
	1st torque filter tin	ne constant	PP PV PT CSP CS	V CST HM
2002h-0Fh	Setting Range	Setting Unit	Mfr's Value	Effect
	0~30000	0.01ms		Immediate

	Function code	Mapping	Data type	Accessibility
	Po214	N	INT16	RW
	2 nd torque filter tii	me constant	PP PV PT CSP C	CSV CST HM
	Setting Range	Setting Unit	Mfr's Value	Effect
2002h-10h	0~30000	0.01ms	0	Immediate
	Function code	Mapping	Data type	Accessibility
	Po215	N	INT16	RW

The larger the current loop bandwidth is, the faster the system response is, but noise may be louder conversely.

9.3.4 Gain Switchover

Gain switchover can be triggered by servo drive inside or external DI, which has following effect:

- Switch to lower gain for vibration inhibition in motor standstill state (servo enabled);
- Switch to higher gain to narrow positioning time in motor standstill state;
- Switch to higher gain for obtaining better instruction tracking performance in running state;
- Switch to different gain setting by external signal according to the load condition.

(1) User Parameter

	Gain switching m	ode	PP PV CSP CSV		
	Setting Range	Setting Unit	Mfr's Value	Effect	
2002h-20h	0~6	N/A	0	Immediate	
	Function code	Mapping	Data type	Accessibility	
	Po130	N	INT16	RW	

The setting of Po130 can realize switchover between gain 1 and gain 2 according to different conditions.

Gain 1 includes speed loop proportional gain 1(Po101), speed loop integral time 1(Po102) and position loop proportional gain 1(Po301).

Gain 2 includes speed loop proportional gain 2(Po103), speed loop integral time 2 (Po104) and position loop proportional gain 2(Po346).

Parameter	Content
Po130=0	No switch, default to use gain 1
Po130=1	No switch, default to use gain 2

	Switch to gain 2 immediately when speed is higher than the setting value of
Po130=2	Po131, if speed is lower than Po131, after delay the setting time of
	Po135(0.1ms), switch to gain 1.
D-120 2	Switch terminal control, use gain 1 if the switching terminal defined in CN3
Po130=3	is invalid; use gain 2 if valid.
	Switch to gain 2 immediately when position error is higher than the setting
Po130=4	value of Po132; If lower than Po131, delay the setting time of Po135
	(0.1ms), switch to gain 1.
D 120 5	Switch to gain 2 immediately if there is pulse input; if there is no pulse
Po130=5	input, delay the setting time of Po135(0.1ms), then switch to gain 1.
	Switch to gain 2 immediately if there is pulse input; If there is no pulse
Po130=6	input and the speed is lower than Po131, delay the setting time of
	Po135(0.1ms), then switch to gain 1.

	Gain switching sp	eed	PP PV CS	PCSV	
	Setting Range	Setting Unit	Mfr's Value	Effect	
2001h-20h	1~32000	0.1rpm	100	Immediate	
	Function code	Mapping	Data type	Accessibility	
	Po131	N	INT16	RW	
	Gain switching pu	ılse	PP PV	CSP CSV	
	Setting Range	Setting Unit	Mfr's Value	Effect	
2001h-21h	1~32000	N/A	100	Immediate	
	Function code	Mapping	Data type	Accessibility	
	Po132	N	INT16	RW	
	Positon loop gain	switching time	PP PV	CSP CSV	
	Setting Range	Setting Unit	Mfr's Value	Effect	
2001h-22h	1~32000	0.1ms	20	Immediate	
200111-2211	Function code	Mapping	Data type	Accessibility	
	Po133	N	INT16	RW	
	The time from one gain switching to another gain smoothly.				
	Speed loop gain s	witching time	PP PV	CSP CSV	
	Setting Range	Setting Unit	Mfr's Value	Effect	
2001h-23h	0~20000	0.1ms	100	Immediate	
	Function code	Mapping	Data type	Accessibility	
	Po134	N	INT16	RW	

	The time from one gain switching to another gain smoothly.			
	Gain 2 switch to g	gain 1 delay time	PP PV	CSP CSV
	Setting Range	Setting Unit	Mfr's Value	Effect
	0~32000	0.1ms	1000	Immediate
2001h-24h	Function code Mapping		Data type	Accessibility
	Po135	INT16	RW	
		tches to gain 1, delay the time set by Po135, then switch		
	the time according	g to the setting of P	o133.	

9.4 Vibration Suppression

9.4.1 Vibration Suppression Function

Resonance may produce at about the mechanical resonance frequency when the servo gain is increased, making the gain cannot be increased further.

Mechanical resonance can be suppressed in the following two ways:

1) Torque reference filter (2002h-0Fh and 2002h-10h)

Set the filter time constant to make the torque reference attenuates at above the cutoff frequency, suppressing mechanical resonance.

2) Notch filter

The notch reduces the gain at certain frequency to suppress mechanical resonance. After resonance is suppressed with correct setting of the notch, attempt to increase the gain gradually. The following figure shows the principle of the notch.




Fig 7.4.1Inhibition principle of notch filter

A total of four notches can be used, and each is defined by three parameters, frequency, width level, and depth level. The four notches can be set manually or set as adaptive notches. When they are used as adaptive notches, their parameters are automatically set by the servo drive.

Object	1 st Notch Filter	2 nd Notch Filter	3 rd Notch Filter	4 th Notch Filter
Frequency	2002h-12h	2002h-15h	2002h-18h	2002h-1Bh
Width level	2002h-13h	2002h-16h	2002h-19h	2002h-1Ch
Depth level	2002h-14h	2002h-17h	2002h-1Ah	2002h-1Dh

9.4.2 Suppression of Low-frequency Resonance

If the mechanical load end is long and heavy, vibration may easily occur in this part at emergency stop, affecting the positioning. The frequency of such vibration does not exceed 100 Hz, lower than the mechanical resonance frequency, and is called low frequency resonance. Use the low-frequency resonance suppression function to reduce.




Fig 7.4.2 Low frequency resonance sketch map

(1) User Parameter

	Center frequency of jitter inhibition			PP CSP
	Setting Range	Setting Unit	Mfr's Value	Effect
2002h-29h	50~2000	0.1Hz	2000	Immediate
	Function code	Mapping	Data type	Accessibility
	Po240	N	INT16	RW
	Intensity of jitter inhibition			PP CSP
	Setting Range	Setting Unit	Mfr's Value	Effect
2002h-2Bh	0~100	N/A	0	Immediate
	Function code	Mapping	Data type	Accessibility
	Po242	N	INT16	RW

X. Maintenance and Inspection

10.1 Alarm and Trouble shooting at start

10.1.1 Position control mode

Start-up process	Description	Cause	Countermeasures
		1.Control terminal i disconnected	Rewiring Connect L1C/L2C power cable to socket separately.
Connect control power supply (L1C L2C), main power supply (R S T)	Digital tube is not on or green light is not on	2.Control power supply fault	■ Check the voltage between L1C and L2C
		3. Servo drive fault	Please contact with manufacturer.
	Keypad panel displays 'AL-XXX'	Refer to chapter 10.2 to	o find the cause and solve the problem.
	Keypad panel displays 'AL-XXX'	Refer to chapter 10.2 to	o find the cause and solve the problem.
	Servo motor is in unlocked state	1. Control word is invalid	 Check whether green light is on, if it is not on, taking following step. Check whether RUN green light is lighted, if light is flashing or off, OP mode is not arrived. Check whether master and slave XML document is set correctly.
Servo drive is enabled by		2. Control mode is wrong	■ Select communication mode.
control word	Servo motor is galloping.		 Encoder cable fault 1. Check whether Lo-04 value is correct when motor rotates 1 revolution. 2. Check whether servo drive trips into AL-17 U/V/W motor cable fault. 1. Check whether U/V/W wiring is correct. 2. If wiring is correct, please study motor angle.
	Low speed rotation is not stable.	Gain is set improperly.	■ Adjust gain according to chapter 9.
Rotation is not smooth at low speed.	Motor shaft vibrates side to side.	Rotation inertia ratio (Po013) is too high.	 If servo drive runs safely, please recognize inertia again according to chapter 9.2. Adjust gain according chapter 9.

Normal run	Location is not accurate.	There is position error.	 Pulse received by Lo-08 is not same as the one sent by PC/PLC 1. Check whether servo grounding is reliable. 2. Check whether signal cable is twisted-pair shield cable, whether shielding layer is connected to housing correctly. Check whether motor shaft coupler is locked tightly. Check whether device has vibration. Adjust the gain according to chapter 9.
------------	---------------------------	--------------------------	--

10.2 Alarm code and possible cause

Code	Alarm code	Alarm name	Possible Cause
1	AL-01	Overcurrent	Output short-circuit or module malfunction
2	AL-02	Overvlotage	Main circuit DC voltage is too high.
3	AL-03	Undervoltage	Main circuit DC voltage is too low
4	AL-04	Hardware failure	Hardware failure inside drive
5	AL-05	Electric angle recognition error	Motor cable sequence error
6	AL-06	Motor Overload	High current is output for long time.
7	AL-07	Overspeed	Speed is too high
8	AL-08	Servo drive overload	High current is output for long time.
9	AL-09	Position loop trace error overflow	Position loop trace error overflow
10	AL-10	Encoder abnormal	Servo motor encoder is damaged.
11	AL-11	Emergency stop	External emergency stop terminal is valid
12	AL-12	Servo drive overheat	Temperature of servo drive radiator is too high
13	AL-13	Power supply phase loss of main circuit	In the state of power supply connection of main circuit, the voltage of one phase in three-phase power supply is too low.
14	AL-14	Energy consumption error	Brake parameters aren't set correct or continuous brake time is too long.
15	AL-15		
16	AL-16	Wrong setting of input terminal	Duplicate definition of input terminals
17	AL-17	Disconnection of encoder cable	Disconnection of servo encoder cable

1.0	17.10	Rotation inertia recognition	Alarm when wrong rotary inertia
18	AL-18	wrong	recognition
19	AL-19	Alarm of encoder battery	Battery alarm of servo encoder
20	AL-20	Uninitialized of E2ROM	Uninitialized of E2ROM for servo motor
21	AL-21		
22	AL-22		
23	AL-23	Torque unreached protection	The deviation between given torque and output torque is too large.
24	AL-24	Battery undervoltage	Battery undervoltage alarm
25	AL-25		
26	AL-26		
27	AL-27	Overtravel	Overtravel alarm
28	AL-28	E ² ROM	E2ROM error
29	AL-29	Leakage protection	Servo drive or motor has electric leakage.
30	AL-30	Motor locked-rotor protection	Motor is locked-rotor.
31	AL-31	Mixed error of full closed-loop	Mixed error of full closed-loop is too large
32	AL-32		
33	AL-33		
34	AL-34		
35	AL-35	Home searching overtime	Homing search is overtime
36	AL-36	Parameter copy error	Parameter copy error
37	AL-37	Network initialization failed	EEPROM is writen or hardware fault
38	AL-38	OP abnormal protection	Communication abnormal protection in OP mode
39	AL-39	Synchronous signal loss	Synchronous signal loss
40	AL-40	Synchronous period setting fault	Synchronous period setting fault

10.3 Alarm Code and Trouble shooting

ACAUTION

- ★ Do not reset immediately when servo drive malfunctions. At first find the causation and eliminate completely.
- ★ Process failure according to the manual when drive or servo motor malfunctions. Please contact with distributors or manufacturer directly if problem still cannot be solved. Do not maintain without authorization.

Alarm Code	Alarm Name	Possible Cause	Treatment
		Main circuit wiring error	Modify wiring
		Output short-circuit	Cable may be short-circuit, repair or replace it.
AL-01	Overcurrent	Short-circuit inside of servo drive or grounding short-circuit	Repair or replace servo drive
		Malfunction because of interference	Adopt anti-interference method, improve wiring.
		Servo drive malfunction	Repair or replace servo drive
		Power supply is too high	Check rated voltage.
	Overvoltage	Load rotation inertia is too large	Prolong deceleration time
AL-02			Select external brake resistor
			Reduce load
			Increase capacity of drive
			Check power supply
AL-03	Under-voltage	Input voltage is low	Check if power supply of main circuit is powered on.
AL-04	Hardware fault	Hardware fault inside drive	Contact with manufacturer
AL-05	Electric angle recognition error	Motor cable sequence error	Adjust cable sequences, exchange two of phases.

		Poor contact of servo motor wiring or encoder wiring	Check servo motor and encoder wiring
		Mechanical factors	Check the transmission ratio of machine.
AL-06	Servo motor overload	With electromagnetic brake unreleased, servo motor is running	Check the wiring of electromagnetic brake.
			Reduce load
		Load too heavy	Increase the capacity of drive
AL-07	Over-speed	Servo motor speed is higher than max speed	Servo motor cable or encoder cable wiring is wrong, please check it.
AL-08	Servo drive overload	High current is output for long time.	Check servo motor and encoder wiring. Decrease load. Increase servo drive capacity
	Position loop trace error overflow	Servo motor U, V, W or encoder wiring is wrong, or connector is not connected well	Check the wiring.
AL-09		Servo drive gain is low.	Increase gain, adjust speed and position gain
		The frequency of position pulse command is too high	Reduce pulse frequency or adjust electronic gear
AT 10	Encoder	Encoder disconnected or servo motor locked-rotor	Check encoder wiring.
AL-10	abnormal	Servo motor failure	Power on again, if alarm still occurs, please contact with manufacture.
A.V. da	Emergency stop	Input terminal logic is not corresponding to wiring	Check wiring or modify terminal logic
AL-11		Hardware damage of input terminal with ESP function	Set the function to other input terminal or contact with manufacturer

		Environment temperature is too high	Improve ventilation
		Dirty radiator.	Clean air outlet and radiator.
		Foreign matters in fan	Clear out foreign matters
AL-12	Servo drive	Fan damage	Replace fan
1.2.12	overheat	Improper installation of drive, such as poor ventilation or wrong installation direction.	Install as required
		Too heavy load	
AL-13	Power supply phase loss of	Discharge energy is too large When main circuit is powered on, one phase voltage of three is too low.	Check phase loss of input power supply.
	main circuit	Use single-phase power supply.	Check parameter setting
	Energy	Wrong braking resistor parameter	Modify parameter value
AL-14	consumption error	Continuous brake time is too long	Check load, servo drive only can drive non-potential energy load.
AL-16	Duplicate setting of input terminal	Duplicate definition of input terminals	Reset to avoid duplicate definition
AL-17	Encoder cable disconnected	Encoder cable disconnected	Encoder cable disconnected
AL-18	Rotation inertia recognition fault	Rotation inertia recognition fault	Turn up Po013 manually
AL-19	Alarm of encoder battery	Battery alarm of encoder	1. Check whether encoder cable is connected normally. If cable is disconnected, connect again and reset alarm. 2. Check whether battery capacity is 3.6V. If it is lower than 3.2V, change battery and reset alarm when servo drive control power is ON state. 3. Shielding AL-19: So-38=1, So-43=1 reset alarm. 4. Check whether the wiring of battery is reliable if user makes cable by himself.

AL-20	Uninitialized of E2ROM	Uninitialized of E2ROM for servo motor	Uninitialized process for encoder of servo motor, learn motor angle manually.
AL-21	Reserved		
AL-22	Reserved		
AL-23	Torque unreached protection	Motor cable or power cable disconnected	Please check motor cable or encoder cable wiring.
AL-24	Battery undervoltage	Battery undervoltage alarm	1. If users don't replace a new battery in time or power supply of encoder is abnormal, alarm of AL-24 will happen and encoder current position will be lost. User must reset mechanical origin to eliminate it. 2. Shielding AL-24: So-48=1, So-41=1(set current position as mechanical origin), So-43=1 reset alarm, PC/PLC will reset mechanical origin.
AL-25	Motor overheat	Motor temperature is too high.	Improve ventilation
AL-26	Temperature detection circuit is disconnected	Temperature detection circuit is disconnected	Check the connection.
AL-27	Overtravel	Overtravel alarm	Setting range of FWD/FEV for overtravel protection.
AL-28	E ² ROM error	E2ROM error	Contact with manufacturer
AL-29	Leakage protection	Leakage protection	Servo drive or motor has electric leakage.
AL-30	Motor locked-rotor protection	Locked-rotor in motor running state	1. Check whether mechanical structure is blocked; 2. Check whether motor power cable is loosened; 3. Locked-tutor 4. Load is too heavy, exceeding motor allowed torque; 5. Wiring of motor power cable is wrong

		Po377, Po378 and Po380 is not suitable.	Check Po377, Po378 and Po380 value.
		Mechanical transmission part has large gap or not fastened	Check mechanical transmission part
AL-31	Mixed error of full closed-loop is	Servo motor U, V, W terminal or encoder wiring is wrong or connector contact is poor	Check the wiring of servo motor and encoder
	too large	Lack or wrong wiring of mechanical terminal encoder	Check the wiring of mechanical terminal encoder
		Servo drive gain is low	Increase gain, refer to the gain of speed and position
		Mechanical termination encoder wiring is not well	Check mechanical termination encoder wiring.
AL-32	Reserved		
AL-33	Reserved		
AL-34	Reserved		
AL-35	Home searching overtime	Home searching overtime	Check wiring.
	overtime		Check servo drive.
AL-36	Parameter copy error	Parameter copy error	Check the parameter setting.
AL-37	Network initialization failed	EEPROM is written or hardware fault	Check E ² PROM
AL-38	OP abnormal protection	Communication abnormal protection in OP mode	Check the link
AL-39	Synchronous signal loss	Synchronous signal loss	Synchronous signal loss
AL-40	Synchronous period setting fault	Synchronous period is too small	Increase synchronous period

10.3.1 Other malfunctions

Malfunction	Cause	Measure
	Main circuit power supply is disconnected.	Check the wiring.
	Control circuit power supply is disconnected.	Check the wiring.
	The wiring of I/O terminal is wrong.	Check the wiring.
	The wiring of servo motor or encoder is wrong.	Check the wiring.
Servo motor	Control command is not input.	Input control command correctly.
does not run.	Some wrong using of input/output terminal. For example: servo on terminal is disconnected or it is defined wrong.	Define and use control terminal correctly.
	Forward/reverse rotation prohibited.	Make the function of forward/reverse rotation prohibited invalid.
	Torque limited.	Check the parameters and interface of torque limited function.
	Servo drive fault.	Maintain or replace servo drive.
Servo motor	Servo motor wiring is wrong.	Check the wiring.
moves instantaneously and then stops	Servo drive fault.	Please contact with manufacturer.
	Maynting not seemed	Check mounting screws and tighten
	Mounting not secured	Align the couplings.
A has a series of	Wrong parameters setting	Check servo drive parameters.
Abnormal noise from servo motor	Defective bearings	Replace servo motor.
	Driven machine fault	Check whether there are any foreign matters, damages or deformation on the machine section.
	Encoder fault	Check whether encoder cable is damaged.

XI Appendix

11.1 Encoder cable selection

11.1.1 Absolute encoder cable

Encoder cable with round plug (applicable for 80 flange and below 80 flange servo motor)

Name	Model	Length	Cable appearance
	DB9-4BS02-3M-0.2	3M	Battery
	DB9-4BS02-5M-0.2	5M	box box
Encoder cable (for function	DB9-4BS02-10M-0.2	10M	
code D70, D71)	DB9-4GS02-3M-0.2	3M	
	DB9-4GS02-5M-0.2	5M	L±15
	DB9-4GS02-10M-0.2	10M	

Encoder cable with L aviation plug (applicable for 110, 130 and 180 flange servo motor)

Name	Model	Length	Cable appearance
	DB9-4BS03-3M-0.2	3M	Battery
	DB9-4BS03-5M-0.2	5M	L±15mm
Encoder cable (for function	DB9-4BS03-10M-0.2	10M	
code D70, D71)	DB9-4GS03-3M-0.2	3M	L±15mm

11.1.2 Incremental encoder cable

Encoder cable with DB plug (applicable for 80 flange and below 80 flange servo motor)

Name	Model	Length	Cable appearance
15-core	DB15-15GP02-3M-0.2	3M	Servo drive Encoder
encoder cable (for	DB15-15GP02-5M-0.2	5M	side side
D50)	DB15-15GP02-10M-0.2	10M	
8-core	DB15-8GP02-3M-0.2	3M	
encoder cable (for	DB15-8GP02-5M-0.2	5M	
D51)	DB15-8GP02-10M-0.2	10M	
4-core	DB9-4GS02-3M-0.2	3M	
encoder cable (for	DB9-4GS02-5M-0.2	5M	
D52)	DB9-4GS02-10M-0.2	10M	L±15

Encoder cable with L aviation plug (applicable for 110, 130 and 180 flange servo motor)

Name	Model	Length	Cable appearance
15-core	DB15-15GP01-3M-0.2	3M	
encoder cable (for	DB15-15GP01-5M-0.2	5M	g in an
D50)			
8-core	DB15-8GP01-3M-0.2	3M	L±15mm
encoder cable (for	DB15-8GP01-5M-0.2	5M	The state of the s
D51)	DB15-8GP01-10M-0.2	10M	
4-core	DB9-4GS03-3M-0.2	3M	
encoder cable (for	DB9-4GS03-5M-0.2	5M	L±15mm
D52)	DB9-4GS03-10M-0.2	10M	

Encoder cable with I aviation plug (applicable for servo motor with base No.E,F)

Name	Model	Length	Cable appearance
15-core	DB15-15GP03-3M-0.2	3M	G-10
encoder cable (for	DB15-15GP03-5M-0.2	5M	
D50)	DB15-15GP03-10M-0.2	10M	L±15
8-core	DB15-8GP03-3M-0.2	3M	-

encoder	DB15-8GP03-5M-0.2	5M
cable (for D51)	DB15-8GP03-10M-0.2	10M

11.1.3 Resolver encoder cable

Encoder cable with Laviationplug (applicable for 180 flange and below 180 flange motor)

Name	Model	Length	Cable appearance
Encoder cable	DB9-8GR01-3M-0.2	3M	
(applicable	DB9-8GR01-5M-0.2	5M	
function code D2)	DB9-8GR01-10M-0.2	10M	L±15mm——

Encoder cable with I aviationplug (applicable for servo motor with base No. E, F)

Name	Model	Length	Cable appearance
Encoder cable	DB9-8GR02-3M-0.2	3M	
(applicable function	DB9-8GR02-5M-0.2	5M	L±15
code D2)	DB9-8GR02-10M-0.2	10M	C213

11.2 Control cable


Name	Model	Length	Appearance
	DB44-15PC-1M-0.2	1M	
Control cable	DB44-15PC-2M-0.2	2M	Marked tube
	DB44-15PC-3M-0.2	3M	

11.3 Power cable

Applicable for flange≤80 servo motor

Name	Model	Length	Appearance
Power cable	DB4-4PO-*M- diameter	*M means length	L±20

Applicable for flange 110,130,180 servo motor



Note: aviation plug is used for servo motor with flange above 110. Servo motor with 180 flange has large current, so the line diameter should be larger, named as "HK4B-4P0-*M-diameter". Except servo motor with 180 flange, other cables are named as "HK4A-4P0-*M-diameter". For M1 and M2 structure of 220V servo drive, the name of cable should add –B, for M2 structure of 380V servo drive, the name of cable should add –H.

Applicable for 180 spigpot and 250 spigpot servo motor

Name	Model	Length	Appearance
Power cable	ZL4-4PO-*M- diameter	*M means length	L±10

Note:

- ★ ZL4-4PO-XXX is single strand cable, grounding cable is yellow-green cable of 2.5 mm².
- ★ 180 spigpot and 250 spigpot servo motors have copper terminal for spare part, if user purchases copper terminal, please refer to following data:

Motor	Copper terminal
Motor rated power 11KW	6-8
Motor rated power 15KW-18.5KW	10-8
Motor rated power 22KW-30KW	16-8
Motor rated power 37KW	25-8

11.4 Shielded network cable

EtherCAT communication rate can reach to 100MB frequency. To make sure communication reliability, we recommend following EtherCAT communication cable:

Name	Model	Length	Appearance	
Shielded network cable	SC-ECT** M-C	According to requirement	label	

In cable model, **M means ** meter, user can select cable length. As shown in the figure, cable length is L (unit is cm), error is ± 2 cm. For example, 30cm cable model is SC-ECT0.3M-C.

Ethernet Category 5 (100BASE-TX) network cable or high-strength shielded network cable is used as the EtherCAT communication cable. The double-layer shielded network cable is recommended for servo drive. When EtherCAT communication is selected, the single network cable between any two of servo drive should not be longer than 50 meters; good network cable can improve anti-interference capability between master station and servo drive.

Direct-through or crossover Ethernet cables are allowable. Cable characteristic impedance is $100\Omega\pm5\%$ (characteristic frequency below 1000MHz). The double-layer shielded 100M-Ethernet enhanced category 5 or better network cable is recommended.

11.5 Other cable

Communication cable

Name	Model	Length	Appearance
Communication cable	1394-2TR-*M-0.3	*M means length	None

Motor brake cable

Name	Model	Length	Appearance	
Brake cable	HK3-2BR-*M-0.75	Actual length	VIE OND They of motor take Suitable for 80, 110, 130, 180 flange brake servo motor	
Brake cable	DB2-2BR-*M-0.75	Actual length	OND Plug of motor side Suitable for 60 flange brake servo motor	

11.6 Motor and matched cable

(1) 220V servo motor series

Motor model		Servo drive model		Power cable model
	SMSA-201*32***	SD20-E201S2M1	SD20-E201T2M1	
	SMSA-401*32***	SD20-E401S2M1	SD20-E401T2M1	DB4-4PO-*M-0.75-B
	SMSA-751*33***	SD20-E751S2M1	SD20-E751T2M1	
CMC :	SMSA-102*33***	SD20-E102S2M2	SD20-E102T2M2	DD4 4DO *M 1 0 D
SMS series 3000r/min	SMSA-122*35***	SD20-E122S2M2	SD20-E122T2M2	DB4-4PO-*M -1.0-B
30001/111111	SMSA-152*37***	CD20 E192C2M2	CD20 E192T2M2	HK4A-4PO-*M-1.5-B
	SMSA-182*35***	SD20-E182S2M2	SD20-E182T2M2	HK4A-4PO-*M-2.5-B
	SMSA-232*37***	_	SD20-E302T2M3	HK4A-4PO-*M-2.5
	SMSA-302*37***	_	SD20-E452T2M3	HK4A-4PO-*M-4.0
SMS series 2500r/min	SMSB-102*33***	SD20-G/E102S2M2	SD20-G/E102T2M2	DB4-4PO-*M -1.5
	SMMA-801*35**	GD 40 F102G2142	SD20-E102T2M2	HK4A-4PO-*M-0.75-B
	SMMA-851*37**	SD20-E102S2M2		HK4A-4PO-*M-1.0-B
	SMMA-102*37**	SD20-E122S2M2	SD20-E122T2M2	HK4A-4PO-*M-1.0-B
	SMMA-122*35**			
SMM series	SMMA-132*37**	CD20 E192C2M2	SD20-E182T2M2	HK4A-4PO-*M-1.5-B
2000r/min	SMMA-152*37**	SD20-E182S2M2		
	SMMA-202*37**	_	SD20-E302T2M3	HK4A-4PO-*M-2.5
	SMMA-312*37**	_	GD20 F452T2M2	HW4D 4DO *M 4.0
	SMMA-352*3A**	_	SD20-E452T2M3	HK4B-4PO-*M-4.0
	SMMA-452*3A***	_	SD20-G/E552T2M4	HK4B-4PO-*M-6.0
	SMMB-122*37**	SD20-E122S2M2	SD20-E122T2M2	HK4A-4PO-*M-1.0-B
SMM series 1500r/min	SMMB-152*37**	SD20-E182S2M2	SD20-E182T2M2	HK4A-4PO-*M-1.5-B
	SMMB-232*37**	_	SD20-E302T2M3	HK4A-4PO-*M-2.5
	SMMB-272*3A**			HK4B-4PO-*M-2.5
	SMMB-302*3A**		SD20-E452T2M3	HV4D 4DO *M 4 0
	SMMB-432*3A**		SD20-E452T2M3	HK4B-4PO-*M-4.0
	SMMB-552*3A***	_	SD20-G/E552T2M4	HIVAD ADO *M CO
	SMMB-752*3A***	_	SD20-G/E752T2M4	HK4B-4PO-*M-6.0

	SMLA-102*37**	SD20-E102S2M2	SD20-E102T2M2	HK4A-4PO-*M-1.0-B
SML series 1000r/min	SMLA-152*37**	SD20-E182S2M2	SD20-E182T2M2	HK4A-4PO-*M-1.5-B
	SMLA-292*3A**	_	SD20-E302T2M3	HK4B-4PO-*M-2.5
	SMLA-372*3A**	_	SD20-E452T2M3	HK4B-4PO-*M-4.0

(2) 380V servo motor series

Motor model		Servo drive model	Power cable model
	SMSA-751*63***	GD20 F102F2M2	DD4 4D0 *M 0.75 H
	SMSA-102*63***	SD20-E102T3M2	DB4-4PO-*M-0.75-H
SMS	SMSA-122*65***		HK4A-4PO-*M-1.0
series	SMSA-152*67***	SD20-E202T3M3	HK4A-4PO-*M-1.0
3000r/min	SMSA-182*65***		HK4A-4PO-*M-1.5
	SMSA-232*67***	SD20-E302T3M3	HK4A-4PO-*M-1.5
	SMSA-302*67***	SD20-E452T3M3	HK4A-4PO-*M-2.5
	SMMA-801*65**		
	SMMA-851*67**	SD20-E102T3M2	
	SMMA-102*67**		HK4A-4PO-*M-0.75-H
	SMMA-122*65**	GD20 F1 52F21 62	
	SMMA-132*67**	SD20-E152T3M2	
104	SMMA-152*67**	GD20 F202F21 (2	HK4A-4PO-*M-1.0
MM series	SMMA-202*67**	SD20-E202T3M3	HK4A-4PO-*M-1.5
2000r/min	SMMA-312*67**		HK4A-4PO-*M-2.5
	SMMA-352*6A**	SD20-E452T3M3	HK4B-4PO-*M-2.5
	SMMA-452*6A**		HK4B-4PO-*M-2.5
	SMMA-602*6A**	GD20 F752F21 0 44	HK4B-4PO-*M-4.0
	SMMA-752*6A**	SD20-E752T3MM4	
	SMMA-103*6A**	SD20-E153T3M4	HK4B-4PO-*M-6.0
	SMMB-122*67**	SD20-E152T3M2	THE A ADO SEE TO
SMM	SMMB-152*67**	GD20 F202F21 (2	HK4A-4PO-*M-1.0
series	SMMB-232*67**	SD20-E202T3M3	HK4A-4PO-*M-1.5
1500r/min	SMMB-302*67**	SD20-E302T3M3	HK4A-4PO-*M-2.5
	SMMB-272*6A**	SD20-E302T3M3	HK4B-4PO-*M-2.5

-	SMMB-302*6A**	CD20 E202T2M2	
		SD20-E302T3M3	
	SMMB-432*6A**	SD20-E452T3M3	
	SMMB-552*6A**	SD20-E552T3M3	
	SMMB-752*6A**	SD20-E752T3MM4	HK4B-4PO-*M-4.0
	SM15-0100*6EE*FL	SD20-E113T3MM4	ZL4-4PO-*M-6.0
	SM15-0124*6EE*FL	SD20-E153T3M4	ZL4-4PO-*M-6.0
	SM15-0160*6EE*FL	SD20 E192T2M5	ZL4-4PO-*M-10.0
	SM15-0180*6EE*FL	SD20-E183T3M5	ZL4-4PO-*M-10.0
	SM15-0210*6FE*FL	SD20-E223T3M5	ZL4-4PO-*M-10.0
	SM15-0240*6EE*FL	SD20-E303T3M6	ZL4-4PO-*M-16.0
	SM15-0290*6FE*FL	SD20-E303T3M6	ZL4-4PO-*M-16.0
	SM15-0350*6FE*FL	SD20-E373T3M6	ZL4-4PO-*M-25.0
SML	SMLA-372*6A**	SD20-E452T3M3	HK4B-4PO-*M-2.5
series	SMLA-102*67**	SD20-E152T3M2	HK4B-4PO-*M-0.75-B
1000r/min	SMLA-292*6A**	SD20-E302T3M3	HK4B-4PO-*M-1.5
	SM17-0092*6EE*FL	SD20-E113T3MM4	ZL4-4PO-*M-6.0
	SM17-0110*6EE*FL	SD20-E113T3MM4	ZL4-4PO-*M-6.0
SMM	SM17-0140*6EE*FL	SD20-E153T3M4	ZL4-4PO-*M-6.0
series	SM17-0180*6EE*FL	SD20-E183T3M5	ZL4-4PO-*M-10.0
1700r/min	SM17-0210*6FE*FL	SD20-E223T3M5	ZL4-4PO-*M-10.0
	SM17-0240*6EE*FL	SD20-E303T3M6	ZL4-4PO-*M-16.0
	SM17-0270*6EE*FL	SD20-E303T3M6	ZL4-4PO-*M-16.0
	SM17-0330*6FE*FL	SD20-E373T3M6	ZL4-4PO-*M-25.0
	SM20-0100*6EE*FL	SD20-E113T3MM4	ZL4-4PO-*M-6.0
	SM20-0140*6EE*FL	SD20-E153T3M4	ZL4-4PO-*M-6.0
	SM20-0180*6EE*FL	SD20-E183T3M5	ZL4-4PO-*M-10.0
	SM20-0220*6EE*FL	SD20-E223T3M5	ZL4-4PO-*M-10.0
series 2000r/min	SM20-0250*6EE*FL	SD20 E202T2M6	ZL4-4PO-*M-16.0
	SM20-0280*6EE*FL	SD20-E303T3M6	ZL4-4PO-*M-16.0
	SM20-0300*6EE*FL	SD20 E272T2M6	ZL4-4PO-*M-16.0
	SM20-0360*6FE*FL	SD20-E373T3M6	ZL4-4PO-*M-25.0